
Adafruit BNO055 Library Documentation

Release 1.0

Radomir Dopieralski

Jan 27, 2020

Contents

1	Dependencies	3
2	Installing from PyPI	5
3	Usage Notes	7
4	Contributing	9
5	Documentation	11
6	Table of Contents	13
6.1	Simple test	13
6.2	adafruit_bno055 - Adafruit 9-DOF Absolute Orientation IMU Fusion Breakout - BNO055 . . .	14
7	Indices and tables	17
	Python Module Index	19
	Index	21

CHAPTER 1

Dependencies

This driver depends on the [Register](#) and [Bus Device](#) libraries. Please ensure they are also available on the CircuitPython filesystem. This is easily achieved by downloading [a library and driver bundle](#).

CHAPTER 2

Installing from PyPI

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-bno055
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-bno055
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name  
python3 -m venv .env  
source .env/bin/activate  
pip3 install adafruit-circuitpython-bno055
```


CHAPTER 3

Usage Notes

Of course, you must import the library to use it:

```
import adafruit_bno055
```

This driver takes an instantiated and active I2C object (from the `busio` or the `bitbangio` library) as an argument to its constructor. The way to create an I2C object depends on the board you are using. For boards with labeled SCL and SDA pins, you can:

```
from busio import I2C
from board import SDA, SCL

i2c = I2C(SCL, SDA)
```

Once you have the I2C object, you can create the sensor object:

```
sensor = adafruit_bno055.BNO055(i2c)
```

And then you can start reading the measurements:

```
print(sensor.temperature)
print(sensor.euler)
print(sensor.gravity)
```


CHAPTER 4

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 5

Documentation

For information on building library documentation, please check out [this guide](#).

CHAPTER 6

Table of Contents

6.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/bno055_simpletest.py

```
1 import time
2 import board
3 import busio
4 import adafruit_bno055
5
6 i2c = busio.I2C(board.SCL, board.SDA)
7 sensor = adafruit_bno055.BNO055(i2c)
8
9 while True:
10     print('Temperature: {} degrees C'.format(sensor.temperature))
11     print('Accelerometer (m/s^2): {}'.format(sensor.acceleration))
12     print('Magnetometer (microteslas): {}'.format(sensor.magnetic))
13     print('Gyroscope (rad/sec): {}'.format(sensor.gyro))
14     print('Euler angle: {}'.format(sensor.euler))
15     print('Quaternion: {}'.format(sensor.quaternion))
16     print('Linear acceleration (m/s^2): {}'.format(sensor.linear_acceleration))
17     print('Gravity (m/s^2): {}'.format(sensor.gravity))
18     print()
19
20     time.sleep(1)
```

6.2 adafruit_bno055 - Adafruit 9-DOF Absolute Orientation IMU Fusion Breakout - BNO055

This is a CircuitPython driver for the Bosch BNO055 nine degree of freedom inertial measurement unit module with sensor fusion.

- Author(s): Radomir Dopieralski

```
class adafruit_bno055.BNO055(i2c, address=40)
```

Driver for the BNO055 9DOF IMU sensor.

acceleration

Gives the raw accelerometer readings, in m/s. Returns an empty tuple of length 3 when this property has been disabled by the current mode.

calibrated

Boolean indicating calibration status.

calibration_status

Tuple containing sys, gyro, accel, and mag calibration data.

euler

Gives the calculated orientation angles, in degrees. Returns an empty tuple of length 3 when this property has been disabled by the current mode.

external_crystal

Switches the use of external crystal on or off.

gravity

Returns the gravity vector, without acceleration in m/s. Returns an empty tuple of length 3 when this property has been disabled by the current mode.

gyro

Gives the raw gyroscope reading in radians per second. Returns an empty tuple of length 3 when this property has been disabled by the current mode.

linear_acceleration

Returns the linear acceleration, without gravity, in m/s. Returns an empty tuple of length 3 when this property has been disabled by the current mode.

magnetic

Gives the raw magnetometer readings in microteslas. Returns an empty tuple of length 3 when this property has been disabled by the current mode.

mode

Switch the mode of operation and return the previous mode.

Mode of operation defines which sensors are enabled and whether the measurements are absolute or relative. If a sensor is disabled, it will return an empty tuple.

legend: x=on, -=off +-----+---+---+---+ | Mode | Accel | Compass
| Gyro | Absolute | +=====+=====+=====+=====+=====+
| CONFIG_MODE | - | - | - | - | +-----+---+---+---+ | AC-
ONLY_MODE | X | - | - | - | +-----+---+---+---+ | MAGONLY_MODE
| - | X | - | - | +-----+---+---+---+ | GYRONLY_MODE | - |
- | X | - | +-----+---+---+---+ | ACCMAG_MODE | X | X |
- | - | +-----+---+---+---+ | ACCGYRO_MODE | X | - | X |
- | +-----+---+---+---+ | MAGGYRO_MODE | - | X | X | - |

```
+-----+-----+-----+-----+-----+-----+-----+-----+
| AMG_MODE | X | X | X | - | +-----+
+-----+-----+-----+-----+-----+-----+-----+-----+
| IMUPLUS_MODE | X | - | X | - | +-----+
+-----+-----+-----+-----+-----+-----+-----+
| COMPASS_MODE | X | X | - | X | +-----+
+-----+-----+-----+-----+-----+-----+-----+
| M4G_MODE | X | X | - | - | +-----+
+-----+-----+-----+-----+-----+-----+-----+
| NDOF_FMC_OFF_MODE| X | X | X | X | +-----+
+-----+-----+-----+-----+-----+-----+-----+
| NDOF_MODE | X | X | X | X | +-----+
+-----+-----+-----+-----+-----+-----+
```

The default mode is NDOF MODE.

offsets_accelerometer

Calibration offsets for the accelerometer

offsets_gyroscope

Calibration offsets for the gyroscope

offsets_magnetometer

Calibration offsets for the magnetometer

quaternion

Gives the calculated orientation as a quaternion. Returns an empty tuple of length 3 when this property has been disabled by the current mode.

radius accelerometer

Radius for accelerometer (cm?)

radius magnetometer

Radius for magnetometer (cm?)

temperature

Measures the temperature of the chip in degrees Celsius

use external crystal

_external_crystal Switches the use of external crystal on or off

CHAPTER 7

Indices and tables

- genindex
- modindex
- search

Python Module Index

a

adafruit_bno055, 13

Index

A

acceleration (*adafruit_bno055.BNO055 attribute*), 14
adafruit_bno055 (*module*), 13

B

BNO055 (*class in adafruit_bno055*), 14

C

calibrated (*adafruit_bno055.BNO055 attribute*), 14
calibration_status (*adafruit_bno055.BNO055 attribute*), 14

E

euler (*adafruit_bno055.BNO055 attribute*), 14
external_crystal (*adafruit_bno055.BNO055 attribute*), 14

G

gravity (*adafruit_bno055.BNO055 attribute*), 14
gyro (*adafruit_bno055.BNO055 attribute*), 14

L

linear_acceleration (*adafruit_bno055.BNO055 attribute*), 14

M

magnetic (*adafruit_bno055.BNO055 attribute*), 14
mode (*adafruit_bno055.BNO055 attribute*), 14

O

offsets_accelerometer
(*adafruit_bno055.BNO055 attribute*), 15
offsets_gyroscope (*adafruit_bno055.BNO055 attribute*), 15
offsets_magnetometer
(*adafruit_bno055.BNO055 attribute*), 15

Q

quaternion (*adafruit_bno055.BNO055 attribute*), 15

R

radius_accelerometer
(*adafruit_bno055.BNO055 attribute*), 15
radius_magnetometer (*adafruit_bno055.BNO055 attribute*), 15

T

temperature (*adafruit_bno055.BNO055 attribute*), 15

U

use_external_crystal
(*adafruit_bno055.BNO055 attribute*), 15