
Adafruit INA219 Library Documentation

Release 1.0

Dean Miller

Dec 21, 2018

Contents

1	Dependencies	3
2	Usage Example	5
3	Contributing	7
4	Building locally	9
4.1	Sphinx documentation	9
5	Table of Contents	11
5.1	Simple test	11
5.2	adafruit_ina219	11
5.2.1	Implementation Notes	12
6	Indices and tables	13
	Python Module Index	15

CircuitPython driver for the [INA219](#) current sensor.

CHAPTER 1

Dependencies

This driver depends on:

- Adafruit CircuitPython
- Bus Device

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

CHAPTER 2

Usage Example

see example

CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Building locally

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-ina219 --library_
↪location .
```

4.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.

CHAPTER 5

Table of Contents

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/ina219_simpletest.py

```
1 import time
2
3 from board import SCL, SDA
4 import busio
5
6 import adafruit_ina219
7
8 i2c_bus = busio.I2C(SCL, SDA)
9
10 ina219 = adafruit_ina219.INA219(i2c_bus)
11
12 print("ina219 test")
13
14 while True:
15     print("Bus Voltage: {} V".format(ina219.bus_voltage))
16     print("Shunt Voltage: {} mV".format(ina219.shunt_voltage / 1000))
17     print("Load Voltage: {} V".format(ina219.bus_voltage + ina219.shunt_voltage))
18     print("Current: {} mA".format(ina219.current))
19     print("")
20
21     time.sleep(2)
```

5.2 adafruit_ina219

CircuitPython driver for the INA219 current sensor.

- Author(s): Dean Miller

5.2.1 Implementation Notes

Hardware:

- Adafruit INA219 High Side DC Current Sensor Breakout
- Adafruit INA219 FeatherWing

Software and Dependencies:

- Adafruit CircuitPython firmware (2.2.0+) for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: https://github.com/adafruit/Adafruit_CircuitPython_BusDevice

```
class adafruit_ina219.INA219(i2c_bus, addr=64)
    Driver for the INA219 current sensor
```

bus_voltage
The bus voltage (between V- and GND) in Volts

current
The current through the shunt resistor in millamps.

set_calibration_16V_400mA()
Configures to INA219 to be able to measure up to 16V and 400mA of current. Counter overflow occurs at 1.6A.

Note: These calculations assume a 0.1 ohm shunt resistor is present

set_calibration_32V_1A()
Configures to INA219 to be able to measure up to 32V and 1A of current. Counter overflow occurs at 1.3A.

Note: These calculations assume a 0.1 ohm shunt resistor is present

set_calibration_32V_2A()
Configures to INA219 to be able to measure up to 32V and 2A of current. Counter overflow occurs at 3.2A.

..note :: These calculations assume a 0.1 shunt ohm resistor is present

shunt_voltage
The shunt voltage (between V+ and V-) in Volts (so +-327V)

CHAPTER 6

Indices and tables

- genindex
- modindex
- search

Python Module Index

a

adafruit_ina219, 11

Index

A

adafruit_ina219 (module), [11](#)

B

bus_voltage (adafruit_ina219.INA219 attribute), [12](#)

C

current (adafruit_ina219.INA219 attribute), [12](#)

I

INA219 (class in adafruit_ina219), [12](#)

S

set_calibration_16V_400mA() (adafruit_ina219.INA219
method), [12](#)

set_calibration_32V_1A() (adafruit_ina219.INA219
method), [12](#)

set_calibration_32V_2A() (adafruit_ina219.INA219
method), [12](#)

shunt_voltage (adafruit_ina219.INA219 attribute), [12](#)