
Adafruit MCP9808 Library Documentation

Release 1.0

Phillip Moyer

Jan 20, 2021

Contents

1	Dependencies	3
2	Installing from PyPI	5
3	Usage Notes	7
4	Contributing	9
5	Documentation	11
6	Table of Contents	13
6.1	Simple test	13
6.2	adafruit_mcp9808 - MCP9808 I2C Temperature Sensor	14
6.2.1	Implementation Notes	14
7	Indices and tables	15
	Python Module Index	17
	Index	19

The MCP9808 is an awesome, high accuracy temperature sensor that communicates over I2C. Its available on [Adafruit](#) as a [breakout](#).

CHAPTER 1

Dependencies

This driver depends on:

- [Adafruit CircuitPython](#)
- [Bus Device](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

CHAPTER 2

Installing from PyPI

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-mcp9808
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-mcp9808
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name
python3 -m venv .env
source .env/bin/activate
pip3 install adafruit-circuitpython-mcp9808
```


CHAPTER 3

Usage Notes

Getting the temperature in Celsius is easy! First, import all of the pins from the board, busio for native I2C communication and the thermometer library itself.

```
from board import *
import busio
import adafruit_mcp9808
```

Next, initialize the I2C bus in a with statement so it always gets shut down ok. Then, construct the thermometer class:

```
# Do one reading
with busio.I2C(SCL, SDA) as i2c:
    t = adafruit_mcp9808.MCP9808(i2c)

# Finally, read the temperature property and print it out
print(t.temperature)
```


CHAPTER 4

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 5

Documentation

For information on building library documentation, please check out [this guide](#).

6.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/mcp9808_simpletest.py

```
1  # SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
2  # SPDX-License-Identifier: MIT
3
4  import time
5  import board
6  import busio
7  import adafruit_mcp9808
8
9  i2c_bus = busio.I2C(board.SCL, board.SDA)
10
11 # To initialise using the default address:
12 mcp = adafruit_mcp9808.MCP9808(i2c_bus)
13
14 # To initialise using a specified address:
15 # Necessary when, for example, connecting A0 to VDD to make address=0x19
16 # mcp = adafruit_mcp9808.MCP9808(i2c_bus, address=0x19)
17
18
19 while True:
20     tempC = mcp.temperature
21     tempF = tempC * 9 / 5 + 32
22     print("Temperature: {} C {} F ".format(tempC, tempF))
23     time.sleep(2)
```

6.2 adafruit_mcp9808 - MCP9808 I2C Temperature Sensor

CircuitPython library to support MCP9808 high accuracy temperature sensor.

- Author(s): Scott Shawcroft

6.2.1 Implementation Notes

Hardware:

- Adafruit [MCP9808 High Accuracy I2C Temperature Sensor Breakout](#) (Product ID: 1782)

Software and Dependencies:

- Adafruit CircuitPython firmware (0.8.0+) for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: https://github.com/adafruit/Adafruit_CircuitPython_BusDevice

Notes:

1. Datasheet: <http://www.adafruit.com/datasheets/MCP9808.pdf>

class adafruit_mcp9808.**MCP9808** (*i2c_bus*, *address=24*)

Interface to the MCP9808 temperature sensor.

temperature

Temperature in celsius. Read-only.

CHAPTER 7

Indices and tables

- `genindex`
- `modindex`
- `search`

a

adafruit_mcp9808, [13](#)

A

`adafruit_mcp9808` (*module*), [13](#)

M

`MCP9808` (*class in `adafruit_mcp9808`*), [14](#)

T

`temperature` (*`adafruit_mcp9808.MCP9808` attribute*), [14](#)