
Adafruit MAX31855 Library Documentation

Release 1.0

Radomir Dopieralski

Oct 03, 2019

Contents

1	Dependencies	3
2	Usage Example	5
3	Contributing	7
4	Building locally	9
4.1	Sphinx documentation	9
5	Table of Contents	11
5.1	Simple test	11
5.2	adafruit_max31855	11
5.2.1	Implementation Notes	12
6	Indices and tables	13
	Python Module Index	15
	Index	17

CircuitPython driver for the [MAX31855 Thermocouple Amplifier Breakout](#)

CHAPTER 1

Dependencies

This driver depends on:

- [Adafruit CircuitPython](#)
- [Bus Device](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

CHAPTER 2

Usage Example

Of course, you must import the library to use it:

```
import adafruit_max31855
```

You also need to create an SPI interface object, and a pin object for the chip select pin. You can use any pin for the CS, but we use D5 here:

```
from busio import SPI
from digitalio import DigitalInOut
import board

spi = SPI(clock=board.SCK, MISO=board.MISO, MOSI=board.MOSI)
cs = DigitalInOut(board.D5)
```

Next, just create the sensor object:

```
sensor = adafruit_max31855.MAX31855(spi, cs)
```

And you can start making measurements:

```
print(sensor.temperature)
```

The temperature is read in degrees Celsius (°C). You have to convert it to other units yourself, if you need it.

CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Building locally

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-max31855 --
↳library_location .
```

4.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/max31855_simpletest.py

```
1 import time
2 import board
3 import busio
4 import digitalio
5 import adafruit_max31855
6
7 spi = busio.SPI(board.SCK, MOSI=board.MOSI, MISO=board.MISO)
8 cs = digitalio.DigitalInOut(board.D5)
9
10 max31855 = adafruit_max31855.MAX31855(spi, cs)
11 while True:
12     tempC = max31855.temperature
13     tempF = tempC * 9 / 5 + 32
14     print('Temperature: {} C {} F '.format(tempC, tempF))
15     time.sleep(2.0)
```

5.2 adafruit_max31855

This is a CircuitPython driver for the Maxim Integrated MAX31855 thermocouple amplifier module.

- Author(s): Radomir Dopieralski

5.2.1 Implementation Notes

Hardware:

- Adafruit [MAX31855 Thermocouple Amplifier Breakout](#) (Product ID: 269)

Software and Dependencies:

- Adafruit CircuitPython firmware for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: https://github.com/adafruit/Adafruit_CircuitPython_BusDevice

class `adafruit_max31855.MAX31855` (*spi, cs*)

Driver for the MAX31855 thermocouple amplifier.

reference_temperature

Internal reference temperature in degrees Celsius.

temperature

Thermocouple temperature in degrees Celsius.

temperature_NIST

Thermocouple temperature in degrees Celsius, computed using raw voltages and NIST approximation for Type K, see: https://srdata.nist.gov/its90/download/type_k.tab

CHAPTER 6

Indices and tables

- `genindex`
- `modindex`
- `search`

a

adafruit_max31855, [11](#)

A

`adafruit_max31855` (*module*), [11](#)

M

`MAX31855` (*class in adafruit_max31855*), [12](#)

R

`reference_temperature`
(*adafruit_max31855.MAX31855 attribute*),
[12](#)

T

`temperature` (*adafruit_max31855.MAX31855 attribute*), [12](#)
`temperature_NIST` (*adafruit_max31855.MAX31855 attribute*), [12](#)