
Adafruitsgp30 Library Documentation

Release 1.0

Ladyada

Aug 25, 2020

Contents

1	Installation and Dependencies	3
1.1	Installing from PyPI	3
2	Usage Notes	5
2.1	Reading from the Sensor	5
3	Contributing	7
4	Documentation	9
5	Table of Contents	11
5.1	Simple test	11
5.2	adafruit_sgp30	12
5.2.1	Implementation Notes	12
6	Indices and tables	15
	Python Module Index	17
	Index	19

A CircuitPython driver for the Sensirion SGP30 gas sensor with eCO2 and TVOC output. This sensor uses I2C!

Installation and Dependencies

This driver depends on:

- [Adafruit CircuitPython](#)
- [Bus Device](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

1.1 Installing from PyPI

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-sgp30
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-sgp30
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name
python3 -m venv .env
source .env/bin/activate
pip3 install adafruit-circuitpython-sgp30
```


CHAPTER 2

Usage Notes

See [the guide](#) for wiring and installation instructions.

First, import the library:

```
import busio
import adafruit_sgp30
```

Next, initialize the I2C bus object:

```
import board
i2c_bus = busio.I2C(board.SCL, board.SDA, frequency=100000)
```

Since we have the I2C bus object, we can now use it to instantiate the SGP30 object:

```
sgp30 = adafruit_sgp30.Adafruit_SGP30(i2c_bus)
```

2.1 Reading from the Sensor

To read from the sensor:

```
eCO2, TVOC = sgp30.iaq_measure()
print("eCO2 = %d ppm \t TVOC = %d ppb" % (eCO2, TVOC))
```


CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Documentation

For information on building library documentation, please check out [this guide](#).

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/sgp30_simpletest.py

```
1  """ Example for using the SGP30 with CircuitPython and the Adafruit library """
2
3  import time
4  import board
5  import busio
6  import adafruit_sgp30
7
8  i2c = busio.I2C(board.SCL, board.SDA, frequency=100000)
9
10 # Create library object on our I2C port
11 sgp30 = adafruit_sgp30.Adafruit_SGP30(i2c)
12
13 print("SGP30 serial #", [hex(i) for i in sgp30.serial])
14
15 sgp30.iaq_init()
16 sgp30.set_iaq_baseline(0x8973, 0x8AAE)
17
18 elapsed_sec = 0
19
20 while True:
21     print("eCO2 = %d ppm \t TVOC = %d ppb" % (sgp30.eCO2, sgp30.TVOC))
22     time.sleep(1)
23     elapsed_sec += 1
24     if elapsed_sec > 10:
25         elapsed_sec = 0
26         print(
27             "**** Baseline values: eCO2 = 0x%x, TVOC = 0x%x"
```

(continues on next page)

(continued from previous page)

```

28         % (sgp30.baseline_eCO2, sgp30.baseline_TVOC)
29     )

```

5.2 adafruit_sgp30

I2C driver for SGP30 Sensirion VoC sensor

- Author(s): ladyada

5.2.1 Implementation Notes

Hardware:

- Adafruit [SGP30 Air Quality Sensor Breakout - VOC and eCO2](#) (Product ID: 3709)

Software and Dependencies:

- Adafruit CircuitPython firmware for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: https://github.com/adafruit/Adafruit_CircuitPython_BusDevice

class `adafruit_sgp30.Adafruit_SGP30` (*i2c*, *address=88*)

A driver for the SGP30 gas sensor.

Ethanol

Ethanol Raw Signal in ticks

H2

H2 Raw Signal in ticks

TVOC

Total Volatile Organic Compound in parts per billion.

baseline_TVOC

Total Volatile Organic Compound baseline value

baseline_eCO2

Carbon Dioxide Equivalent baseline value

eCO2

Carbon Dioxide Equivalent in parts per million

get_iaq_baseline()

Retrieve the IAQ algorithm baseline for eCO2 and TVOC

iaq_init()

Initialize the IAQ algorithm

iaq_measure()

Measure the eCO2 and TVOC

raw_measure()

Measure H2 and Ethanol (Raw Signals)

set_iaq_baseline(eCO2, TVOC)

Set the previously recorded IAQ algorithm baseline for eCO2 and TVOC

set_iaq_humidity (*gramsPM3*)

Set the humidity in g/m3 for eCO2 and TVOC compensation algorithm

CHAPTER 6

Indices and tables

- `genindex`
- `modindex`
- `search`

a

adafruit_sgp30, [12](#)

A

Adafruit_SGP30 (*class in adafruit_sgp30*), [12](#)
adafruit_sgp30 (*module*), [12](#)

B

baseline_eCO2 (*adafruit_sgp30.Adafruit_SGP30 attribute*), [12](#)
baseline_TVOC (*adafruit_sgp30.Adafruit_SGP30 attribute*), [12](#)

E

eCO2 (*adafruit_sgp30.Adafruit_SGP30 attribute*), [12](#)
Ethanol (*adafruit_sgp30.Adafruit_SGP30 attribute*), [12](#)

G

get_iaq_baseline() (*adafruit_sgp30.Adafruit_SGP30 method*), [12](#)

H

H2 (*adafruit_sgp30.Adafruit_SGP30 attribute*), [12](#)

I

iaq_init() (*adafruit_sgp30.Adafruit_SGP30 method*), [12](#)
iaq_measure() (*adafruit_sgp30.Adafruit_SGP30 method*), [12](#)

R

raw_measure() (*adafruit_sgp30.Adafruit_SGP30 method*), [12](#)

S

set_iaq_baseline() (*adafruit_sgp30.Adafruit_SGP30 method*), [12](#)

set_iaq_humidity() (*adafruit_sgp30.Adafruit_SGP30 method*), [12](#)

T

TVOC (*adafruit_sgp30.Adafruit_SGP30 attribute*), [12](#)