

---

# **Adafruit LSM9DS0 Library Documentation**

***Release 1.0***

**Tony DiCola**

**Aug 20, 2018**



---

## Contents

---

<b>1</b>	<b>Dependencies</b>	<b>3</b>
<b>2</b>	<b>Usage Example</b>	<b>5</b>
<b>3</b>	<b>Contributing</b>	<b>7</b>
<b>4</b>	<b>Building locally</b>	<b>9</b>
4.1	Sphinx documentation . . . . .	9
<b>5</b>	<b>Table of Contents</b>	<b>11</b>
5.1	Simple test . . . . .	11
5.2	adafruit_lsm9ds0 . . . . .	12
5.2.1	Implementation Notes . . . . .	12
<b>6</b>	<b>Indices and tables</b>	<b>15</b>
	<b>Python Module Index</b>	<b>17</b>



CircuitPython module for the LSM9DS0 accelerometer, magnetometer, gyroscope.



# CHAPTER 1

---

## Dependencies

---

This driver depends on:

- [Adafruit CircuitPython](#)
- [Bus Device](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).





## CHAPTER 2

---

### Usage Example

---

See `examples/lsm9ds0_simpletest.py` for a demo of the usage.



## CHAPTER 3

---

### Contributing

---

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.



## CHAPTER 4

---

### Building locally

---

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-lsm9ds0 --
↳library_location .
```

### 4.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.



## Table of Contents

## 5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/lsm9ds0\_simpletest.py

```

1  # Simple demo of the LSM9DS0 accelerometer, magnetometer, gyroscope.
2  # Will print the acceleration, magnetometer, and gyroscope values every second.
3  import time
4
5  import board
6  import busio
7  # import digitalio # Used with SPI
8
9  import adafruit_lsm9ds0
10
11
12  # You have a couple options for wiring this sensor, either I2C (recommended)
13  # or a SPI connection. Choose _one_ option below and uncomment it:
14
15  # I2C connection:
16  i2c = busio.I2C(board.SCL, board.SDA)
17  sensor = adafruit_lsm9ds0.LSM9DS0_I2C(i2c)
18
19  # SPI connection:
20  #spi = busio.SPI(board.SCK, MOSI=board.MOSI, MISO=board.MISO)
21  #xmcs = digitalio.DigitalInOut(board.D5) # Pin connected to XMCS (accel/mag chip_
    ↳select).
22  #gcs = digitalio.DigitalInOut(board.D6) # Pin connected to GCS (gyro chip select).
23  #sensor = adafruit_lsm9ds0.LSM9DS0_SPI(spi, xmcs, gcs)
24
25  # Main loop will read the acceleration, magnetometer, gyroscope, Temperature
26  # values every second and print them out.

```

(continues on next page)

(continued from previous page)

```

27 while True:
28     # Read acceleration, magnetometer, gyroscope, temperature.
29     accel_x, accel_y, accel_z = sensor.accelerometer
30     mag_x, mag_y, mag_z = sensor.magnetometer
31     gyro_x, gyro_y, gyro_z = sensor.gyroscope
32     temp = sensor.temperature
33     # Print values.
34     print('Acceleration (m/s^2): ({0:0.3f},{1:0.3f},{2:0.3f})'.format(accel_x, accel_
↪y, accel_z))
35     print('Magnetometer (gauss): ({0:0.3f},{1:0.3f},{2:0.3f})'.format(mag_x, mag_y,
↪mag_z))
36     print('Gyroscope (degrees/sec): ({0:0.3f},{1:0.3f},{2:0.3f})'.format(gyro_x, gyro_
↪y, gyro_z))
37     print('Temperature: {0:0.3f}C'.format(temp))
38     # Delay for a second.
39     time.sleep(1.0)

```

## 5.2 adafruit\_lsm9ds0

CircuitPython module for the LSM9DS0 accelerometer, magnetometer, gyroscope. Based on the driver from: [https://github.com/adafruit/Adafruit\\_LSM9DS0](https://github.com/adafruit/Adafruit_LSM9DS0)

See examples/simpletest.py for a demo of the usage.

- Author(s): Tony DiCola

### 5.2.1 Implementation Notes

#### Hardware:

- Adafruit 9-DOF Accel/Mag/Gyro+Temp Breakout Board - LSM9DS0 (Product ID: 2021)
- FLORA 9-DOF Accelerometer/Gyroscope/Magnetometer - LSM9DS0 (Product ID: 2020)

#### Software and Dependencies:

- Adafruit CircuitPython firmware for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: [https://github.com/adafruit/Adafruit\\_CircuitPython\\_BusDevice](https://github.com/adafruit/Adafruit_CircuitPython_BusDevice)

**class** adafruit\_lsm9ds0.LSM9DS0

Driver for the LSM9DS0 accelerometer, magnetometer, gyroscope.

#### accel\_range

The accelerometer range. Must be a value of: - ACCEL\_RANGE\_2G - ACCEL\_RANGE\_4G - ACCEL\_RANGE\_6G - ACCEL\_RANGE\_8G - ACCEL\_RANGE\_16G

#### accelerometer

The accelerometer X, Y, Z axis values as a 3-tuple of m/s^2 values.

#### gyro\_scale

The gyroscope scale. Must be a value of: - GYRO\_SCALE\_245DPS - GYRO\_SCALE\_500DPS - GYRO\_SCALE\_2000DPS

#### gyroscope

The gyroscope X, Y, Z axis values as a 3-tuple of degrees/second values.



**mag\_gain**

The magnetometer gain. Must be a value of: - MAGGAIN\_2GAUSS - MAGGAIN\_4GAUSS - MAGGAIN\_8GAUSS - MAGGAIN\_12GAUSS

**magnetometer**

The magnetometer X, Y, Z axis values as a 3-tuple of gauss values.

**read\_accel\_raw()**

Read the raw accelerometer sensor values and return it as a 3-tuple of X, Y, Z axis values that are 16-bit unsigned values. If you want the acceleration in nice units you probably want to use the accelerometer property!

**read\_gyro\_raw()**

Read the raw gyroscope sensor values and return it as a 3-tuple of X, Y, Z axis values that are 16-bit unsigned values. If you want the gyroscope in nice units you probably want to use the gyroscope property!

**read\_mag\_raw()**

Read the raw magnetometer sensor values and return it as a 3-tuple of X, Y, Z axis values that are 16-bit unsigned values. If you want the magnetometer in nice units you probably want to use the magnetometer property!

**read\_temp\_raw()**

Read the raw temperature sensor value and return it as a 16-bit unsigned value. If you want the temperature in nice units you probably want to use the temperature property!

**temperature**

The temperature of the sensor in degrees Celsius.

**class** adafruit\_lsm9ds0.**LSM9DS0\_I2C**(*i2c*)

Driver for the LSM9DS0 connected over I2C.

**class** adafruit\_lsm9ds0.**LSM9DS0\_SPI**(*spi, xmcs, gcs*)

Driver for the LSM9DS0 connected over SPI.



## CHAPTER 6

---

### Indices and tables

---

- `genindex`
- `modindex`
- `search`



### a

adafruit\_lsm9ds0, [12](#)



### A

`accel_range` (adafruit\_lsm9ds0.LSM9DS0 attribute), [12](#)  
`accelerometer` (adafruit\_lsm9ds0.LSM9DS0 attribute), [12](#)  
`adafruit_lsm9ds0` (module), [12](#)

### G

`gyro_scale` (adafruit\_lsm9ds0.LSM9DS0 attribute), [12](#)  
`gyroscope` (adafruit\_lsm9ds0.LSM9DS0 attribute), [12](#)

### L

`LSM9DS0` (class in adafruit\_lsm9ds0), [12](#)  
`LSM9DS0_I2C` (class in adafruit\_lsm9ds0), [13](#)  
`LSM9DS0_SPI` (class in adafruit\_lsm9ds0), [13](#)

### M

`mag_gain` (adafruit\_lsm9ds0.LSM9DS0 attribute), [12](#)  
`magnetometer` (adafruit\_lsm9ds0.LSM9DS0 attribute),  
[13](#)

### R

`read_accel_raw()` (adafruit\_lsm9ds0.LSM9DS0 method),  
[13](#)  
`read_gyro_raw()` (adafruit\_lsm9ds0.LSM9DS0 method),  
[13](#)  
`read_mag_raw()` (adafruit\_lsm9ds0.LSM9DS0 method),  
[13](#)  
`read_temp_raw()` (adafruit\_lsm9ds0.LSM9DS0 method),  
[13](#)

### T

`temperature` (adafruit\_lsm9ds0.LSM9DS0 attribute), [13](#)