
AdafruitOneWire Library Documentation

Release 1.0

Carter Nelson

Mar 02, 2021

Contents

1	Dependencies	3
2	Usage Example	5
3	Contributing	7
4	Documentation	9
5	Table of Contents	11
5.1	Simple test	11
5.2	adafruit_owewire.bus	12
5.3	adafruit_owewire.device	13
6	Indices and tables	15
	Python Module Index	17
	Index	19

Classes for use in communicating with devices on a 1-Wire bus.

CHAPTER 1

Dependencies

This driver depends on:

- [Adafruit CircuitPython](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

CHAPTER 2

Usage Example

```
import board
from adafruit_owewire.bus import OneWireBus
ow_bus = OneWireBus(board.D2)
devices = ow_bus.scan()
for d in devices:
    print("ROM={}\tFamily=0x{:02x}".format(d.rom, d.family_code))
```


CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Documentation

For information on building library documentation, please check out [this guide](#).

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/onewire_simpletest.py

```
1  # SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
2  # SPDX-License-Identifier: MIT
3
4  import board
5  from adafruit_onewire.bus import OneWireBus
6
7  # Create the 1-Wire Bus
8  # Use whatever pin you've connected to on your board
9  ow_bus = OneWireBus(board.D2)
10
11 # Reset and check for presence pulse.
12 # This is basically - "is there anything out there?"
13 print("Resetting bus...", end="")
14 if ow_bus.reset():
15     print("OK.")
16 else:
17     raise RuntimeError("Nothing found on bus.")
18
19 # Run a scan to get all of the device ROM values
20 print("Scanning for devices...", end="")
21 devices = ow_bus.scan()
22 print("OK.")
23 print("Found {} device(s)".format(len(devices)))
24
25 # For each device found, print out some info
26 for i, d in enumerate(devices):
27     print("Device {:>3}".format(i))
```

(continues on next page)

(continued from previous page)

```
28 print("\tSerial Number = ", end="")
29 for byte in d.serial_number:
30     print("0x{:02x} ".format(byte), end="")
31 print("\n\tFamily = 0x{:02x}".format(d.family_code))
32
33 # Usage beyond this is device specific. See a CircuitPython library for a 1-Wire
34 # device for examples and how OneWireDevice is used.
```

5.2 adafruit_owewire.bus

Provide access to a 1-Wire bus.

- Author(s): Carter Nelson

class adafruit_owewire.bus.OneWireAddress (rom)

A class to represent a 1-Wire address.

crc

The 8 bit CRC.

family_code

The 8 bit family code.

rom

The unique 64 bit ROM code.

serial_number

The 48 bit serial number.

class adafruit_owewire.bus.OneWireBus (pin)

A class to represent a 1-Wire bus.

static crc8 (data)

Perform the 1-Wire CRC check on the provided data.

Parameters data (bytearray) – 8 byte array representing 64 bit ROM code

maximum_devices

The maximum number of devices the bus will scan for. Valid range is 1 to 255. It is an error to have more devices on the bus than this number. Having less is OK.

readinto (buf, *, start=0, end=None)

Read into buf from the device. The number of bytes read will be the length of buf.

If start or end is provided, then the buffer will be sliced as if buf[start:end]. This will not cause an allocation like buf[start:end] will so it saves memory.

Parameters

- buf (bytearray) – buffer to write into
- start (int) – Index to start writing at
- end (int) – Index to write up to but not include

reset (required=False)

Perform a reset and check for presence pulse.

Parameters required (bool) – require presence pulse

scan()

Scan for devices on the bus and return a list of addresses.

write(*buf*, *, *start*=0, *end*=None)

Write the bytes from *buf* to the device.

If *start* or *end* is provided, then the buffer will be sliced as if `buffer[start:end]`. This will not cause an allocation like `buffer[start:end]` will so it saves memory.

Parameters

- **buf** (*bytearray*) – buffer containing the bytes to write
- **start** (*int*) – Index to start writing from
- **end** (*int*) – Index to read up to but not include

exception `adafruit_onewire.bus.OneWireError`

A class to represent a 1-Wire exception.

5.3 `adafruit_onewire.device`

Provides access to a single device on the 1-Wire bus.

- Author(s): Carter Nelson

class `adafruit_onewire.device.OneWireDevice` (*bus*, *address*)

A class to represent a single device on the 1-Wire bus.

readinto(*buf*, *, *start*=0, *end*=None)

Read into *buf* from the device. The number of bytes read will be the length of *buf*.

If *start* or *end* is provided, then the buffer will be sliced as if `buf[start:end]`. This will not cause an allocation like `buf[start:end]` will so it saves memory.

Parameters

- **buf** (*bytearray*) – buffer to write into
- **start** (*int*) – Index to start writing at
- **end** (*int*) – Index to write up to but not include

write(*buf*, *, *start*=0, *end*=None)

Write the bytes from *buf* to the device.

If *start* or *end* is provided, then the buffer will be sliced as if `buffer[start:end]`. This will not cause an allocation like `buffer[start:end]` will so it saves memory.

Parameters

- **buf** (*bytearray*) – buffer containing the bytes to write
- **start** (*int*) – Index to start writing from
- **end** (*int*) – Index to read up to but not include

CHAPTER 6

Indices and tables

- `genindex`
- `modindex`
- `search`

Python Module Index

a

`adafruit_owewire.bus`, [12](#)

`adafruit_owewire.device`, [13](#)

A

`adafruit_owewire.bus` (module), [12](#)
`adafruit_owewire.device` (module), [13](#)

C

`crc` (`adafruit_owewire.bus.OneWireAddress` attribute), [12](#)
`crc8()` (`adafruit_owewire.bus.OneWireBus` static method), [12](#)

F

`family_code` (`adafruit_owewire.bus.OneWireAddress` attribute), [12](#)

M

`maximum_devices` (`adafruit_owewire.bus.OneWireBus` attribute), [12](#)

O

`OneWireAddress` (class in `adafruit_owewire.bus`), [12](#)
`OneWireBus` (class in `adafruit_owewire.bus`), [12](#)
`OneWireDevice` (class in `adafruit_owewire.device`), [13](#)
`OneWireError`, [13](#)

R

`readinto()` (`adafruit_owewire.bus.OneWireBus` method), [12](#)
`readinto()` (`adafruit_owewire.device.OneWireDevice` method), [13](#)
`reset()` (`adafruit_owewire.bus.OneWireBus` method), [12](#)
`rom` (`adafruit_owewire.bus.OneWireAddress` attribute), [12](#)

S

`scan()` (`adafruit_owewire.bus.OneWireBus` method), [12](#)
`serial_number` (`adafruit_owewire.bus.OneWireAddress` attribute), [12](#)

W

`write()` (`adafruit_owewire.bus.OneWireBus` method), [13](#)
`write()` (`adafruit_owewire.device.OneWireDevice` method), [13](#)