# AdafruitRegister Library Documentation

Release 1.0

**Scott Shawcroft and Tony Dicola** 

# Contents

1	Dependencies	3
2	Usage Example 2.1 Creating a driver	<b>5</b> 5
3	Contributing	9
4		<b>11</b> 11
5	5.1 Simple tests	13 13 16 16 16 16 17 18 18
6	Indices and tables	21
Рy	thon Module Index	23

This library provides a variety of data descriptor class for Adafruit CircuitPython that makes it really simple to write a device drivers for a I2C and SPI register based devices. Data descriptors act like basic attributes from the outside which makes using them really easy to use.

Contents 1

2 Contents

		CHAPTER <b>1</b>

Dependencies

### This driver depends on:

• Adafruit CircuitPython

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the Adafruit library and driver bundle.

# CHAPTER 2

Usage Example

# 2.1 Creating a driver

Creating a driver with the register library is really easy. First, import the register modules you need from the available modules:

```
from adafruit_register import i2c_bit
from adafruit_bus_device import i2c_device
```

Next, define where the bit is located in the device's memory map:

```
class HelloWorldDevice:
    """Device with two bits to control when the words 'hello' and 'world' are lit."""
   hello = i2c\_bit.RWBit(0x0, 0x0)
    """Bit to indicate if hello is lit."""
    world = i2c\_bit.RWBit(0x1, 0x0)
    """Bit to indicate if world is lit."""
```

Lastly, we need to add an i2c\_device member of type I2CDevice that manages sharing the I2C bus for us. Make sure the name is exact, otherwise the registers will not be able to find it. Also, make sure that the i2c device implements the busio. I2C interface.

```
def __init__(self, i2c, device_address=0x0):
   self.i2c_device = i2c_device.I2CDevice(i2c, device_address)
```

Thats it! Now we have a class we can use to talk to those registers:

```
import busio
from board import *
with busio.I2C(SCL, SDA) as i2c:
    device = HelloWorldDevice(i2c)
```

(continues on next page)

(continued from previous page)

```
device.hello = True
device.world = True
```

### 2.2 Adding register types

Adding a new register type is a little more complicated because you need to be careful and minimize the amount of memory the class will take. If you don't, then a driver with five registers of your type could take up five times more extra memory.

First, determine whether the new register class should go in an existing module or not. When in doubt choose a new module. The more finer grained the modules are, the fewer extra classes a driver needs to load in.

Here is the start of the RWBit class:

```
class RWBit:
    """
    Single bit register that is readable and writeable.

Values are `bool`

:param int register_address: The register address to read the bit from
:param type bit: The bit index within the byte at ``register_address``
    """

def __init__(self, register_address, bit):
    self.bit_mask = 1 << bit
    self.buffer = bytearray(2)
    self.buffer[0] = register_address</pre>
```

The first thing done is writing an RST formatted class comment that explains the functionality of the register class and any requirements of the register layout. It also documents the parameters passed into the constructor (\_\_init\_\_) which configure the register location in the device map. It does not include the device address or the i2c object because its shared on the device class instance instead. That way if you have multiple of the same device on the same bus, the register classes will be shared.

In \_\_init\_\_ we only use two member variable because each costs 8 bytes of memory plus the memory for the value. And remember this gets multiplied by the number of registers of this type in a driver! Thats why we pack both the register address and data byte into one bytearray. We could use two byte arrays of size one but each MicroPython object is 16 bytes minimum due to the garbage collector. So, by sharing a byte array we keep it to the 16 byte minimum instead of 32 bytes. Each memoryview also costs 16 bytes minimum so we avoid them too.

Another thing we could do is allocate the bytearray only when we need it. This has the advantage of taking less memory up front but the cost of allocating it every access and risking it failing. If you want to add a version of Foo that lazily allocates the underlying buffer call it FooLazy.

Ok, onward. To make a data descriptor we must implement \_\_get\_\_ and \_\_set\_\_.

```
def __get__(self, obj, objtype=None):
    with obj.i2c_device:
        obj.i2c_device.write(self.buffer, end=1, stop=False)
        obj.i2c_device.readinto(self.buffer, start=1)
    return bool(self.buffer[1] & self.bit_mask)

def __set__(self, obj, value):
    with obj.i2c_device:
        obj.i2c_device.write(self.buffer, end=1, stop=False)
```

(continues on next page)

(continued from previous page)

```
obj.i2c_device.readinto(self.buffer, start=1)
if value:
    self.buffer[1] |= self.bit_mask
else:
    self.buffer[1] &= ~self.bit_mask
obj.i2c_device.write(self.buffer)
```

As you can see, we have two places to get state from. First, self stores the register class members which locate the register within the device memory map. Second, obj is the driver class that uses the register class which must by definition provide a I2CDevice compatible object as i2c\_device. This object does two thing for us:

- 1. Waits for the bus to free, locks it as we use it and frees it after.
- 2. Saves the device address and other settings so we don't have to.

Note that we take heavy advantage of the start and end parameters to the i2c functions to slice the buffer without actually allocating anything extra. They function just like self.buffer[start:end] without the extra allocation.

Thats it! Now you can use your new register class like the example above. Just remember to keep the number of members to a minimum because the class may be used a bunch of times.

		- ≺
CHAPT	EK	J

Contributing

Contributions are welcome! Please read our Code of Conduct before contributing to help this project stay welcoming.

# CHAPTER 4

**Building locally** 

To build this library locally you'll need to install the circuitpython-build-tools package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-register -- \hookrightarrow library_location .
```

# 4.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs sphinx-build -E -W -b html . _build/html
```

This will output the documentation to docs/\_build/html. Open the index.html in your browser to view them. It will also (due to -W) error out on any warning like Travis will. This is a good way to locally verify it will pass.

# CHAPTER 5

Table of Contents

# 5.1 Simple tests

Ensure your device works with this simple test.

Listing 1: examples/rwbit.py

```
from board import SCL, SDA
   from busio import I2C
   from adafruit_bus_device.i2c_device import I2CDevice
   from adafruit_register.i2c_bit import RWBit
   DEVICE_ADDRESS = 0x68 # device address of DS3231 board
   A_DEVICE_REGISTER = 0x0E # control register on the DS3231 board
   class DeviceControl: #pylint: disable-msg=too-few-public-methods
       def __init__(self, i2c):
           self.i2c_device = i2c # self.i2c_device required by RWBit class
11
12
       flag1 = RWBit(A_DEVICE_REGISTER, 0) # bit 0 of the control register
13
       flag2 = RWBit(A_DEVICE_REGISTER, 1) # bit 1
14
       flag3 = RWBit(A_DEVICE_REGISTER, 7) # bit 7
   # The follow is for I2C communications
17
   comm_port = I2C(SCL, SDA)
18
   device = I2CDevice(comm_port, DEVICE_ADDRESS)
19
   flags = DeviceControl(device)
20
21
   # set the bits in the device
   flags.flag1 = False
  flags.flag2 = True
  flags.flag3 = False
   # display the device values for the bits
   print("flag1: {}; flag2: {}; flag3: {}".format(flags.flag1, flags.flag2, flags.flag3))
```

(continues on next page)

(continued from previous page)

```
# toggle the bits
flags.flag1 = not flags.flag1
flags.flag2 = not flags.flag2
flags.flag3 = not flags.flag3
# display the device values for the bits
print("flag1: {}; flag2: {}; flag3: {}".format(flags.flag1, flags.flag2, flags.flag3))
```

#### Listing 2: examples/rwbits.py

```
from board import SCL, SDA
   from busio import I2C
2
   from adafruit_bus_device.i2c_device import I2CDevice
   from adafruit_register.i2c_bits import RWBits
   DEVICE ADDRESS = 0x39 # device address of APDS9960 board
   A DEVICE REGISTER 1 = 0xA2 # a control register on the APDS9960 board
   A_DEVICE_REGISTER_2 = 0xA3 # another control register on the APDS9960 board
   class DeviceControl: #pylint: disable-msg=too-few-public-methods
10
       def __init__(self, i2c):
11
           self.i2c_device = i2c # self.i2c_device required by RWBit class
12
13
       setting1 = RWBits(2, A_DEVICE_REGISTER_1, 6) # 2 bits: bits 6 & 7
14
       setting2 = RWBits(2, A_DEVICE_REGISTER_2, 5) # 2 bits: bits 5 & 6
15
   # The follow is for I2C communications
   comm_port = I2C(SCL, SDA)
   device = I2CDevice(comm_port, DEVICE_ADDRESS)
19
   settings = DeviceControl(device)
20
21
   # set the bits in the device
22
   settings.setting1 = 0
23
   settings.setting2 = 3
24
   # display the device values for the bits
25
   print("setting1: {}; setting2: {}".format(settings.setting1, settings.setting2))
26
27
   # toggle the bits
28
   settings.setting1 = 3
29
   settings.setting2 = 0
   # display the device values for the bits
  print("setting1: {}; setting2: {}".format(settings.setting1, settings.setting2))
```

### Listing 3: examples/struct.py

```
from board import SCL, SDA
   from busio import I2C
2
   from adafruit_bus_device.i2c_device import I2CDevice
   from adafruit_register.i2c_struct import Struct
4
   DEVICE_ADDRESS = 0x40 # device address of PCA9685 board
6
   A_DEVICE_REGISTER = 0x06 # PWM 0 control register on the PCA9685 board
7
   class DeviceControl: #pylint: disable-msg=too-few-public-methods
9
       def __init__(self, i2c):
10
           self.i2c_device = i2c # self.i2c_device required by Struct class
11
```

(continues on next page)

(continued from previous page)

```
12
       tuple_of_numbers = Struct(A_DEVICE_REGISTER, "<HH") # 2 16-bit numbers
13
14
   # The follow is for I2C communications
15
   comm_port = I2C(SCL, SDA)
16
   device = I2CDevice(comm_port, DEVICE_ADDRESS)
17
   registers = DeviceControl(device)
18
19
   # set the bits in the device
20
   registers.tuple_of_numbers = (0, 0x00FF)
21
   # display the device values for the bits
22
   print("register 1: {}; register 2: {}".format(*registers.tuple_of_numbers))
25
   # toggle the bits
   registers.tuple_of_numbers = (0x1000, 0)
26
   # display the device values for the bits
27
  print("register 1: {}; register 2: {}".format(*registers.tuple_of_numbers))
```

#### Listing 4: examples/unarystruct.py

```
from board import SCL, SDA
   from busio import I2C
2
   from adafruit bus device.i2c device import I2CDevice
   from adafruit register.i2c struct import UnaryStruct
   DEVICE_ADDRESS = 0x74 # device address of PCA9685 board
   A_DEVICE_REGISTER_1 = 0x00 # Configuration register on the is31f13731 board
   A_DEVICE_REGISTER_2 = 0x03 # Auto Play Control Register 2 on the is31f13731 board
   class DeviceControl: #pylint: disable-msg=too-few-public-methods
10
       def __init__(self, i2c):
11
           self.i2c_device = i2c # self.i2c_device required by UnaryStruct class
12
13
       register1 = UnaryStruct(A_DEVICE_REGISTER_1, "<B") # 8-bit number</pre>
14
       register2 = UnaryStruct(A_DEVICE_REGISTER_2, "<B") # 8-bit number</pre>
15
16
   # The follow is for I2C communications
17
   comm_port = I2C(SCL, SDA)
18
   device = I2CDevice(comm_port, DEVICE_ADDRESS)
19
   registers = DeviceControl(device)
20
21
22
   # set the bits in the device
   registers.register1 = 1 << 3 | 2
23
   registers.register2 = 32
24
   # display the device values for the bits
25
   print("register 1: {}; register 2: {}".format(registers.register1, registers.
   →register2))
27
   # toggle the bits
28
   registers.register1 = 2 << 3 | 5
29
   registers.register2 = 60
30
   # display the device values for the bits
31
   print("register 1: {}; register 2: {}".format(registers.register1, registers.
   →register2))
```

5.1. Simple tests

### 5.2 Module Reference

#### 5.2.1 I2C

#### 5.2.1.1 i2c bit - Single bit registers

```
adafruit_register.i2c_bit
```

Single bit registers

• Author(s): Scott Shawcroft

class adafruit\_register.i2c\_bit.ROBit (register\_address, bit, register\_width=1)
Single bit register that is read only. Subclass of RWBit.

Values are bool

#### **Parameters**

- register\_address (int) The register address to read the bit from
- **bit** (*type*) The bit index within the byte at register\_address
- register\_width (int) The number of bytes in the register. Defaults to 1.

class adafruit\_register.i2c\_bit.RWBit (register\_address, bit, register\_width=1)
Single bit register that is readable and writeable.

Values are bool

#### **Parameters**

- $register\_address(int)$  The register address to read the bit from
- **bit** (*type*) The bit index within the byte at register\_address
- register\_width (int) The number of bytes in the register. Defaults to 1.

#### 5.2.1.2 i2c bits - Multi bit registers

```
adafruit_register.i2c_bits
```

Multi bit registers

• Author(s): Scott Shawcroft

Multibit register (less than a full byte) that is read-only. This must be within a byte register.

Values are int between 0 and  $2 ** num\_bits - 1$ .

#### **Parameters**

- num\_bits (int) The number of bits in the field.
- register\_address (int) The register address to read the bit from
- lowest\_bit (type) The lowest bits index within the byte at register\_address
- register\_width (int) The number of bytes in the register. Defaults to 1.

```
class adafruit_register.i2c_bits.RWBits(num_bits, register_address, lowest_bit, regis-
ter width=1)
```

Multibit register (less than a full byte) that is readable and writeable. This must be within a byte register.

Values are int between 0 and 2 \*\* num\_bits - 1.

#### **Parameters**

- num\_bits (int) The number of bits in the field.
- register address (int) The register address to read the bit from
- lowest\_bit (type) The lowest bits index within the byte at register\_address
- **register\_width** (*int*) The number of bytes in the register. Defaults to 1.

### 5.2.1.3 i2c\_struct - Generic structured registers based on struct

```
adafruit_register.i2c_struct
```

Generic structured registers based on struct

• Author(s): Scott Shawcroft

**class** adafruit\_register.i2c\_struct.**ROUnaryStruct** (*register\_address*, *struct\_format*)

Arbitrary single value structure register that is read-only.

Values map to the first value in the defined struct. See struct module documentation for struct format string and its possible value types.

#### **Parameters**

- register\_address (int) The register address to read the bit from
- **struct\_format** (*type*) The struct format string for this register.

```
class adafruit_register.i2c_struct.Struct(register_address, struct_format)
Arbitrary structure register that is readable and writeable.
```

Values are tuples that map to the values in the defined struct. See struct module documentation for struct format string and its possible value types.

#### Parameters

- register\_address (int) The register address to read the bit from
- **struct\_format** (*type*) The struct format string for this register.

```
class adafruit_register.i2c_struct.UnaryStruct (register_address, struct_format)
Arbitrary single value structure register that is readable and writeable.
```

Values map to the first value in the defined struct. See struct module documentation for struct format string and its possible value types.

#### **Parameters**

- $register\_address(int)$  The register address to read the bit from
- **struct format** (type) The struct format string for this register.

5.2. Module Reference 17

#### 5.2.1.4 i2c\_bcd\_datetime - Binary Coded Decimal date and time register

#### adafruit\_register.i2c\_bcd\_datetime

Binary Coded Decimal date and time register

• Author(s): Scott Shawcroft

Date and time register using binary coded decimal structure.

The byte order of the register must\* be: second, minute, hour, weekday, day (1-31), month, year (in years after 2000).

• Setting weekday\_first=False will flip the weekday/day order so that day comes first.

Values are time.struct\_time

#### **Parameters**

- register\_address (int) The register address to start the read
- weekday\_first (bool) True if weekday is in a lower register than the day of the month (1-31)
- weekday\_start (int) 0 or 1 depending on the RTC's representation of the first day of the week

#### 5.2.1.5 i2c\_bcd\_alarm - Binary Coded Decimal alarm register

```
adafruit register.i2c bcd alarm
```

Binary Coded Decimal alarm register

• Author(s): Scott Shawcroft

Alarm date and time register using binary coded decimal structure.

The byte order of the registers must\* be: [second], minute, hour, day, weekday. Each byte must also have a high enable bit where 1 is disabled and 0 is enabled.

- If weekday\_shared is True, then weekday and day share a register.
- If has\_seconds is True, then there is a seconds register.

Values are a tuple of (time.struct\_time, str) where the struct represents a date and time that would alarm. The string is the frequency:

- "secondly", once a second (only if alarm has\_seconds)
- "minutely", once a minute when seconds match (if alarm doesn't seconds then when seconds = 0)
- "hourly", once an hour when tm min and tm sec match

- "daily", once a day when tm\_hour, tm\_min and tm\_sec match
- "weekly", once a week when tm\_wday, tm\_hour, tm\_min, tm\_sec match
- "monthly", once a month when tm\_mday, tm\_hour, tm\_min, tm\_sec match

#### **Parameters**

- register\_address (int) The register address to start the read
- has\_seconds (bool) True if the alarm can happen minutely.
- weekday\_shared (bool) True if weekday and day share the same register
- weekday\_start (int) 0 or 1 depending on the RTC's representation of the first day of the week (Monday)

### 5.2.2 SPI

Coming soon!

5.2. Module Reference 19

# CHAPTER 6

# Indices and tables

- genindex
- modindex
- search

# Python Module Index

### а

```
adafruit_register.i2c_bcd_alarm, 18
adafruit_register.i2c_bcd_datetime, 18
adafruit_register.i2c_bit, 16
adafruit_register.i2c_bits, 16
adafruit_register.i2c_struct, 17
```

24 Python Module Index

# Index

### Α adafruit\_register.i2c\_bcd\_alarm (module), 18 adafruit\_register.i2c\_bcd\_datetime (module), 18 adafruit\_register.i2c\_bit (module), 16 adafruit\_register.i2c\_bits (module), 16 adafruit\_register.i2c\_struct (module), 17 В BCDA larm Time Register(class in adafruit\_register.i2c\_bcd\_alarm), 18 BCDDateTimeRegister (class in adafruit\_register.i2c\_bcd\_datetime), 18 R ROBit (class in adafruit\_register.i2c\_bit), 16 ROBits (class in adafruit\_register.i2c\_bits), 16 ROUnaryStruct (class in adafruit\_register.i2c\_struct), 17 RWBit (class in adafruit\_register.i2c\_bit), 16 RWBits (class in adafruit\_register.i2c\_bits), 16 S Struct (class in adafruit\_register.i2c\_struct), 17 U UnaryStruct (class in adafruit\_register.i2c\_struct), 17