
Adafruit IRREMOTE Library Documentation

Release 1.0

Scott Shawcroft

Jan 15, 2019

Contents

1	Dependencies	3
2	Usage Example	5
3	Contributing	7
4	Building locally	9
4.1	Sphinx documentation	9
5	Table of Contents	11
5.1	Simple test	11
5.2	adafruit_irremote	12
5.2.1	Implementation Notes	12
6	Indices and tables	15
	Python Module Index	17

CircuitPython driver for use with IR Receivers.

Examples of products to use this library with:

- [Circuit Playground Express](#)
- [IR Receiver Sensor](#)

CHAPTER 1

Dependencies

This driver depends on:

- Adafruit CircuitPython

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the Adafruit library and driver bundle.

CHAPTER 2

Usage Example

```
# Circuit Playground Express Demo Code
# Adjust the pulseio 'board.PIN' if using something else
import pulseio
import board
import adafruit_irremote
pulsein = pulseio.PulseIn(board.REMOTEIN, maxlen=120, idle_state=True)
decoder = adafruit_irremote.GenericDecode()

# size must match what you are decoding! for NEC use 4
received_code = bytearray(4)

while True:
    pulses = decoder.read_pulses(pulsein)
    print("Heard", len(pulses), "Pulses:", pulses)
    try:
        code = decoder.decode_bits(pulses, debug=False)
        print("Decoded:", code)
    except adafruit_irremote.IRNECREpeatException: # unusual short code!
        print("NEC repeat!")
    except adafruit_irremote.IRDecodeException as e:      # failed to decode
        print("Failed to decode: ", e.args)

    print("-----")
```


CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Building locally

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-irremote --
˓→library_location .
```

4.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.

CHAPTER 5

Table of Contents

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/irremote_simpletest.py

```
1 # Circuit Playground Express Demo Code
2 # Adjust the pulseio 'board.PIN' if using something else
3 import pulseio
4 import board
5 import adafruit_irremote
6 pulsein = pulseio.PulseIn(board.REMOTEIN, maxlen=120, idle_state=True)
7 decoder = adafruit_irremote.GenericDecode()
8
9 # size must match what you are decoding! for NEC use 4
10 received_code = bytearray(4)
11
12 while True:
13     pulses = decoder.read_pulses(pulsein)
14     print("Heard", len(pulses), "Pulses:", pulses)
15     try:
16         code = decoder.decode_bits(pulses, debug=False)
17         print("Decoded:", code)
18     except adafruit_irremote.IRNECRepeatException: # unusual short code!
19         print("NEC repeat!")
20     except adafruit_irremote.IRDecodeException as e:      # failed to decode
21         print("Failed to decode: ", e.args)
22
23     print("-----")
```

5.2 adafruit_irremote

Demo code for Circuit Playground Express:

```
# Circuit Playground Express Demo Code
# Adjust the pulseio 'board.PIN' if using something else
import pulseio
import board
import adafruit_irremote

pulsein = pulseio.PulseIn(board.REMOTEIN, maxlen=120, idle_state=True)
decoder = adafruit_irremote.GenericDecode()

# size must match what you are decoding! for NEC use 4
received_code = bytearray(4)

while True:
    pulses = decoder.read_pulses(pulsein)
    print("Heard", len(pulses), "Pulses:", pulses)
    try:
        code = decoder.decode_bits(pulses, debug=False)
        print("Decoded:", code)
    except adafruit_irremote.IRNCRRepeatException: # unusual short code!
        print("NEC repeat!")
    except adafruit_irremote.IRDecodeException as e:      # failed to decode
        print("Failed to decode: ", e.args)

    print("-----")
```

- Author(s): Scott Shawcroft

5.2.1 Implementation Notes

Hardware:

- CircuitPlayground Express
- IR Receiver Sensor

Software and Dependencies:

- Adafruit CircuitPython firmware for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>

```
class adafruit_irremote.GenericDecode
    Generic decoding of infrared signals

    bin_data(pulses)
        Compute bins of pulse lengths where pulses are +-25% of the average.

        Parameters pulses (list) – Input pulse lengths

    decode_bits(pulses, debug=False)
        Decode the pulses into bits.

    read_pulses(input_pulses, *, max_pulse=10000, blocking=True, pulse_window=0.1, blocking_delay=0.1)
        Read out a burst of pulses until pulses stop for a specified period (pulse_window), pruning pulses after a
        pulse longer than max_pulse.
```

Parameters

- **input_pulses** (*PulseIn*) – Object to read pulses from
- **max_pulse** (*int*) – Pulse duration to end a burst
- **blocking** (*bool*) – If True, will block until pulses found. If False, will return None if no pulses. Defaults to True for backwards compatibility
- **pulse_window** (*float*) – pulses are collected for this period of time
- **blocking_delay** (*float*) – delay between pulse checks when blocking

```
class adafruit_irremote.GenericTransmit(header, one, zero, trail)
```

Generic infrared transmit class that handles encoding.

```
transmit(pulseout, data)
```

Transmit the data using the pulseout.

Parameters

- **pulseout** (*pulseio.PulseOut*) – PulseOut to transmit on
- **data** (*bytarray*) – Data to transmit

```
exception adafruit_irremote.IRDecodeException
```

Generic decode exception

```
exception adafruit_irremote.IRNECRepeatException
```

Exception when a NEC repeat is decoded

CHAPTER 6

Indices and tables

- genindex
- modindex
- search

Python Module Index

a

adafruit_irremote, 11

Index

A

adafruit_irremote (module), [11](#)

B

bin_data() (adafruit_irremote.GenericDecode method),
[12](#)

D

decode_bits() (adafruit_irremote.GenericDecode
method), [12](#)

G

GenericDecode (class in adafruit_irremote), [12](#)
GenericTransmit (class in adafruit_irremote), [13](#)

I

IRDecodeException, [13](#)
IRNECRepeatException, [13](#)

R

read_pulses() (adafruit_irremote.GenericDecode
method), [12](#)

T

transmit() (adafruit_irremote.GenericTransmit method),
[13](#)