

---

# **Adafruit MAX31865 Library Documentation**

*Release 1.0*

**Tony DiCola**

**Aug 25, 2018**



---

## Contents

---

<b>1</b>	<b>Dependencies</b>	<b>3</b>
<b>2</b>	<b>Usage Example</b>	<b>5</b>
<b>3</b>	<b>Contributing</b>	<b>7</b>
<b>4</b>	<b>Building locally</b>	<b>9</b>
4.1	Sphinx documentation . . . . .	9
<b>5</b>	<b>Table of Contents</b>	<b>11</b>
5.1	Simple test . . . . .	11
5.2	adafruit_max31865 . . . . .	12
5.2.1	Implementation Notes . . . . .	12
<b>6</b>	<b>Indices and tables</b>	<b>15</b>
	<b>Python Module Index</b>	<b>17</b>



CircuitPython module for the MAX31865 thermocouple amplifier.



# CHAPTER 1

---

## Dependencies

---

This driver depends on:

- [Adafruit CircuitPython](#)
- [Bus Device](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).



## CHAPTER 2

---

### Usage Example

---

See `examples/max31865_simpletest.py` for a demo of the usage.



## CHAPTER 3

---

### Contributing

---

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.



## CHAPTER 4

---

### Building locally

---

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-max31865 --
↳library_location .
```

### 4.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.



## 5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/max31865\_simpletest.py

```
1 # Simple demo of the MAX31865 thermocouple amplifier.
2 # Will print the temperature every second.
3 import time
4
5 import board
6 import busio
7 import digitalio
8
9 import adafruit_max31865
10
11
12 # Initialize SPI bus and sensor.
13 spi = busio.SPI(board.SCK, MOSI=board.MOSI, MISO=board.MISO)
14 cs = digitalio.DigitalInOut(board.D5) # Chip select of the MAX31865 board.
15 sensor = adafruit_max31865.MAX31865(spi, cs)
16 # Note you can optionally provide the thermocouple RTD nominal, the reference
17 # resistance, and the number of wires for the sensor (2 the default, 3, or 4)
18 # with keyword args:
19 #sensor = adafruit_max31865.MAX31865(spi, cs, rtd_nominal=100, ref_resistor=430.0,
20 #↳wires=2)
21
22 # Main loop to print the temperature every second.
23 while True:
24     # Read temperature.
25     temp = sensor.temperature
26     # Print the value.
27     print('Temperature: {0:0.3f}C'.format(temp))
```

(continues on next page)

(continued from previous page)

```

27     # Delay for a second.
28     time.sleep(1.0)

```

## 5.2 adafruit\_max31865

CircuitPython module for the MAX31865 platinum RTD temperature sensor. See examples/simpletest.py for an example of the usage.

- Author(s): Tony DiCola

### 5.2.1 Implementation Notes

#### Hardware:

- Adafruit Universal Thermocouple Amplifier MAX31856 Breakout (Product ID: 3263)
- Adafruit PT100 RTD Temperature Sensor Amplifier - MAX31865 (Product ID: 3328)
- Adafruit PT1000 RTD Temperature Sensor Amplifier - MAX31865 (Product ID: 3648)

#### Software and Dependencies:

- Adafruit CircuitPython firmware for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: [https://github.com/adafruit/Adafruit\\_CircuitPython\\_BusDevice](https://github.com/adafruit/Adafruit_CircuitPython_BusDevice)

**class** `adafruit_max31865.MAX31865` (*spi, cs, \*, rtd\_nominal=100, ref\_resistor=430.0, wires=2*)  
 Driver for the MAX31865 thermocouple amplifier.

#### **auto\_convert**

The state of the sensor's automatic conversion mode (True/False).

#### **bias**

The state of the sensor's bias (True/False).

#### **clear\_faults** ()

Clear any fault state previously detected by the sensor.

#### **fault**

The fault state of the sensor. Use `clear_faults()` to clear the fault state. Returns a 6-tuple of boolean values which indicate if any faults are present:

- HIGHTHRESH
- LOWTHRESH
- REFINLOW
- REFINHIGH
- RTDINLOW
- OVUV

#### **read\_rtd** ()

Perform a raw reading of the thermocouple and return its 15-bit value. You'll need to manually convert this to temperature using the nominal value of the resistance-to-digital conversion and some math. If you just want temperature use the `temperature` property instead.

**resistance**

Read the resistance of the RTD and return its value in Ohms.

**temperature**

Read the temperature of the sensor and return its value in degrees Celsius.



## CHAPTER 6

---

### Indices and tables

---

- `genindex`
- `modindex`
- `search`



**a**

[adafruit\\_max31865](#), 12



## A

adafruit\_max31865 (module), [12](#)  
auto\_convert (adafruit\_max31865.MAX31865 attribute),  
[12](#)

## B

bias (adafruit\_max31865.MAX31865 attribute), [12](#)

## C

clear\_faults() (adafruit\_max31865.MAX31865 method),  
[12](#)

## F

fault (adafruit\_max31865.MAX31865 attribute), [12](#)

## M

MAX31865 (class in adafruit\_max31865), [12](#)

## R

read\_rtd() (adafruit\_max31865.MAX31865 method), [12](#)  
resistance (adafruit\_max31865.MAX31865 attribute), [12](#)

## T

temperature (adafruit\_max31865.MAX31865 attribute),  
[13](#)