
Adafruit
CIRCUITPYTHON*ADS1X15LibraryDocumentati*
Release 1.0

Carter Nelson

Feb 23, 2018

Contents

1	Dependencies	3
2	Usage Example	5
2.1	Single Ended	5
2.2	Differential	5
3	Contributing	7
4	Building locally	9
4.1	Sphinx documentation	9
5	Table of Contents	11
5.1	Simple test	11
5.2	adafruit_ads1x15	12
5.3	adafruit_ads1x15.differential	13
5.4	adafruit_ads1x15.single_ended	13
6	Indices and tables	15
	Python Module Index	17

Support for the ADS1x15 series of analog-to-digital converters. Available in 12-bit (ADS1015) and 16-bit (ADS1115) versions.

CHAPTER 1

Dependencies

This driver depends on:

- [Adafruit CircuitPython](#)
- [Bus Device](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

2.1 Single Ended

```
import board
import busio
from adafruit_ads1x15.single_ended import ADS1015

i2c = busio.I2C(board.SCL, board.SDA)
adc = ADS1015(i2c)
while True:
    # channel 0
    print(adc[0].value, adc[0].volts)
```

2.2 Differential

```
import board
import busio
from adafruit_ads1x15.differential import ADS1015

i2c = busio.I2C(board.SCL, board.SDA)
adc = ADS1015(i2c)
while True:
    # channel 0 - channel 1
    print(adc[(0,1)].value, adc[(0,1)].volts)
```


CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Building locally

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-ads1x15 --
↳library_location .
```

4.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.

5.1 Simple test

Ensure your device works with this simple test.

Listing 5.1: examples/ads1115_single_ended_simpletest.py

```

1  import time
2  import board
3  import busio
4  from adafruit_ads1x15.single_ended import ADS1115
5
6  # Create the I2C bus
7  i2c = busio.I2C(board.SCL, board.SDA)
8
9  # Create the ADC object using the I2C bus
10 adc = ADS1115(i2c)
11
12 # Print header
13 print("      CHAN 0      CHAN 1      CHAN 2      CHAN 3")
14 print("{:>5}\t{:>5}\t{:>5}\t{:>5}\t{:>5}\t{:>5}\t{:>5}\t{:>5}")
15     .format('raw', 'v', 'raw', 'v', 'raw', 'v', 'raw', 'v'))
16
17 while True:
18     # Get raw readings for each channel
19     r0 = adc[0].value
20     r1 = adc[1].value
21     r2 = adc[2].value
22     r3 = adc[3].value
23
24     # Get voltage readings for each channel
25     v0 = adc[0].volts
26     v1 = adc[1].volts
27     v2 = adc[2].volts
28     v3 = adc[3].volts

```

```

29
30     # Print results
31     print("{:>5}\t{:>5.3f}\t{:>5}\t{:>5.3f}\t{:>5}\t{:>5.3f}\t{:>5}\t{:>5.3f}"
32           .format(r0, v0, r1, v1, r2, v2, r3, v3))
33
34     # Sleep for a bit
35     time.sleep(0.5)

```

Listing 5.2: examples/ads1115-differential_simpletest.py

```

1  import time
2  import board
3  import busio
4  from adafruit_ads1x15.differential import ADS1115
5
6  # Create the I2C bus
7  i2c = busio.I2C(board.SCL, board.SDA)
8
9  # Create the ADC object using the I2C bus
10 adc = ADS1115(i2c)
11
12 # Print header
13 print("CHAN 0 - CHAN 1")
14 print("{:>5}\t{:>5}\t{:>5.3f}\t{:>5.3f}".format('raw', 'v'))
15
16 while True:
17     # Get raw reading for differential input between channel 0 and 1
18     raw = adc[(0, 1)].value
19
20     # Get voltage reading for differential input between channel 0 and 1
21     volts = adc[(0, 1)].volts
22
23     # Print results
24     print("{:>5}\t{:>5}\t{:>5.3f}\t{:>5.3f}".format(raw, volts))
25
26     # Sleep for a bit
27     time.sleep(0.5)

```

5.2 adafruit_ads1x15

CircuitPython driver for ADS1015/1115 ADCs.

- Author(s): Carter Nelson

class adafruit_ads1x15.adafruit_ads1x15.ADC_Channel(*adc, channel*)

Provides per channel access to ADC readings.

value

ADC reading in raw counts.

volts

ADC reading in volts.

class adafruit_ads1x15.adafruit_ads1x15.ADS1x15(*i2c, address=<sphinx.ext.autodoc._MockObject object>*)

Base functionality for ADS1x15 analog to digital converters.

get_last_result()

Read the last conversion result when in continuous conversion mode. Will return a signed integer value.

stop_adc()

Stop all continuous ADC conversions (either normal or difference mode).

5.3 adafruit_ads1x15.differential

Differential driver for ADS1015/1115 ADCs.

- Author(s): Carter Nelson

class adafruit_ads1x15.differential.ADS1015(*args, **kwargs)

ADS1015 12-bit differential analog to digital converter instance.

class adafruit_ads1x15.differential.ADS1115(*args, **kwargs)

ADS1115 16-bit differential analog to digital converter instance.

class adafruit_ads1x15.differential.ADS1x15_Differential(i2c, *ad-*
dress=<sphinx.ext.autodoc._MockObject
object>)

Base functionality for ADS1x15 analog to digital converters operating in differential mode.

read_adc_difference(differential, gain=1, data_rate=None)

Read the difference between two ADC channels and return the ADC value as a signed integer result. Differential must be one of: - 0 = Channel 0 minus channel 1 - 1 = Channel 0 minus channel 3 - 2 = Channel 1 minus channel 3 - 3 = Channel 2 minus channel 3

read_volts_difference(differential, gain=1, data_rate=None)

Read the difference between two ADC channels and return the voltage value as a floating point result. Differential must be one of: - 0 = Channel 0 minus channel 1 - 1 = Channel 0 minus channel 3 - 2 = Channel 1 minus channel 3 - 3 = Channel 2 minus channel 3

start_adc_difference(differential, gain=1, data_rate=None)

Start continuous ADC conversions between two ADC channels. Differential must be one of: - 0 = Channel 0 minus channel 1 - 1 = Channel 0 minus channel 3 - 2 = Channel 1 minus channel 3 - 3 = Channel 2 minus channel 3 Will return an initial conversion result, then call the get_last_result() function continuously to read the most recent conversion result. Call stop_adc() to stop conversions.

5.4 adafruit_ads1x15.single_ended

Single-ended driver for ADS1015/1115 ADCs.

- Author(s): Carter Nelson

class adafruit_ads1x15.single_ended.ADS1015(*args, **kwargs)

ADS1015 12-bit single ended analog to digital converter instance.

class adafruit_ads1x15.single_ended.ADS1115(*args, **kwargs)

ADS1115 16-bit single ended analog to digital converter instance.

class adafruit_ads1x15.single_ended.ADS1x15_SingleEnded(i2c, *ad-*
dress=<sphinx.ext.autodoc._MockObject
object>)

Base functionality for ADS1x15 analog to digital converters operating in single ended mode.

read_adc (*channel*, *gain=1*, *data_rate=None*)

Read a single ADC channel and return the ADC value as a signed integer result. Channel must be a value within 0-3.

read_volts (*channel*, *gain=1*, *data_rate=None*)

Read a single ADC channel and return the voltage value as a floating point result. Channel must be a value within 0-3.

start_adc (*channel*, *gain=1*, *data_rate=None*)

Start continuous ADC conversions on the specified channel (0-3). Will return an initial conversion result, then call the `get_last_result()` function to read the most recent conversion result. Call `stop_adc()` to stop conversions.

CHAPTER 6

Indices and tables

- `genindex`
- `modindex`
- `search`

a

`adafruit_ads1x15.adafruit_ads1x15`, [12](#)
`adafruit_ads1x15.differential`, [13](#)
`adafruit_ads1x15.single_ended`, [13](#)

A

adafruit_ads1x15.adafruit_ads1x15 (module), [12](#)
adafruit_ads1x15.differential (module), [13](#)
adafruit_ads1x15.single_ended (module), [13](#)
ADC_Channel (class in adafruit_ads1x15.adafruit_ads1x15), [12](#)
ADS1015 (class in adafruit_ads1x15.differential), [13](#)
ADS1015 (class in adafruit_ads1x15.single_ended), [13](#)
ADS1115 (class in adafruit_ads1x15.differential), [13](#)
ADS1115 (class in adafruit_ads1x15.single_ended), [13](#)
ADS1x15 (class in adafruit_ads1x15.adafruit_ads1x15), [12](#)
ADS1x15_Differential (class in adafruit_ads1x15.differential), [13](#)
ADS1x15_SingleEnded (class in adafruit_ads1x15.single_ended), [13](#)

G

get_last_result() (adafruit_ads1x15.adafruit_ads1x15.ADS1x15 method), [12](#)

R

read_adc() (adafruit_ads1x15.single_ended.ADS1x15_SingleEnded method), [13](#)
read_adc_difference() (adafruit_ads1x15.differential.ADS1x15_Differential method), [13](#)
read_volts() (adafruit_ads1x15.single_ended.ADS1x15_SingleEnded method), [14](#)
read_volts_difference() (adafruit_ads1x15.differential.ADS1x15_Differential method), [13](#)

S

start_adc() (adafruit_ads1x15.single_ended.ADS1x15_SingleEnded method), [14](#)
start_adc_difference() (adafruit_ads1x15.differential.ADS1x15_Differential method), [13](#)
stop_adc() (adafruit_ads1x15.adafruit_ads1x15.ADS1x15 method), [13](#)

V

value (adafruit_ads1x15.adafruit_ads1x15.ADC_Channel attribute), [12](#)
volts (adafruit_ads1x15.adafruit_ads1x15.ADC_Channel attribute), [12](#)