
AdafruitADXL34x Library Documentation

Release 1.0

Bryan Siepert

May 06, 2019

Contents

1	Dependencies	3
2	Usage Example	5
3	Contributing	7
4	Building locally	9
4.1	Zip release files	9
4.2	Sphinx documentation	9
5	Table of Contents	11
5.1	Simple test	11
5.2	Motion detection	11
5.3	Freefall detection	12
5.4	Tap detection	12
5.5	adafruit_adxl34x	13
5.5.1	Implementation Notes	13
6	Indices and tables	17
	Python Module Index	19

A CircuitPython driver for the ADXL34x family of accelerometers

CHAPTER 1

Dependencies

This driver depends on:

- Adafruit CircuitPython
- Bus Device

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

CHAPTER 2

Usage Example

```
import time
import board
import busio
import adafruit_adxl34x
i2c = busio.I2C(board.SCL, board.SDA)
accelerometer = adafruit_adxl34x.ADXL345(i2c)
while True:
    print("%f %f %f"%accelerometer.acceleration)
    time.sleep(1)
```


CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Building locally

4.1 Zip release files

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-adxl34x --
→library_location .
```

4.2 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.

CHAPTER 5

Table of Contents

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/adxl34x_simpletest.py

```
1 import time
2 import board
3 import busio
4 import adafruit_adxl34x
5 i2c = busio.I2C(board.SCL, board.SDA)
6 accelerometer = adafruit_adxl34x.ADXL345(i2c)
7 while True:
8     print("%f %f %f"%accelerometer.acceleration)
9     time.sleep(1)
```

5.2 Motion detection

Use the accelerometer to detect motion.

Listing 2: examples/adxl34x_motion_detection_test.py

```
1 import time
2 import board
3 import busio
4 import adafruit_adxl34x
5
6 i2c = busio.I2C(board.SCL, board.SDA)
7
8 accelerometer = adafruit_adxl34x.ADXL345(i2c)
9 accelerometer.enable_motion_detection()
```

(continues on next page)

(continued from previous page)

```

10 # alternatively you can specify the threshold when you enable motion detection for ↵
11 # more control:
12 # accelerometer.enable_motion_detection(threshold=10)
13 while True:
14     print("%f %f %f"%accelerometer.acceleration)
15
16     print("Motion detected: %s"%accelerometer.events['motion'])
17     time.sleep(0.5)

```

5.3 Freefall detection

Use the accelerometer to detect when something is dropped.

Listing 3: examples/adxl34x_freefall_detection_test.py

```

1 import time
2 import board
3 import busio
4 import adafruit_adxl34x
5
6 i2c = busio.I2C(board.SCL, board.SDA)
7
8 accelerometer = adafruit_adxl34x.ADXL345(i2c)
9 accelerometer.enable_freefall_detection()
10 # alternatively you can specify attributes when you enable freefall detection for ↵
11 # more control:
12 # accelerometer.enable_freefall_detection(threshold=10, time=25)
13 while True:
14     print("%f %f %f"%accelerometer.acceleration)
15
16     print("Dropped: %s"%accelerometer.events["freefall"])
17     time.sleep(0.5)

```

5.4 Tap detection

The accelerometer can also be configured to detect taps.

Listing 4: examples/adxl34x_tap_detection_test.py

```

1 import time
2 import board
3 import busio
4 import adafruit_adxl34x
5
6 i2c = busio.I2C(board.SCL, board.SDA)
7
8 accelerometer = adafruit_adxl34x.ADXL345(i2c)
9 accelerometer.enable_tap_detection()
10 # you can also configure the tap detection parameters when you enable tap detection:
11 # accelerometer.enable_tap_detection(tap_count=2, threshold=20, duration=50)
12 while True:

```

(continues on next page)

(continued from previous page)

```

13     print("%f %f %f"%accelerometer.acceleration)
14
15     print("Tapped: %s"%accelerometer.events['tap'])
16     time.sleep(0.5)

```

5.5 adafruit_adxl34x

A driver for the ADXL34x 3-axis accelerometer family

- Author(s): Bryan Siepert

Based on drivers by K. Townsend and Tony DiCola

5.5.1 Implementation Notes

Hardware: <https://www.adafruit.com/product/1231>

Software and Dependencies:

- Adafruit CircuitPython firmware for the supported boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: https://github.com/adafruit/Adafruit_CircuitPython_BusDevice

class adafruit_adxl34x.**ADXL345** (*i2c, address=83*)

Driver for the ADXL345 3 axis accelerometer

Parameters

- **i2c_bus** (*I2C*) – The I2C bus the ADXL345 is connected to.
- **address** – The I2C device address for the sensor. Default is 0x53.

acceleration

The x, y, z acceleration values returned in a 3-tuple in m / s ^ 2.

data_rate

The data rate of the sensor.

disable_freefall_detection()

Disable freefall detection

disable_motion_detection()

Disable motion detection

disable_tap_detection()

Disable tap detection

enable_freefall_detection(*, threshold=10, time=25)

Freefall detection parameters:

Parameters

- **threshold** (*int*) – The value that acceleration on all axes must be under to register as dropped. The scale factor is 62.5 mg/LSB.
- **time** (*int*) – The amount of time that acceleration on all axes must be less than threshold to register as dropped. The scale factor is 5 ms/LSB. Values between 100 ms and 350 ms (20 to 70) are recommended.

If you wish to set them yourself rather than using the defaults, you must use keyword arguments:

```
accelerometer.enable_freefall_detection(time=30)
```

`enable_motion_detection` (*, *threshold*=18)

The activity detection parameters.

Parameters `threshold` (*int*) – The value that acceleration on any axis must exceed to register as active. The scale factor is 62.5 mg/LSB.

If you wish to set them yourself rather than using the defaults, you must use keyword arguments:

```
accelerometer.enable_motion_detection(threshold=20)
```

`enable_tap_detection` (*, *tap_count*=1, *threshold*=20, *duration*=50, *latency*=20, *window*=255)

The tap detection parameters.

Parameters

- `tap_count` (*int*) – 1 to detect only single taps, and 2 to detect only double taps.
- `threshold` (*int*) – A threshold for the tap detection. The scale factor is 62.5 mg/LSB
The higher the value the less sensitive the detection. This changes based on the accelerometer range.
- `duration` (*int*) – This caps the duration of the impulse above threshold. Anything above duration won't register as a tap. The scale factor is 625 µs/LSB
- `latency(double tap only)` (*int*) – The length of time after the initial impulse falls below threshold to start the window looking for a second impulse. The scale factor is 1.25 ms/LSB.
- `window(double tap only)` (*int*) – The length of the window in which to look for a second tap. The scale factor is 1.25 ms/LSB

If you wish to set them yourself rather than using the defaults, you must use keyword arguments:

```
accelerometer.enable_tap_detection(duration=30, threshold=25)
```

`events`

`events` will return a dictionary with a key for each event type that has been enabled. The possible keys are:

Key	Description
<code>tap</code>	True if a tap was detected recently. Whether it's looking for a single or double tap is determined by the <code>tap</code> param of <code>enable_tap_detection</code>
<code>motion</code>	True if the sensor has seen acceleration above the threshold set with <code>enable_motion_detection</code> .
<code>freefall</code>	True if the sensor was in freefall. Parameters are set when enabled with <code>enable_freefall_detection</code>

`range`

The measurement range of the sensor.

`class adafruit_adxl34x.DataRate`

An enum-like class representing the possible data rates. Possible values are

- `DataRate.RATE_3200_HZ`
- `DataRate.RATE_1600_HZ`

- DataRate.RATE_800_HZ
- DataRate.RATE_400_HZ
- DataRate.RATE_200_HZ
- DataRate.RATE_100_HZ
- DataRate.RATE_50_HZ
- DataRate.RATE_25_HZ
- DataRate.RATE_12_5_HZ
- DataRate.RATE_6_25HZ
- DataRate.RATE_3_13_HZ
- DataRate.RATE_1_56_HZ
- DataRate.RATE_0_78_HZ
- DataRate.RATE_0_39_HZ
- DataRate.RATE_0_20_HZ
- DataRate.RATE_0_10_HZ

class adafruit_adxl34x.Range

An enum-like class representing the possible measurement ranges in +/- G.

Possible values are

- Range.RANGE_16_G
- Range.RANGE_8_G
- Range.RANGE_4_G
- Range.RANGE_2_G

CHAPTER 6

Indices and tables

- genindex
- modindex
- search

Python Module Index

a

`adafruit_adxl34x`, 13

Index

A

acceleration (*adafruit_adxl34x.ADXL345 attribute*), 13
adafruit_adxl34x (*module*), 13
ADXL345 (*class in adafruit_adxl34x*), 13

D

data_rate (*adafruit_adxl34x.ADXL345 attribute*), 13
DataRate (*class in adafruit_adxl34x*), 14
disable_freefall_detection()
 (*adafruit_adxl34x.ADXL345 method*), 13
disable_motion_detection()
 (*adafruit_adxl34x.ADXL345 method*), 13
disable_tap_detection()
 (*adafruit_adxl34x.ADXL345 method*), 13

E

enable_freefall_detection()
 (*adafruit_adxl34x.ADXL345 method*), 13
enable_motion_detection()
 (*adafruit_adxl34x.ADXL345 method*), 14
enable_tap_detection()
 (*adafruit_adxl34x.ADXL345 method*), 14
events (*adafruit_adxl34x.ADXL345 attribute*), 14

R

range (*adafruit_adxl34x.ADXL345 attribute*), 14
Range (*class in adafruit_adxl34x*), 15