
AdafruitBMP3XX Library Documentation

Release 1.0

Carter Nelson

Apr 26, 2021

Contents

1 Dependencies	3
1.1 Installing from PyPI	3
2 Usage Example	5
3 Contributing	7
4 Documentation	9
5 Table of Contents	11
5.1 Simple test	11
5.2 adafruit_bmp3xx	12
5.2.1 Implementation Notes	12
6 Indices and tables	15
Python Module Index	17
Index	19

CircuitPython driver from BMP3XX Temperature and Barometric Pressure sensor.

CHAPTER 1

Dependencies

This driver depends on:

- Adafruit CircuitPython
- Bus Device

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the Adafruit library and driver bundle.

1.1 Installing from PyPI

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-bmp3xx
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-bmp3xx
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name
python3 -m venv .env
source .env/bin/activate
pip3 install adafruit-circuitpython-bmp3xx
```


CHAPTER 2

Usage Example

See usage examples in the examples folder.

CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Documentation

For information on building library documentation, please check out [this guide](#).

CHAPTER 5

Table of Contents

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/bmp3xx_simpletest.py

```
1 # SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
2 # SPDX-License-Identifier: MIT
3
4 import time
5 import board
6 import adafruit_bmp3xx
7
8 # I2C setup
9 i2c = board.I2C()    # uses board.SCL and board.SDA
10 bmp = adafruit_bmp3xx.BMP3XX_I2C(i2c)
11
12 # SPI setup
13 # from digitalio import DigitalInOut, Direction
14 # spi = board.SPI()
15 # cs = DigitalInOut(board.D5)
16 # bmp = adafruit_bmp3xx.BMP3XX_SPI(spi, cs)
17
18 bmp.pressure_oversampling = 8
19 bmp.temperature_oversampling = 2
20
21 while True:
22     print(
23         "Pressure: {:.4f}  Temperature: {:.2f}".format(bmp.pressure, bmp.
24             temperature)
25     )
26     time.sleep(1)
```

5.2 adafruit_bmp3xx

CircuitPython driver from BMP388 Temperature and Barometric Pressure sensor.

- Author(s): Carter Nelson

5.2.1 Implementation Notes

Hardware:

- Adafruit BMP388

Software and Dependencies:

- Adafruit CircuitPython firmware for the supported boards: <https://github.com/adafruit/circuitpython/releases>

```
# * Adafruit's Bus Device library: https://github.com/adafruit/Adafruit\_CircuitPython\_BusDevice
```

```
class adafruit_bmp3xx.BMP3XX
```

Base class for BMP3XX sensor.

altitude

The altitude in meters based on the currently set sea level pressure.

filter_coefficient

The IIR filter coefficient.

pressure

The pressure in hPa.

pressure_oversampling

The pressure oversampling setting.

reset()

Perform a power on reset. All user configuration settings are overwritten with their default state.

sea_level_pressure = None

Sea level pressure in hPa.

temperature

The temperature in degrees Celsius

temperature_oversampling

The temperature oversampling setting.

```
class adafruit_bmp3xx.BMP3XX_I2C(i2c, address=119)
```

Driver for I2C connected BMP3XX.

Parameters

- **i2c** (*I2C*) – The I2C bus the BMP388 is connected to.
- **address** (*int*) – I2C device address. Defaults to 0x77. but another address can be passed in as an argument

Quickstart: Importing and using the BMP388

Here is an example of using the *BMP3XX_I2C* class. First you will need to import the libraries to use the sensor

```
import board
import adafruit_bmp3xx
```

Once this is done you can define your `board.I2C` object and define your sensor object

```
i2c = board.I2C()      # uses board.SCL and board.SDA
bmp = adafruit_bmp3xx.BMP3XX_I2C(i2c)
```

Now you have access to the temperature and pressure attributes

```
temperature = bmp.temperature
pressure = bmp.pressure
```

class adafruit_bmp3xx.**BMP3XX_SPI** (*spi, cs*)
Driver for SPI connected BMP3XX.

Parameters

- **spi** (*SPI*) – SPI device
- **cs** (*DigitalInOut*) – Chip Select

Quickstart: Importing and using the BMP388

Here is an example of using the `BMP3XX_SPI` class. First you will need to import the libraries to use the sensor

```
import board
import adafruit_bmp3xx
from digitalio import DigitalInOut, Direction
```

Once this is done you can define your `board.SPI` object and define your sensor object

```
spi = board.SPI()
cs = DigitalInOut(board.D5)
bmp = adafruit_bmp3xx.BMP3XX_SPI(spi, cs)
```

Now you have access to the temperature and pressure attributes

```
temperature = bmp.temperature
pressure = bmp.pressure
```


CHAPTER 6

Indices and tables

- genindex
- modindex
- search

Python Module Index

a

`adafruit_bmp3xx`, 11

A

`adafruit_bmp3xx (module)`, 11
`altitude (adafruit_bmp3xx.BMP3XX attribute)`, 12

B

`BMP3XX (class in adafruit_bmp3xx)`, 12
`BMP3XX_I2C (class in adafruit_bmp3xx)`, 12
`BMP3XX_SPI (class in adafruit_bmp3xx)`, 13

F

`filter_coefficient (adafruit_bmp3xx.BMP3XX attribute)`, 12

P

`pressure (adafruit_bmp3xx.BMP3XX attribute)`, 12
`pressure_oversampling (adafruit_bmp3xx.BMP3XX attribute)`, 12

R

`reset () (adafruit_bmp3xx.BMP3XX method)`, 12

S

`sea_level_pressure (adafruit_bmp3xx.BMP3XX attribute)`, 12

T

`temperature (adafruit_bmp3xx.BMP3XX attribute)`, 12
`temperature_oversampling (adafruit_bmp3xx.BMP3XX attribute)`, 12