
Adafruit HID Library Documentation

Release 1.0

Scott Shawcroft

Aug 26, 2021

Contents

1	Dependencies	3
2	Additional Layouts	5
3	Usage Example	7
4	Contributing	11
5	Documentation	13
6	Table of Contents	15
6.1	Simple test	15
6.2	Keyboard Shortcuts	16
6.3	Simple Gamepad	16
6.4	HID Joywing	18
6.5	Consumer Control Brightness	19
6.6	adafruit_hid.keyboard.Keyboard	20
6.7	adafruit_hid.keycode.Keycode	21
6.8	adafruit_hid.keyboard_layout_us.KeyboardLayoutUS	28
6.9	adafruit_hid.mouse.Mouse	28
6.10	adafruit_hid.consumer_control.ConsumerControl	30
6.11	adafruit_hid.consumer_control_code.ConsumerControlCode	31
7	Indices and tables	33
Python Module Index		35
Index		37

This driver simulates USB HID devices. Currently keyboard and mouse are implemented.

CHAPTER 1

Dependencies

This driver depends on:

- Adafruit CircuitPython

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the Adafruit library and driver bundle.

CHAPTER 2

Additional Layouts

This library has an en-US layout. Please check out and expand [the library](#) from Neradoc for additional layouts.

CHAPTER 3

Usage Example

The `Keyboard` class sends keypress reports for a USB keyboard device to the host.

The `Keycode` class defines USB HID keycodes to send using `Keyboard`.

```
import usb_hid
from adafruit_hid.keyboard import Keyboard
from adafruit_hid.keycode import Keycode

# Set up a keyboard device.
kbd = Keyboard(usb_hid.devices)

# Type lowercase 'a'. Presses the 'a' key and releases it.
kbd.send(Keycode.A)

# Type capital 'A'.
kbd.send(Keycode.SHIFT, Keycode.A)

# Type control-x.
kbd.send(Keycode.CONTROL, Keycode.X)

# You can also control press and release actions separately.
kbd.press(Keycode.CONTROL, Keycode.X)
kbd.release_all()

# Press and hold the shifted '1' key to get '!' (exclamation mark).
kbd.press(Keycode.SHIFT, Keycode.ONE)
# Release the ONE key and send another report.
kbd.release(Keycode.ONE)
# Press shifted '2' to get '@'.
kbd.press(Keycode.TWO)
# Release all keys.
kbd.release_all()
```

The `KeyboardLayoutUS` sends ASCII characters using keypresses. It assumes the host is set to accept keypresses from a US keyboard.

If the host is expecting a non-US keyboard, the character to key mapping provided by `KeyboardLayoutUS` will not always be correct. Different keypresses will be needed in some cases. For instance, to type an 'A' on a French keyboard (AZERTY instead of QWERTY), `Keycode.Q` should be pressed.

Currently this package provides only `KeyboardLayoutUS`. More `KeyboardLayout` classes could be added to handle non-US keyboards and the different input methods provided by various operating systems.

```
import usb_hid
from adafruit_hid.keyboard import Keyboard
from adafruit_hid.keyboard_layout_us import KeyboardLayoutUS

kbd = Keyboard(usb_hid.devices)
layout = KeyboardLayoutUS(kbd)

# Type 'abc' followed by Enter (a newline).
layout.write('abc\n')

# Get the keycodes needed to type a '$'.
# The method will return (Keycode.SHIFT, Keycode.FOUR).
keycodes = layout.keycodes('$')
```

The `Mouse` class simulates a three-button mouse with a scroll wheel.

```
import usb_hid
from adafruit_hid.mouse import Mouse

m = Mouse(usb_hid.devices)

# Click the left mouse button.
m.click(Mouse.LEFT_BUTTON)

# Move the mouse diagonally to the upper left.
m.move(-100, -100, 0)

# Roll the mouse wheel away from the user one unit.
# Amount scrolled depends on the host.
m.move(0, 0, -1)

# Keyword arguments may also be used. Omitted arguments default to 0.
m.move(x=-100, y=-100)
m.move(wheel=-1)

# Move the mouse while holding down the left button. (click-drag).
m.press(Mouse.LEFT_BUTTON)
m.move(x=50, y=20)
m.release_all()      # or m.release(Mouse.LEFT_BUTTON)
```

The `ConsumerControl` class emulates consumer control devices such as remote controls, or the multimedia keys on certain keyboards.

```
import usb_hid
from adafruit_hid.consumer_control import ConsumerControl
from adafruit_hid.consumer_control_code import ConsumerControlCode

cc = ConsumerControl(usb_hid.devices)

# Raise volume.
cc.send(ConsumerControlCode.VOLUME_INCREMENT)
```

(continues on next page)

(continued from previous page)

```
# Pause or resume playback.  
cc.send(ConsumerControlCode.PLAY_PAUSE)
```


CHAPTER 4

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 5

Documentation

For information on building library documentation, please check out [this guide](#).

CHAPTER 6

Table of Contents

6.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/hid_simpletest.py

```
1 # SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
2 # SPDX-License-Identifier: MIT
3
4 import time
5 import board
6 import digitalio
7 import usb_hid
8 from adafruit_hid.mouse import Mouse
9
10 mouse = Mouse(usb_hid.devices)
11
12 # define buttons. these can be any physical switches/buttons, but the values
13 # here work out-of-the-box with a CircuitPlayground Express' A and B buttons.
14 up = digitalio.DigitalInOut(board.D4)
15 up.direction = digitalio.Direction.INPUT
16 up.pull = digitalio.Pull.DOWN
17
18 down = digitalio.DigitalInOut(board.D5)
19 down.direction = digitalio.Direction.INPUT
20 down.pull = digitalio.Pull.DOWN
21
22 while True:
23     # scroll up one unit (varies with host/OS)
24     if up.value:
25         mouse.move(wheel=1)
26
27     # scroll down one unit (varies with host/OS)
```

(continues on next page)

(continued from previous page)

```
28     elif down.value:
29         mouse.move(wheel=-1)
30
31     time.sleep(0.1)
```

6.2 Keyboard Shortcuts

Send ALT+Tab for swapping windows, and CTRL+K for searching in a browser.

Listing 2: examples/hid_keyboard_shortcuts.py

```
1  # SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
2  # SPDX-License-Identifier: MIT
3
4  import time
5  import board
6  import digitalio
7  import usb_hid
8  from adafruit_hid.keyboard import Keyboard
9  from adafruit_hid.keycode import Keycode
10
11 kbd = Keyboard(usb_hid.devices)
12
13 # define buttons. these can be any physical switches/buttons, but the values
14 # here work out-of-the-box with a CircuitPlayground Express' A and B buttons.
15 swap = digitalio.DigitalInOut(board.D4)
16 swap.direction = digitalio.Direction.INPUT
17 swap.pull = digitalio.Pull.DOWN
18
19 search = digitalio.DigitalInOut(board.D5)
20 search.direction = digitalio.Direction.INPUT
21 search.pull = digitalio.Pull.DOWN
22
23 while True:
24     # press ALT+TAB to swap windows
25     if swap.value:
26         kbd.send(Keycode.ALT, Keycode.TAB)
27
28     # press CTRL+K, which in a web browser will open the search dialog
29     elif search.value:
30         kbd.send(Keycode.CONTROL, Keycode.K)
31
32     time.sleep(0.1)
```

6.3 Simple Gamepad

Send gamepad buttons and joystick to the host.

Listing 3: examples/hid_simple_gamepad.py

```
1  # SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
2  # SPDX-License-Identifier: MIT
```

(continues on next page)

(continued from previous page)

```

3  # You must add a gamepad HID device inside your boot.py file
4  # in order to use this example.
5  # See this Learn Guide for details:
6  # https://learn.adafruit.com/customizing-usb-devices-in-circuitpython/hid-devices
7  ↪#custom-hid-devices-3096614-9
8
9 import board
10 import digitalio
11 import analogio
12 import usb_hid
13
14 from hid_gamepad import Gamepad
15
16 gp = Gamepad(usb_hid.devices)
17
18 # Create some buttons. The physical buttons are connected
19 # to ground on one side and these and these pins on the other.
20 button_pins = (board.D2, board.D3, board.D4, board.D5)
21
22 # Map the buttons to button numbers on the Gamepad.
23 # gamepad_buttons[i] will send that button number when buttons[i]
24 # is pushed.
25 gamepad_buttons = (1, 2, 8, 15)
26
27 buttons = [digitalio.DigitalInOut(pin) for pin in button_pins]
28 for button in buttons:
29     button.direction = digitalio.Direction.INPUT
30     button.pull = digitalio.Pull.UP
31
32 # Connect an analog two-axis joystick to A4 and A5.
33 ax = analogio.AnalogIn(board.A4)
34 ay = analogio.AnalogIn(board.A5)
35
36 # Equivalent of Arduino's map() function.
37 def range_map(x, in_min, in_max, out_min, out_max):
38     return (x - in_min) * (out_max - out_min) // (in_max - in_min) + out_min
39
40
41 while True:
42     # Buttons are grounded when pressed (.value = False).
43     for i, button in enumerate(buttons):
44         gamepad_button_num = gamepad_buttons[i]
45         if button.value:
46             gp.release_buttons(gamepad_button_num)
47             print(" release", gamepad_button_num, end="")
48         else:
49             gp.press_buttons(gamepad_button_num)
50             print(" press", gamepad_button_num, end="")
51
52     # Convert range[0, 65535] to -127 to 127
53     gp.move_joysticks(
54         x=range_map(ax.value, 0, 65535, -127, 127),
55         y=range_map(ay.value, 0, 65535, -127, 127),
56     )
57     print(" x", ax.value, "y", ay.value)

```

6.4 HID Joywing

Use Joy FeatherWing to drive Gamepad.

Listing 4: examples/hid_joywing_gamepad.py

```
1 # SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
2 # SPDX-License-Identifier: MIT
3
4 # Use Joy FeatherWing to drive Gamepad.
5 # https://www.adafruit.com/product/3632
6 # https://learn.adafruit.com/joy-featherwing
7
8 # You must add a gamepad HID device inside your boot.py file
9 # in order to use this example.
10 # See this Learn Guide for details:
11 # https://learn.adafruit.com/customizing-usb-devices-in-circuitpython/hid-devices
12 #→#custom-hid-devices-3096614-9
13
14 import time
15
16 import board
17 import busio
18 from micropython import const
19 from adafruit_seesaw.seesaw import Seesaw
20 import usb_hid
21 from hid_gamepad import Gamepad
22
23 def range_map(value, in_min, in_max, out_min, out_max):
24     return (value - in_min) * (out_max - out_min) // (in_max - in_min) + out_min
25
26
27 BUTTON_RIGHT = const(6)
28 BUTTON_DOWN = const(7)
29 BUTTON_LEFT = const(9)
30 BUTTON_UP = const(10)
31 BUTTON_SEL = const(14)
32 button_mask = const(
33     (1 << BUTTON_RIGHT)
34     | (1 << BUTTON_DOWN)
35     | (1 << BUTTON_LEFT)
36     | (1 << BUTTON_UP)
37     | (1 << BUTTON_SEL)
38 )
39
40 i2c = busio.I2C(board.SCL, board.SDA)
41
42 ss = Seesaw(i2c)
43
44 ss.pin_mode_bulk(button_mask, ss.INPUT_PULLUP)
45
46 last_game_x = 0
47 last_game_y = 0
48
49 g = Gamepad(usb_hid.devices)
```

(continues on next page)

(continued from previous page)

```

51 while True:
52     x = ss.analog_read(2)
53     y = ss.analog_read(3)
54
55     game_x = range_map(x, 0, 1023, -127, 127)
56     game_y = range_map(y, 0, 1023, -127, 127)
57     if last_game_x != game_x or last_game_y != game_y:
58         last_game_x = game_x
59         last_game_y = game_y
60         print(game_x, game_y)
61         g.move_joysticks(x=game_x, y=game_y)
62
63     buttons = (BUTTON_RIGHT, BUTTON_DOWN, BUTTON_LEFT, BUTTON_UP, BUTTON_SEL)
64     button_state = [False] * len(buttons)
65     for i, button in enumerate(buttons):
66         buttons = ss.digital_read_bulk(button_mask)
67         if not (buttons & (1 << button) and not button_state[i]):
68             g.press_buttons(i + 1)
69             print("Press", i + 1)
70             button_state[i] = True
71         elif button_state[i]:
72             g.release_buttons(i + 1)
73             print("Release", i + 1)
74             button_state[i] = False
75
76     time.sleep(0.01)

```

6.5 Consumer Control Brightness

Send brightness up and down consumer codes to the host.

Listing 5: examples/hid_consumer_control_brightness.py

```

1 # SPDX-FileCopyrightText: 2021 Tim C for Adafruit Industries
2 # SPDX-License-Identifier: MIT
3
4 import time
5 import board
6 import digitalio
7 import usb_hid
8 from adafruit_hid.consumer_control import ConsumerControl
9 from adafruit_hid.consumer_control_code import ConsumerControlCode
10
11 cc = ConsumerControl(usb_hid.devices)
12
13 # define buttons. these can be any physical switches/buttons, but the values
14 # here work out-of-the-box with a FunHouse UP and DOWN buttons.
15 button_up = digitalio.DigitalInOut(board.BUTTON_UP)
16 button_up.switch_to_input(pull=digitalio.Pull.DOWN)
17
18 button_down = digitalio.DigitalInOut(board.BUTTON_DOWN)
19 button_down.switch_to_input(pull=digitalio.Pull.DOWN)
20
21 while True:

```

(continues on next page)

(continued from previous page)

```

22     if button_up.value:
23         print("Button up pressed!")
24         # send brightness up button press
25         cc.send(ConsumerControlCode.BRIGHTNESS_INCREMENT)
26
27     if button_down.value:
28         print("Button down pressed!")
29         # send brightness down button press
30         cc.send(ConsumerControlCode.BRIGHTNESS_DECREMENT)
31
32     time.sleep(0.1)

```

6.6 adafruit_hid.keyboard.Keyboard

- Author(s): Scott Shawcroft, Dan Halbert

class adafruit_hid.keyboard.Keyboard(*devices*)

Send HID keyboard reports.

LED_CAPS_LOCK = 2

LED Usage ID for Caps Lock

LED_COMPOSE = 8

LED Usage ID for Compose

LED_NUM_LOCK = 1

LED Usage ID for Num Lock

LED_SCROLL_LOCK = 4

LED Usage ID for Scroll Lock

led_on(*led_code*)

Returns whether an LED is on based on the led code

Examples:

```

import usb_hid
from adafruit_hid.keyboard import Keyboard
from adafruit_hid.keycode import Keycode
import time

# Initialize Keyboard
kbd = Keyboard(usb_hid.devices)

# Press and release CapsLock.
kbd.press(Keycode.CAPS_LOCK)
time.sleep(.09)
kbd.release(Keycode.CAPS_LOCK)

# Check status of the LED_CAPS_LOCK
print(kbd.led_on(Keyboard.LED_CAPS_LOCK))

```

led_status

Returns the last received report

press(*keycodes)

Send a report indicating that the given keys have been pressed.

Parameters keycodes – Press these keycodes all at once.

Raises ValueError – if more than six regular keys are pressed.

Keycodes may be modifiers or regular keys. No more than six regular keys may be pressed simultaneously.

Examples:

```
from adafruit_hid keycode import Keycode

# Press ctrl-x.
kbd.press(Keycode.LEFT_CONTROL, Keycode.X)

# Or, more conveniently, use the CONTROL alias for LEFT_CONTROL:
kbd.press(Keycode.CONTROL, Keycode.X)

# Press a, b, c keys all at once.
kbd.press(Keycode.A, Keycode.B, Keycode.C)
```

release(*keycodes)

Send a USB HID report indicating that the given keys have been released.

Parameters keycodes – Release these keycodes all at once.

If a keycode to be released was not pressed, it is ignored.

Example:

```
# release SHIFT key
kbd.release(Keycode.SHIFT)
```

release_all()

Release all pressed keys.

send(*keycodes)

Press the given keycodes and then release all pressed keys.

Parameters keycodes – keycodes to send together

6.7 adafruit_hid keycode.Keycode

- Author(s): Scott Shawcroft, Dan Halbert

class adafruit_hid keycode.Keycode

USB HID Keycode constants.

This list is modeled after the names for USB keycodes defined in https://usb.org/sites/default/files/hut1_21_0.pdf#page=83. This list does not include every single code, but does include all the keys on a regular PC or Mac keyboard.

Remember that keycodes are the names for key *positions* on a US keyboard, and may not correspond to the character that you mean to send if you want to emulate non-US keyboard. For instance, on a French keyboard (AZERTY instead of QWERTY), the keycode for ‘q’ is used to indicate an ‘a’. Likewise, ‘y’ represents ‘z’ on a German keyboard. This is historical: the idea was that the keycaps could be changed without changing the keycodes sent, so that different firmware was not needed for different variations of a keyboard.

A = 4

a and A

ALT = 226
Alias for LEFT_ALT; Alt is also known as Option (Mac)
APPLICATION = 101
Application: also known as the Menu key (Windows)
B = 5
b and B
BACKSLASH = 49
\ and
BACKSPACE = 42
Delete backward (Backspace)
C = 6
c and C
CAPS_LOCK = 57
Caps Lock
COMMA = 54
, and <
COMMAND = 227
Labeled as Command on Mac keyboards, with a clover glyph
CONTROL = 224
Alias for LEFT_CONTROL
D = 7
d and D
DELETE = 76
Delete forward
DOWN_ARROW = 81
Move the cursor down
E = 8
e and E
EIGHT = 37
8 and *
END = 77
End (often moves to end of line)
ENTER = 40
Enter (Return)
EQUALS = 46
=` and ``+
ESCAPE = 41
Escape
F = 9
f and F
F1 = 58
Function key F1

```
F10 = 67
    Function key F10

F11 = 68
    Function key F11

F12 = 69
    Function key F12

F13 = 104
    Function key F13 (Mac)

F14 = 105
    Function key F14 (Mac)

F15 = 106
    Function key F15 (Mac)

F16 = 107
    Function key F16 (Mac)

F17 = 108
    Function key F17 (Mac)

F18 = 109
    Function key F18 (Mac)

F19 = 110
    Function key F19 (Mac)

F2 = 59
    Function key F2

F20 = 111
    Function key F20

F21 = 112
    Function key F21

F22 = 113
    Function key F22

F23 = 114
    Function key F23

F24 = 115
    Function key F24

F3 = 60
    Function key F3

F4 = 61
    Function key F4

F5 = 62
    Function key F5

F6 = 63
    Function key F6

F7 = 64
    Function key F7
```

F8 = 65
Function key F8

F9 = 66
Function key F9

FIVE = 34
5 and %

FORWARD_SLASH = 56
/ and ?

FOUR = 33
4 and \$

G = 10
g and G

GRAVE_ACCENT = 53
` and ~

GUI = 227
Alias for LEFT_GUI; GUI is also known as the Windows key, Command (Mac), or Meta

H = 11
h and H

HOME = 74
Home (often moves to beginning of line)

I = 12
i and I

INSERT = 73
Insert

J = 13
j and J

K = 14
k and K

KEYPAD_ASTERISK = 85
Keypad *

KEYPAD_BACKSLASH = 100
Keypad \ and | (Non-US)

KEYPAD_EIGHT = 96
Keypad 8 and Up Arrow

KEYPAD_ENTER = 88
Keypad Enter

KEYPAD_EQUALS = 103
Keypad = (Mac)

KEYPAD_FIVE = 93
Keypad 5

KEYPAD_FORWARD_SLASH = 84
Keypad /

```
KEYPAD_FOUR = 92
    Keypad 4 and Left Arrow

KEYPAD_MINUS = 86
    Keypad - 

KEYPAD_NINE = 97
    Keypad 9 and PgUp

KEYPAD_NUMLOCK = 83
    Num Lock (Clear on Mac)

KEYPAD_ONE = 89
    Keypad 1 and End

KEYPAD_PERIOD = 99
    Keypad . and Del

KEYPAD_PLUS = 87
    Keypad + 

KEYPAD_SEVEN = 95
    Keypad 7 and Home

KEYPAD_SIX = 94
    Keypad 6 and Right Arrow

KEYPAD_THREE = 91
    Keypad 3 and PgDn

KEYPAD_TWO = 90
    Keypad 2 and Down Arrow

KEYPAD_ZERO = 98
    Keypad 0 and Ins

L = 15
    l and L

LEFT_ALT = 226
    Alt modifier left of the spacebar

LEFT_ARROW = 80
    Move the cursor left

LEFT_BRACKET = 47
    [ and {

LEFT_CONTROL = 224
    Control modifier left of the spacebar

LEFT_GUI = 227
    GUI modifier left of the spacebar

LEFT_SHIFT = 225
    Shift modifier left of the spacebar

M = 16
    m and M

MINUS = 45
    -` and ``_
```

N = 17
n and N

NINE = 38
9 and (

O = 18
o and O

ONE = 30
1 and !

OPTION = 226
Labeled as Option on some Mac keyboards

P = 19
p and P

PAGE_DOWN = 78
Go forward one page

PAGE_UP = 75
Go back one page

PAUSE = 72
Pause (Break)

PERIOD = 55
. and >

POUND = 50
and ~ (Non-US keyboard)

POWER = 102
Power (Mac)

PRINT_SCREEN = 70
Print Screen (SysRq)

Q = 20
q and Q

QUOTE = 52
' and "

R = 21
r and R

RETURN = 40
Alias for ENTER

RIGHT_ALT = 230
Alt modifier right of the spacebar

RIGHT_ARROW = 79
Move the cursor right

RIGHT_BRACKET = 48
] and }

RIGHT_CONTROL = 228
Control modifier right of the spacebar

RIGHT_GUI = 231
GUI modifier right of the spacebar

RIGHT_SHIFT = 229
Shift modifier right of the spacebar

S = 22
s and S

SCROLL_LOCK = 71
Scroll Lock

SEMICOLON = 51
; and :

SEVEN = 36
7 and &

SHIFT = 225
Alias for LEFT_SHIFT

SIX = 35
6 and ^

SPACE = 44
Alias for SPACEBAR

SPACEBAR = 44
Spacebar

T = 23
t and T

TAB = 43
Tab and Backtab

THREE = 32
3 and #

TWO = 31
2 and @

U = 24
u and U

UP_ARROW = 82
Move the cursor up

V = 25
v and V

W = 26
w and W

WINDOWS = 227
Labeled with a Windows logo on Windows keyboards

X = 27
x and X

Y = 28
y and Y

```
Z = 29
z and Z

ZERO = 39
0 and )

classmethod modifier_bit (keycode)
    Return the modifier bit to be set in an HID keycode report if this is a modifier key; otherwise return 0.
```

6.8 adafruit_hid.keyboard_layout_us.KeyboardLayoutUS

- Author(s): Dan Halbert

class adafruit_hid.keyboard_layout_us.KeyboardLayoutUS (keyboard)

Map ASCII characters to appropriate keypresses on a standard US PC keyboard.

Non-ASCII characters and most control characters will raise an exception.

keycodes (char)

Return a tuple of keycodes needed to type the given character.

Parameters **char** (*str of length one.*) – A single ASCII character in a string.

Returns tuple of Keycode keycodes.

Raises **ValueError** – if char is not ASCII or there is no keycode for it.

Examples:

```
# Returns (Keycode.TAB, )
keycodes(' ')
# Returns (Keycode.A, )
keycode('a')
# Returns (Keycode.SHIFT, Keycode.A)
keycode('A')
# Raises ValueError because it's a accented e and is not ASCII
keycode('é')
```

write (string)

Type the string by pressing and releasing keys on my keyboard.

Parameters **string** – A string of ASCII characters.

Raises **ValueError** – if any of the characters are not ASCII or have no keycode (such as some control characters).

Example:

```
# Write abc followed by Enter to the keyboard
layout.write('abc\n')
```

6.9 adafruit_hid.mouse.Mouse

- Author(s): Dan Halbert

class adafruit_hid.mouse.Mouse (devices)

Send USB HID mouse reports.

LEFT_BUTTON = 1

Left mouse button.

MIDDLE_BUTTON = 4

Middle mouse button.

RIGHT_BUTTON = 2

Right mouse button.

click(buttons)

Press and release the given mouse buttons.

Parameters buttons – a bitwise-or'd combination of LEFT_BUTTON, MIDDLE_BUTTON, and RIGHT_BUTTON.

Examples:

```
# Click the left button.
m.click(Mouse.LEFT_BUTTON)

# Double-click the left button.
m.click(Mouse.LEFT_BUTTON)
m.click(Mouse.LEFT_BUTTON)
```

move(x=0, y=0, wheel=0)

Move the mouse and turn the wheel as directed.

Parameters

- **x** – Move the mouse along the x axis. Negative is to the left, positive is to the right.
- **y** – Move the mouse along the y axis. Negative is upwards on the display, positive is downwards.
- **wheel** – Rotate the wheel this amount. Negative is toward the user, positive is away from the user. The scrolling effect depends on the host.

Examples:

```
# Move 100 to the left. Do not move up and down. Do not roll the scroll wheel.
m.move(-100, 0, 0)
# Same, with keyword arguments.
m.move(x=-100)

# Move diagonally to the upper right.
m.move(50, 20)
# Same.
m.move(x=50, y=-20)

# Roll the mouse wheel away from the user.
m.move(wheel=1)
```

press(buttons)

Press the given mouse buttons.

Parameters buttons – a bitwise-or'd combination of LEFT_BUTTON, MIDDLE_BUTTON, and RIGHT_BUTTON.

Examples:

```
# Press the left button.  
m.press(Mouse.LEFT_BUTTON)  
  
# Press the left and right buttons simultaneously.  
m.press(Mouse.LEFT_BUTTON | Mouse.RIGHT_BUTTON)
```

release(buttons)

Release the given mouse buttons.

Parameters **buttons** – a bitwise-or'd combination of LEFT_BUTTON, MIDDLE_BUTTON, and RIGHT_BUTTON.

release_all()

Release all the mouse buttons.

6.10 `adafruit_hid.consumer_control.ConsumerControl`

- Author(s): Dan Halbert

class adafruit_hid.consumer_control.ConsumerControl(devices)

Send ConsumerControl code reports, used by multimedia keyboards, remote controls, etc.

press(consumer_code)

Send a report to indicate that the given key has been pressed. Only one consumer control action can be pressed at a time, so any one that was previously pressed will be released.

Parameters **consumer_code** – a 16-bit consumer control code.

Examples:

```
from adafruit_hid.consumer_control_code import ConsumerControlCode  
  
# Raise volume for 0.5 seconds  
consumer_control.press(ConsumerControlCode.VOLUME_INCREMENT)  
time.sleep(0.5)  
consumer_control.release()
```

release()

Send a report indicating that the consumer control key has been released. Only one consumer control key can be pressed at a time.

Examples:

```
from adafruit_hid.consumer_control_code import ConsumerControlCode  
  
# Raise volume for 0.5 seconds  
consumer_control.press(ConsumerControlCode.VOLUME_INCREMENT)  
time.sleep(0.5)  
consumer_control.release()
```

send(consumer_code)

Send a report to do the specified consumer control action, and then stop the action (so it will not repeat).

Parameters **consumer_code** – a 16-bit consumer control code.

Examples:

```
from adafruit_hid.consumer_control_code import ConsumerControlCode

# Raise volume.
consumer_control.send(ConsumerControlCode.VOLUME_INCREMENT)

# Advance to next track (song).
consumer_control.send(ConsumerControlCode.SCAN_NEXT_TRACK)
```

6.11 `adafruit_hid.consumer_control_code.ConsumerControlCode`

- Author(s): Dan Halbert

`class adafruit_hid.consumer_control_code.ConsumerControlCode`
USB HID Consumer Control Device constants.

This list includes a few common consumer control codes from https://www.usb.org/sites/default/files/hut1_21_0.pdf#page=118.

BRIGHTNESS_DECREMENT = 112

Decrease Brightness

BRIGHTNESS_INCREMENT = 111

Increase Brightness

EJECT = 184

Eject

FAST_FORWARD = 179

Fast Forward

MUTE = 226

Mute

PLAY_PAUSE = 205

Play/Pause toggle

RECORD = 178

Record

REWIND = 180

Rewind

SCAN_NEXT_TRACK = 181

Skip to next track

SCAN_PREVIOUS_TRACK = 182

Go back to previous track

STOP = 183

Stop

VOLUME_DECREMENT = 234

Decrease volume

VOLUME_INCREMENT = 233

Increase volume

CHAPTER 7

Indices and tables

- genindex
- modindex
- search

Python Module Index

a

adafruit_hid.consumer_control, 30
adafruit_hid.consumer_control_code, 31
adafruit_hid.keyboard, 20
adafruit_hid.keyboard_layout_us, 28
adafruit_hid.keycode, 21
adafruit_hid.mouse, 28

Index

A

A (*adafruit_hid keycode.Keycode attribute*), 21
adafruit_hid.consumer_control (*module*), 30
adafruit_hid.consumer_control_code (*module*), 31
adafruit_hid.keyboard (*module*), 20
adafruit_hid.keyboard_layout_us (*module*), 28
adafruit_hid.keyCode (*module*), 21
adafruit_hid.mouse (*module*), 28
ALT (*adafruit_hid.KeyCode.Keycode attribute*), 21
APPLICATION (*adafruit_hid.KeyCode.Keycode attribute*), 22

B

B (*adafruit_hid.KeyCode.Keycode attribute*), 22
BACKSLASH (*adafruit_hid.KeyCode.Keycode attribute*), 22
BACKSPACE (*adafruit_hid.KeyCode.Keycode attribute*), 22
BRIGHTNESS_DECREMENT
 (*adafruit_hid.consumer_control_code.ConsumerControlCode.Keycode attribute*), 31
BRIGHTNESS_INCREMENT
 (*adafruit_hid.consumer_control_code.ConsumerControlCode.Keycode attribute*), 31

C

C (*adafruit_hid.KeyCode.Keycode attribute*), 22
CAPS_LOCK (*adafruit_hid.KeyCode.Keycode attribute*), 22
click () (*adafruit_hid.mouse.Mouse method*), 29
COMMA (*adafruit_hid.KeyCode.Keycode attribute*), 22
COMMAND (*adafruit_hid.KeyCode.Keycode attribute*), 22
ConsumerControl
 (class in
 adafruit_hid.consumer_control), 30
ConsumerControlCode
 (class in
 adafruit_hid.consumer_control_code), 31
CONTROL (*adafruit_hid.KeyCode.Keycode attribute*), 22

D

D (*adafruit_hid.KeyCode.Keycode attribute*), 22
DELETE (*adafruit_hid.KeyCode.Keycode attribute*), 22
DOWN_ARROW (*adafruit_hid.KeyCode.Keycode attribute*), 22

E

E (*adafruit_hid.KeyCode.Keycode attribute*), 22
EIGHT (*adafruit_hid.KeyCode.Keycode attribute*), 22
EJECT (*adafruit_hid.consumer_control_code.ConsumerControlCode attribute*), 31
END (*adafruit_hid.KeyCode.Keycode attribute*), 22
ENTER (*adafruit_hid.KeyCode.Keycode attribute*), 22
EQUALS (*adafruit_hid.KeyCode.Keycode attribute*), 22
ESCAPE (*adafruit_hid.KeyCode.Keycode attribute*), 22

F

F (*adafruit_hid.KeyCode.Keycode attribute*), 22
F1 (*adafruit_hid.KeyCode.Keycode attribute*), 22
F10 (*adafruit_hid.KeyCode.Keycode attribute*), 22
F11 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F12 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F13 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F14 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F15 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F16 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F17 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F18 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F19 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F2 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F20 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F21 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F22 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F23 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F24 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F3 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F4 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F5 (*adafruit_hid.KeyCode.Keycode attribute*), 23
F6 (*adafruit_hid.KeyCode.Keycode attribute*), 23

F7 (*adafruit_hid keycode.Keycode attribute*), 23

F8 (*adafruit_hid keycode.Keycode attribute*), 23

F9 (*adafruit_hid keycode.Keycode attribute*), 24

FAST_FORWARD (*adafruit_hid.consumer_control_code.ConsumerControlCode attribute*), 31

FIVE (*adafruit_hid keycode.Keycode attribute*), 24

FORWARD_SLASH (*adafruit_hid keycode.Keycode attribute*), 24

FOUR (*adafruit_hid keycode.Keycode attribute*), 24

G

G (*adafruit_hid keycode.Keycode attribute*), 24

GRAVE_ACCENT (*adafruit_hid keycode.Keycode attribute*), 24

GUI (*adafruit_hid keycode.Keycode attribute*), 24

H

H (*adafruit_hid keycode.Keycode attribute*), 24

HOME (*adafruit_hid keycode.Keycode attribute*), 24

I

I (*adafruit_hid keycode.Keycode attribute*), 24

INSERT (*adafruit_hid keycode.Keycode attribute*), 24

J

J (*adafruit_hid keycode.Keycode attribute*), 24

K

K (*adafruit_hid keycode.Keycode attribute*), 24

Keyboard (*class in adafruit_hid.keyboard*), 20

KeyboardLayoutUS (*class in adafruit_hid.keyboard_layout_us*), 28

Keycode (*class in adafruit_hid keycode*), 21

keycodes () (*adafruit_hid.keyboard_layout_us.Keyboard method*), 28

KEYPAD_ASTERISK (*adafruit_hid keycode.Keycode attribute*), 24

KEYPAD_BACKSLASH (*adafruit_hid keycode.Keycode attribute*), 24

KEYPAD_EIGHT (*adafruit_hid keycode.Keycode attribute*), 24

KEYPAD_ENTER (*adafruit_hid keycode.Keycode attribute*), 24

KEYPAD_EQUALS (*adafruit_hid keycode.Keycode attribute*), 24

KEYPAD_FIVE (*adafruit_hid keycode.Keycode attribute*), 24

KEYPAD_FORWARD_SLASH (*adafruit_hid keycode.Keycode attribute*), 24

KEYPAD_FOUR (*adafruit_hid keycode.Keycode attribute*), 24

KEYPAD_MINUS (*adafruit_hid keycode.Keycode attribute*), 25

KEYPAD_NINE (*adafruit_hid keycode.Keycode attribute*), 25

KEYPAD_NUMLOCK (*adafruit_hid keycode.Keycode attribute*), 25

KEYPAD_ONE (*adafruit_hid keycode.Keycode attribute*), 25

KEYPAD_PERIOD (*adafruit_hid keycode.Keycode attribute*), 25

KEYPAD_PLUS (*adafruit_hid keycode.Keycode attribute*), 25

KEYPAD_SEVEN (*adafruit_hid keycode.Keycode attribute*), 25

KEYPAD_SIX (*adafruit_hid keycode.Keycode attribute*), 25

KEYPAD_THREE (*adafruit_hid keycode.Keycode attribute*), 25

KEYPAD_TWO (*adafruit_hid keycode.Keycode attribute*), 25

KEYPAD_ZERO (*adafruit_hid keycode.Keycode attribute*), 25

L

L (*adafruit_hid keycode.Keycode attribute*), 25

LED_CAPS_LOCK (*adafruit_hid.keyboard.Keyboard attribute*), 20

LED_COMPOSE (*adafruit_hid.keyboard.Keyboard attribute*), 20

LED_NUM_LOCK (*adafruit_hid.keyboard.Keyboard attribute*), 20

led_on () (*adafruit_hid.keyboard.Keyboard method*), 20

LED_SCROLL_LOCK (*adafruit_hid.keyboard.Keyboard attribute*), 20

LayoutUSStatus (*adafruit_hid.keyboard.Keyboard attribute*), 20

LEFT_ALT (*adafruit_hid keycode.Keycode attribute*), 25

LEFT_ARROW (*adafruit_hid keycode.Keycode attribute*), 25

LEFT_BRACKET (*adafruit_hid keycode.Keycode attribute*), 25

LEFT_BUTTON (*adafruit_hid.mouse.Mouse attribute*), 28

LEFT_CONTROL (*adafruit_hid keycode.Keycode attribute*), 25

LEFT_GUI (*adafruit_hid keycode.Keycode attribute*), 25

LEFT_SHIFT (*adafruit_hid keycode.Keycode attribute*), 25

M

M (*adafruit_hid keycode.Keycode attribute*), 25

MIDDLE_BUTTON (*adafruit_hid.mouse.Mouse attribute*), 29

MINUS (*adafruit_hid keycode.Keycode attribute*), 25

modifier_bit() (*adafruit_hid keycode.Keycode class method*), 28
 Mouse (*class in adafruit_hid.mouse*), 28
 move () (*adafruit_hid.mouse.Mouse method*), 29
 MUTE (*adafruit_hid.consumer_control_code.ConsumerControlCode attribute*), 31

N

N (*adafruit_hid keycode.Keycode attribute*), 25
 NINE (*adafruit_hid keycode.Keycode attribute*), 26

O

O (*adafruit_hid keycode.Keycode attribute*), 26
 ONE (*adafruit_hid keycode.Keycode attribute*), 26
 OPTION (*adafruit_hid keycode.Keycode attribute*), 26

P

P (*adafruit_hid keycode.Keycode attribute*), 26
 PAGE_DOWN (*adafruit_hid keycode.Keycode attribute*), 26
 PAGE_UP (*adafruit_hid keycode.Keycode attribute*), 26
 PAUSE (*adafruit_hid keycode.Keycode attribute*), 26
 PERIOD (*adafruit_hid keycode.Keycode attribute*), 26
 PLAY_PAUSE (*adafruit_hid consumer_control_code.ConsumerControlCode attribute*), 31
 POUND (*adafruit_hid keycode.Keycode attribute*), 26
 POWER (*adafruit_hid keycode.Keycode attribute*), 26
 press () (*adafruit_hid consumer_control.ConsumerControl method*), 30
 press () (*adafruit_hid keyboard.Keyboard method*), 20
 press () (*adafruit_hid mouse.Mouse method*), 29
 PRINT_SCREEN (*adafruit_hid keycode.Keycode attribute*), 26

Q

Q (*adafruit_hid keycode.Keycode attribute*), 26
 QUOTE (*adafruit_hid keycode.Keycode attribute*), 26

R

R (*adafruit_hid keycode.Keycode attribute*), 26
 RECORD (*adafruit_hid consumer_control_code.ConsumerControlCode attribute*), 31
 release () (*adafruit_hid consumer_control.ConsumerControl method*), 30
 release () (*adafruit_hid keyboard.Keyboard method*), 21
 release () (*adafruit_hid mouse.Mouse method*), 30
 release_all () (*adafruit_hid keyboard.Keyboard method*), 21
 release_all () (*adafruit_hid mouse.Mouse method*), 30
 RETURN (*adafruit_hid keycode.Keycode attribute*), 26
 REWIND (*adafruit_hid consumer_control_code.ConsumerControlCode attribute*), 31

RIGHT_ALT (*adafruit_hid keycode.Keycode attribute*), 26
 RIGHT_ARROW (*adafruit_hid keycode.Keycode attribute*), 26
 RIGHT_BRACKET (*adafruit_hid keycode.Keycode attribute*), 26
 RIGHT_BUTTON (*adafruit_hid mouse.Mouse attribute*), 29

RIGHT_CONTROL (*adafruit_hid keycode.Keycode attribute*), 26
 RIGHT_GUI (*adafruit_hid keycode.Keycode attribute*), 26
 RIGHT_SHIFT (*adafruit_hid keycode.Keycode attribute*), 27

S

S (*adafruit_hid keycode.Keycode attribute*), 27
 SCAN_NEXT_TRACK (*adafruit_hid consumer_control_code.ConsumerControlCode attribute*), 31
 SCAN_PREVIOUS_TRACK (*adafruit_hid consumer_control_code.ConsumerControlCode attribute*), 31
 SCROLL_LOCK (*adafruit_hid keycode.Keycode attribute*), 27
 SEMICOLON (*adafruit_hid keycode.Keycode attribute*), 27
 send () (*adafruit_hid consumer_control.ConsumerControl method*), 30
 send () (*adafruit_hid keyboard.Keyboard method*), 21
 SEVEN (*adafruit_hid keycode.Keycode attribute*), 27
 SHIFT (*adafruit_hid keycode.Keycode attribute*), 27
 SIX (*adafruit_hid keycode.Keycode attribute*), 27
 SPACE (*adafruit_hid keycode.Keycode attribute*), 27
 SPACEBAR (*adafruit_hid keycode.Keycode attribute*), 27
 STOP (*adafruit_hid consumer_control_code.ConsumerControlCode attribute*), 31

T

T (*adafruit_hid keycode.Keycode attribute*), 27
 TAB (*adafruit_hid keycode.Keycode attribute*), 27
 THREE (*adafruit_hid keycode.Keycode attribute*), 27
 TWO (*adafruit_hid keycode.Keycode attribute*), 27

U

U (*adafruit_hid keycode.Keycode attribute*), 27
 UP_ARROW (*adafruit_hid keycode.Keycode attribute*), 27

V

V (*adafruit_hid keycode.Keycode attribute*), 27
 VOLUME_DECREMENT (*adafruit_hid consumer_control_code.ConsumerControlCode attribute*), 31
 VOLUME_INCREMENT (*adafruit_hid consumer_control_code.ConsumerControlCode attribute*), 31

W

W (*adafruit_hid keycode.Keycode attribute*), [27](#)
WINDOWS (*adafruit_hid keycode.Keycode attribute*), [27](#)
write() (*adafruit_hid keyboard_layout_us.KeyboardLayoutUS method*), [28](#)

X

X (*adafruit_hid keycode.Keycode attribute*), [27](#)

Y

Y (*adafruit_hid keycode.Keycode attribute*), [27](#)

Z

Z (*adafruit_hid keycode.Keycode attribute*), [27](#)
ZERO (*adafruit_hid keycode.Keycode attribute*), [28](#)