AdafruitPN532 Library Documentation

Release 1.0

ladyada

Contents

1	Dependencies 1.1 Installing from PyPI	3
2	Usage Example	5
3	Contributing	7
4	Documentation	9
5	Table of Contents 5.1 Simple test 5.2 adafruit_pn532 5.2.1 Implementation Notes 5.3 adafruit_pn532.i2c 5.4 adafruit_pn532.spi 5.5 adafruit_pn532.uart	12 12 14 14
6	Indices and tables	15
Рy	ython Module Index	17
In	ndex .	19

CircuitPython driver for the PN532 NFC/RFID Breakout and PN532 NFC/RFID Shield

Contents 1

2 Contents

CHAPTER 1

Dependencies

This driver depends on:

- Adafruit CircuitPython
- Bus Device

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the Adafruit library and driver bundle.

1.1 Installing from PyPI

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally from PyPI. To install for current user:

```
pip3 install adafruit-circuitpython-pn532
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-pn532
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name python3 -m venv .env source .env/bin/activate pip3 install adafruit-circuitpython-pn532
```

_				
CH.	AP.	TF	R	_

Usage Example

Check examples/pn532_simpletest.py for usage example

CHAPTER 3

Contributing

Contributions are welcome! Please read our Code of Conduct before contributing to help this project stay welcoming.

\mathbb{C}^{I}	НΑ	РΊ	ΓF	R	4
O1	\Box		ᆫ	11	

Documentation

For information on building library documentation, please check out this guide.

CHAPTER 5

Table of Contents

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/pn532_simpletest.py

```
# SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
   # SPDX-License-Identifier: MIT
   This example shows connecting to the PN532 with I2C (requires clock
   stretching support), SPI, or UART. SPI is best, it uses the most pins but
   is the most reliable and universally supported.
   After initialization, try waving various 13.56MHz RFID cards over it!
   import board
11
   import busio
12
   from digitalio import DigitalInOut
13
14
   # NOTE: pick the import that matches the interface being used
16
17
   from adafruit pn532.i2c import PN532_I2C
18
19
   # from adafruit_pn532.spi import PN532_SPI
20
   # from adafruit_pn532.uart import PN532_UART
21
   # I2C connection:
   i2c = busio.I2C(board.SCL, board.SDA)
24
25
   # Non-hardware
26
   # pn532 = PN532_I2C(i2c, debug=False)
```

(continues on next page)

(continued from previous page)

```
28
   # With I2C, we recommend connecting RSTPD_N (reset) to a digital pin for manual
29
   # harware reset
30
   reset_pin = DigitalInOut(board.D6)
   # On Raspberry Pi, you must also connect a pin to P32 "H_Request" for hardware
32
   # wakeup! this means we don't need to do the I2C clock-stretch thing
33
   req_pin = DigitalInOut(board.D12)
34
   pn532 = PN532_I2C(i2c, debug=False, reset=reset_pin, req=req_pin)
35
   # SPI connection:
   # spi = busio.SPI(board.SCK, board.MOSI, board.MISO)
   # cs_pin = DigitalInOut(board.D5)
   # pn532 = PN532_SPI(spi, cs_pin, debug=False)
41
   # UART connection
42
   # uart = busio.UART(board.TX, board.RX, baudrate=115200, timeout=100)
43
   # pn532 = PN532_UART(uart, debug=False)
44
   ic, ver, rev, support = pn532.firmware_version
46
   print("Found PN532 with firmware version: {0}.{1}".format(ver, rev))
47
48
   # Configure PN532 to communicate with MiFare cards
49
   pn532.SAM_configuration()
50
51
   print("Waiting for RFID/NFC card...")
   while True:
       # Check if a card is available to read
54
       uid = pn532.read_passive_target(timeout=0.5)
55
       print(".", end="")
56
       # Try again if no card is available.
57
       if uid is None:
58
59
           continue
       print("Found card with UID:", [hex(i) for i in uid])
```

5.2 adafruit_pn532

This module will let you communicate with a PN532 RFID/NFC shield or breakout using I2C, SPI or UART.

Author(s): Original Raspberry Pi code by Tony DiCola, CircuitPython by ladyada

5.2.1 Implementation Notes

Hardware:

- Adafruit PN532 Breakout
- · Adafruit PN532 Shield

Software and Dependencies:

- Adafruit CircuitPython firmware for the supported boards: https://github.com/adafruit/circuitpython/releases
- Adafruit's Bus Device library: https://github.com/adafruit/Adafruit_CircuitPython_BusDevice

```
exception adafruit_pn532.adafruit_pn532.BusyError Base class for exceptions in this module.
```

class adafruit_pn532.adafruit_pn532.PN532 (*, debug=False, irq=None, reset=None)

PN532 driver base, must be extended for I2C/SPI/UART interfacing

SAM_configuration()

Configure the PN532 to read MiFare cards.

call_function(command, response_length=0, params=[], timeout=1)

Send specified command to the PN532 and expect up to response_length bytes back in a response. Note that less than the expected bytes might be returned! Params can optionally specify an array of bytes to send as parameters to the function call. Will wait up to timeout seconds for a response and return a bytearray of response bytes, or None if no response is available within the timeout.

firmware_version

Call PN532 GetFirmwareVersion function and return a tuple with the IC, Ver, Rev, and Support values.

get_passive_target (timeout=1)

Will wait up to timeout seconds and return None if no card is found, otherwise a bytearray with the UID of the found card is returned. <code>listen_for_passive_target</code> must have been called first in order to put the PN532 into a listening mode.

It can be useful to use this when using the IRQ pin. Use the IRQ pin to detect when a card is present and then call this function to read the card's UID. This reduces the amount of time spend checking for a card.

Send command to PN532 to begin listening for a Mifare card. This returns True if the command was received successfully. Note, this does not also return the UID of a card! <code>get_passive_target</code> must be called to read the UID when a card is found. If just looking to see if a card is currently present use <code>read_passive_target</code> instead.

mifare_classic_authenticate_block (uid, block_number, key_number, key)

Authenticate specified block number for a MiFare classic card. Uid should be a byte array with the UID of the card, block number should be the block to authenticate, key number should be the key type (like MIFARE_CMD_AUTH_A or MIFARE_CMD_AUTH_B), and key should be a byte array with the key data. Returns True if the block was authenticated, or False if not authenticated.

mifare classic read block(block number)

Read a block of data from the card. Block number should be the block to read. If the block is successfully read a bytearray of length 16 with data starting at the specified block will be returned. If the block is not read then None will be returned.

mifare_classic_write_block(block_number, data)

Write a block of data to the card. Block number should be the block to write and data should be a byte array of length 16 with the data to write. If the data is successfully written then True is returned, otherwise False is returned.

ntag2xx_read_block (block_number)

Read a block of data from the card. Block number should be the block to read. If the block is successfully read a bytearray of length 16 with data starting at the specified block will be returned. If the block is not read then None will be returned.

ntag2xx_write_block (block_number, data)

Write a block of data to the card. Block number should be the block to write and data should be a byte array of length 4 with the data to write. If the data is successfully written then True is returned, otherwise False is returned.

power_down()

Put the PN532 into a low power state. If the reset pin is connected a hard power down is performed, if not, a soft power down is performed instead. Returns True if the PN532 was powered down successfully or False if not.

```
process_response (command, response_length=0, timeout=1)
```

Process the response from the PN532 and expect up to response_length bytes back in a response. Note that less than the expected bytes might be returned! Will wait up to timeout seconds for a response and return a bytearray of response bytes, or None if no response is available within the timeout.

read_passive_target (card_baud=<sphinx.ext.autodoc.importer._MockObject object>, timeout=1)

Wait for a MiFare card to be available and return its UID when found. Will wait up to timeout seconds and return None if no card is found, otherwise a bytearray with the UID of the found card is returned.

reset()

Perform a hardware reset toggle and then wake up the PN532

```
send_command (command, params=[], timeout=1)
```

Send specified command to the PN532 and wait for an acknowledgment. Will wait up to timeout seconds for the acknowledgment and return True. If no acknowledgment is received, False is returned.

5.3 adafruit_pn532.i2c

This module will let you communicate with a PN532 RFID/NFC shield or breakout using I2C.

 Author(s): Original Raspberry Pi code by Tony DiCola, CircuitPython by ladyada, refactor by Carter Nelson

class adafruit_pn532.i2c.**PN532_I2C**(*i2c*, *, *irq=None*, *reset=None*, *req=None*, *debug=False*)

Driver for the PN532 connected over I2C.

5.4 adafruit_pn532.spi

This module will let you communicate with a PN532 RFID/NFC shield or breakout using SPI.

• Author(s): Original Raspberry Pi code by Tony DiCola, CircuitPython by ladyada, refactor by Carter Nelson

```
class adafruit_pn532.spi.PN532_SPI(spi, cs_pin, *, irq=None, reset=None, debug=False)
```

Driver for the PN532 connected over SPI. Pass in a hardware or bitbang SPI device & chip select digitalInOut pin. Optional IRQ pin (not used), reset pin and debugging output.

```
adafruit_pn532.spi.reverse_bit (num)
```

Turn an LSB byte to an MSB byte, and vice versa. Used for SPI as it is LSB for the PN532, but 99% of SPI implementations are MSB only!

5.5 adafruit_pn532.uart

This module will let you communicate with a PN532 RFID/NFC shield or breakout using UART.

 Author(s): Original Raspberry Pi code by Tony DiCola, CircuitPython by ladyada, refactor by Carter Nelson

```
class adafruit_pn532.uart.PN532_UART(uart, *, reset=None, debug=False)
    Driver for the PN532 connected over Serial UART
```

CHAPTER 6

Indices and tables

- genindex
- modindex
- search

16

Python Module Index

а

```
adafruit_pn532.adafruit_pn532,12
adafruit_pn532.i2c,14
adafruit_pn532.spi,14
adafruit_pn532.uart,14
```

18 Python Module Index

Index

A	N
adafruit_pn532.adafruit_pn532 (module), 12 adafruit_pn532.i2c (module), 14 adafruit_pn532.spi (module), 14 adafruit_pn532.uart (module), 14	ntag2xx_read_block() (adafruit_pn532.adafruit_pn532.PN532 method), 13 ntag2xx_write_block()
В	(adafruit_pn532.adafruit_pn532.PN532 method), 13
BusyError, 12	Р
C call_function() (adafruit_pn532.adafruit_pn532.P. method), 13 F	PN532_SPI (class in adafruit_pn532.spi), 14 PN532_UART (class in adafruit_pn532.uart), 14 power_down() (adafruit_pn532.adafruit_pn532.PN532
firmware_version(adafruit_pn532.adafruit_pn532 attribute), 13	PN532 method), 13 process_response() (adafruit_pn532.adafruit_pn532.PN532 method), 13
<pre>get_passive_target() (adafruit_pn532.adafruit_pn532.PN532 method), 13 L listen_for_passive_target() (adafruit_pn532.adafruit_pn532.PN532 method), 13</pre>	R read_passive_target() (adafruit_pn532.adafruit_pn532.PN532 method), 14 reset() (adafruit_pn532.adafruit_pn532.PN532 method), 14 reverse_bit() (in module adafruit_pn532.spi), 14
M	S
mifare_classic_authenticate_block()	SAM_configuration() (adafruit_pn532.adafruit_pn532.PN532 method), 13 send_command() (adafruit_pn532.adafruit_pn532.PN532 method), 14