

---

# **Adafruit RTTTL Library Documentation**

***Release 1.0***

**Scott Shawcroft**

**Apr 06, 2018**



---

## Contents

---

|          |                                |           |
|----------|--------------------------------|-----------|
| <b>1</b> | <b>Dependencies</b>            | <b>3</b>  |
| <b>2</b> | <b>Usage Example</b>           | <b>5</b>  |
| <b>3</b> | <b>Contributing</b>            | <b>7</b>  |
| <b>4</b> | <b>Building locally</b>        | <b>9</b>  |
| 4.1      | Sphinx documentation . . . . . | 9         |
| <b>5</b> | <b>Table of Contents</b>       | <b>11</b> |
| 5.1      | Simple test . . . . .          | 11        |
| 5.2      | adafruit_rtttl . . . . .       | 12        |
| <b>6</b> | <b>Indices and tables</b>      | <b>13</b> |
|          | <b>Python Module Index</b>     | <b>15</b> |



This plays [RTTTL](#) melodies.



# CHAPTER 1

---

## Dependencies

---

This driver depends on:

- [Adafruit CircuitPython](#)
- [Adafruit CircuitPython Waveform](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).





## CHAPTER 2

---

### Usage Example

---

This plays Frosty the Snowman:

```
import board
import adafruit_rtttl

adafruit_rtttl.play(board.A0, "Snowman:d=8,o=5,b=200:2g,4e.,f,4g,2c6,b,c6,4d6,4c6,4b,
↪a,2g.,b,c6,4d6,4c6,4b,a,a,g,4c6,4e.,g,a,4g,4f,4e,4d,2c.,4c,4a,4a,4c6,4c6,4b,4a,4g,
↪4e,4f,4a,4g,4f,2e.,4e,4d,4d,4g,4g,4b,4b,4d6,d6,b,4d6,4c6,4b,4a,4g,4p,2g")
```



## CHAPTER 3

---

### Contributing

---

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.



## CHAPTER 4

---

### Building locally

---

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-rtttl --library_
↪location .
```

### 4.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.



## 5.1 Simple test

Ensure your device works with this simple test.

Listing 5.1: examples/rtttl\_simpletest.py

```
1  # The MIT License (MIT)
2  #
3  # Copyright (c) 2017 Scott Shawcroft for Adafruit Industries
4  #
5  # Permission is hereby granted, free of charge, to any person obtaining a copy
6  # of this software and associated documentation files (the "Software"), to deal
7  # in the Software without restriction, including without limitation the rights
8  # to use, copy, modify, merge, publish, distribute, sublicense, and/or sell
9  # copies of the Software, and to permit persons to whom the Software is
10 # furnished to do so, subject to the following conditions:
11 #
12 # The above copyright notice and this permission notice shall be included in
13 # all copies or substantial portions of the Software.
14 #
15 # THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR
16 # IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY,
17 # FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE
18 # AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER
19 # LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM,
20 # OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN
21 # THE SOFTWARE.
22
23 # This is tested on the CircuitPlayground Express
24
25 import adafruit_rtttl
26 import digitalio
27 import board
28
```

```

29 enable = digitalio.DigitalInOut(board.SPEAKER_ENABLE)
30 enable.switch_to_output(value=True)
31
32 adafruit_rtttl.play(board.SPEAKER, "itchy:d=8,o=6,b=160:c,a5,4p,c,a,4p,c,a5,c,a5," + \
33     "c,a,4p,p,c,d,e,p,e,f,g,4p,d,c,4d,f,4a#,4a,2c7")
34 adafruit_rtttl.play(board.SPEAKER, "Phantom:d=4,o=5,b=140:c,f,c,d#.,8c#,2c#,a#4," + \
35     "d#,8a#4,2c,c,f,c,d#.,8c#,2c#,a#4,d#.,8a#4,2c,p,c,f,g#,c.6,8a#,2a#,a#,d#.6,8a#," + \
36     "2c6,p,c6,2f.6,8d#6,8c#6,8c6,8a#,8g#,8g,8f,2e,c#,c#.,8c,2c")

```

## 5.2 adafruit\_rtttl

Play notes to a digitalio pin using ring tone text transfer language (rtttl).

- Author(s): Scott Shawcroft

`adafruit_rtttl.play` (*pin, rtttl, octave=None, duration=None, tempo=None*)

Play notes to a digitalio pin using ring tone text transfer language (rtttl). :param ~digitalio.DigitalInOut pin: the speaker pin :param rtttl: string containing rtttl :param int octave: represents octave number (default 6 starts at middle c) :param int duration: length of notes (default 4 quarter note) :param int tempo: how fast (default 63 beats per minute)



## CHAPTER 6

---

### Indices and tables

---

- `genindex`
- `modindex`
- `search`



**a**

adafruit\_rtttl, [12](#)



## A

`adafruit_rtttl` (module), [12](#)

## P

`play()` (in module `adafruit_rtttl`), [12](#)