
AdafruitTFmini Library Documentation

Release 1.0

ladyada

Jan 17, 2020

Contents

1	Dependencies	3
1.1	Installing from PyPI	3
2	Usage Example	5
3	Contributing	7
4	Documentation	9
5	Table of Contents	11
5.1	Simple test	11
5.2	adafruit_tfmini	12
5.2.1	Implementation Notes	12
6	Indices and tables	13
	Python Module Index	15
	Index	17

A CircuitPython/Python library for Benewake's TF mini distance sensor

CHAPTER 1

Dependencies

This driver depends on:

- [Adafruit CircuitPython](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

1.1 Installing from PyPI

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-tfmini
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-tfmini
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name
python3 -m venv .env
source .env/bin/activate
pip3 install adafruit-circuitpython-tfmini
```


CHAPTER 2

Usage Example

```
import time
import board # comment this out if using pyserial
import busio # comment this out if using pyserial
import adafruit_tfmmini

# Use hardware uart
uart = busio.UART(board.TX, board.RX)

# Or, you can use pyserial on any computer
#import serial
#uart = serial.Serial("/dev/ttyS2", timeout=1)

# Simplest use, connect with the uart bus object
tfmini = adafruit_tfmmini.TFmini(uart)

# You can put in 'short' or 'long' distance mode
tfmini.mode = adafruit_tfmmini.MODE_SHORT
print("Now in mode", tfmini.mode)

while True:
    print("Distance: %d cm (strength %d, mode %x)" %
          (tfmini.distance, tfmini.strength, tfmini.mode))
    time.sleep(0.1)
```


CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Documentation

For information on building library documentation, please check out [this guide](#).

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/tfmini_simpletest.py

```
1 import time
2 import board # comment this out if using pyserial
3 import busio # comment this out if using pyserial
4 import adafruit_tfmini
5
6 # Use hardware uart
7 uart = busio.UART(board.TX, board.RX)
8
9 # Or, you can use pyserial on any computer
10 #import serial
11 #uart = serial.Serial("/dev/ttyS2", timeout=1)
12
13 # Simplest use, connect with the uart bus object
14 tfmini = adafruit_tfmini.TFmini(uart)
15
16 # You can put in 'short' or 'long' distance mode
17 tfmini.mode = adafruit_tfmini.MODE_SHORT
18 print("Now in mode", tfmini.mode)
19
20 while True:
21     print("Distance: %d cm (strength %d, mode %x)" %
22           (tfmini.distance, tfmini.strength, tfmini.mode))
23     time.sleep(0.1)
```

5.2 adafruit_tfmini

A CircuitPython/Python library for Benewake's TF mini distance sensor

- Author(s): ladyada

5.2.1 Implementation Notes

Hardware:

Software and Dependencies:

- Adafruit CircuitPython firmware for the supported boards: <https://github.com/adafruit/circuitpython/releases>

class `adafruit_tfmini.TFmini` (*uart*, *, *timeout=1*)

TF mini communication module, use with just RX or TX+RX for advanced command & control. :param *uart*: the pyserial or busio.uart compatible uart device :param *timeout*: how long we'll wait for valid data or response, in seconds. Default is 1

distance

The most recent distance measurement in centimeters

mode

The measurement mode can be MODE_SHORT (2) or MODE_LONG (7)

strength

The signal validity, higher value means better measurement

CHAPTER 6

Indices and tables

- `genindex`
- `modindex`
- `search`

a

`adafruit_tfmini`, [11](#)

A

`adafruit_tfmmini` (*module*), [11](#)

D

`distance` (*adafruit_tfmmini.TFmini attribute*), [12](#)

M

`mode` (*adafruit_tfmmini.TFmini attribute*), [12](#)

S

`strength` (*adafruit_tfmmini.TFmini attribute*), [12](#)

T

`TFmini` (*class in adafruit_tfmmini*), [12](#)