

---

# **Adafruit VL53L0X Library Documentation**

***Release 1.0***

**Tony DiCola**

**Aug 13, 2018**



---

## Contents

---

<b>1</b>	<b>Dependencies</b>	<b>3</b>
<b>2</b>	<b>Usage Example</b>	<b>5</b>
<b>3</b>	<b>Contributing</b>	<b>7</b>
<b>4</b>	<b>Building locally</b>	<b>9</b>
4.1	Sphinx documentation . . . . .	9
<b>5</b>	<b>Table of Contents</b>	<b>11</b>
5.1	Simple test . . . . .	11
5.2	adafruit_vl53l0x . . . . .	12
5.2.1	Implementation Notes . . . . .	12
<b>6</b>	<b>Indices and tables</b>	<b>13</b>
	<b>Python Module Index</b>	<b>15</b>



CircuitPython driver for the VL53L0X distance sensor.



# CHAPTER 1

---

## Dependencies

---

This driver depends on:

- Adafruit CircuitPython
- Bus Device

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).



## CHAPTER 2

---

### Usage Example

---

See usage in the examples/vl53l0x\_simpletest.py file.



# CHAPTER 3

---

## Contributing

---

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.



# CHAPTER 4

---

## Building locally

---

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-v15310x --
˓→library_location .
```

## 4.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.



# CHAPTER 5

---

## Table of Contents

---

### 5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/vl53l0x\_simpletest.py

```
1 # Simple demo of the VL53L0X distance sensor.
2 # Will print the sensed range/distance every second.
3 import time
4
5 import board
6 import busio
7
8 import adafruit_vl53l0x
9
10 # Initialize I2C bus and sensor.
11 i2c = busio.I2C(board.SCL, board.SDA)
12 vl53 = adafruit_vl53l0x.VL53L0X(i2c)
13
14 # Optionally adjust the measurement timing budget to change speed and accuracy.
15 # See the example here for more details:
16 # https://github.com/pololu/vl53l0x-arduino/blob/master/examples/Single/Single.ino
17 # For example a higher speed but less accurate timing budget of 20ms:
18 #vl53.measurement_timing_budget = 20000
19 # Or a slower but more accurate timing budget of 200ms:
20 #vl53.measurement_timing_budget = 200000
21 # The default timing budget is 33ms, a good compromise of speed and accuracy.
22
23 # Main loop will read the range and print it every second.
24 while True:
25     print('Range: {0}mm'.format(vl53.range))
26     time.sleep(1.0)
```

## 5.2 adafruit\_vl53l0x

CircuitPython driver for the VL53L0X distance sensor. This code is adapted from the pololu driver here: <https://github.com/pololu/vl53l0x-arduino>

See usage in the examples/vl53l0x\_simpletest.py file.

- Author(s): Tony DiCola

### 5.2.1 Implementation Notes

#### Hardware:

- Adafruit VL53L0X Time of Flight Distance Sensor - ~30 to 1000mm (Product ID: 3317)

#### Software and Dependencies:

- Adafruit CircuitPython firmware for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: [https://github.com/adafruit/Adafruit\\_CircuitPython\\_BusDevice](https://github.com/adafruit/Adafruit_CircuitPython_BusDevice)

```
class adafruit_vl53l0x.VL53L0X(i2c, address=41, io_timeout_s=0)
```

Driver for the VL53L0X distance sensor.

```
measurement_timing_budget
```

The measurement timing budget in microseconds.

```
range
```

Perform a single reading of the range for an object in front of the sensor and return the distance in millimeters.

```
signal_rate_limit
```

The signal rate limit in mega counts per second.

# CHAPTER 6

---

## Indices and tables

---

- genindex
- modindex
- search



---

## Python Module Index

---

**a**

adafruit\_vl53l0x, 11



---

## Index

---

### A

`adafruit_vl53l0x` (module), 11

### M

`measurement_timing_budget`  
(`adafruit_vl53l0x.VL53L0X` attribute), 12

### R

`range` (`adafruit_vl53l0x.VL53L0X` attribute), 12

### S

`signal_rate_limit` (`adafruit_vl53l0x.VL53L0X` attribute),  
12

### V

`VL53L0X` (class in `adafruit_vl53l0x`), 12