

---

# **Adafruit MCP9808 Library Documentation**

***Release 1.0***

**Phiilip Moyer**

**Aug 25, 2018**



---

## Contents

---

|          |   |           |
|----------|---|-----------|
| <b>1</b> | <b>Dependencies</b>   | <b>3</b>  |
| <b>2</b> | <b>Usage Notes</b>  | <b>5</b>  |
| <b>3</b> | <b>Contributing</b>   | <b>7</b>  |
| <b>4</b> | <b>Building locally</b>                                     | <b>9</b>  |
| 4.1      | Sphinx documentation . . . . .                              | 9         |
| <b>5</b> | <b>Table of Contents</b>                                    | <b>11</b> |
| 5.1      | Simple test . . . . .                                       | 11        |
| 5.2      | adafruit_mcp9808 - MCP9808 I2C Temperature Sensor . . . . . | 11        |
| 5.2.1    | Implementation Notes . . . . .                              | 11        |
| <b>6</b> | <b>Indices and tables</b>                                   | <b>13</b> |
|          | <b>Python Module Index</b>                                  | <b>15</b> |



The MCP9808 is an awesome, high accuracy temperature sensor that communicates over I2C. Its available on Adafruit as a breakout.



# CHAPTER 1

---

## Dependencies

---

This driver depends on:

- Adafruit CircuitPython
- Bus Device

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).



# CHAPTER 2

---

## Usage Notes

---

Getting the temperature in Celsius is easy! First, import all of the pins from the board, busio for native I2C communication and the thermometer library itself.

```
from board import *
import busio
import adafruit_mcp9808
```

Next, initialize the I2C bus in a with statement so it always gets shut down ok. Then, construct the thermometer class:

```
# Do one reading
with busio.I2C(SCL, SDA) as i2c:
    t = adafruit_mcp9808.MCP9808(i2c)

    # Finally, read the temperature property and print it out
    print(t.temperature)
```



# CHAPTER 3

---

## Contributing

---

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.



# CHAPTER 4

---

## Building locally

---

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-mcp9808 --
˓→library_location .
```

## 4.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.



# CHAPTER 5

---

## Table of Contents

---

### 5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/mcp9808\_simpletest.py

```
1 import time
2 import board
3 import busio
4 import adafruit_mcp9808
5
6 # This example shows how to get the temperature from a MCP9808 board
7 i2c_bus = busio.I2C(board.SCL, board.SDA)
8 mcp = adafruit_mcp9808.MCP9808(i2c_bus)
9
10 while True:
11     tempC = mcp.temperature
12     tempF = tempC * 9 / 5 + 32
13     print('Temperature: {} C {} F'.format(tempC, tempF))
14     time.sleep(2)
```

### 5.2 adafruit\_mcp9808 - MCP9808 I2C Temperature Sensor

CircuitPython library to support MCP9808 high accuracy temperature sensor.

- Author(s): Scott Shawcroft

#### 5.2.1 Implementation Notes

**Hardware:**

- Adafruit MCP9808 High Accuracy I2C Temperature Sensor Breakout (Product ID: 1782)

### Software and Dependencies:

- Adafruit CircuitPython firmware (0.8.0+) for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: [https://github.com/adafruit/Adafruit\\_CircuitPython\\_BusDevice](https://github.com/adafruit/Adafruit_CircuitPython_BusDevice)

### Notes:

1. Datasheet: <http://www.adafruit.com/datasheets/MCP9808.pdf>

```
class adafruit_mcp9808.MCP9808(i2c_bus, address=24)
    Interface to the MCP9808 temperature sensor.
```

#### temperature

Temperature in celsius. Read-only.

# CHAPTER 6

---

## Indices and tables

---

- genindex
- modindex
- search



---

## Python Module Index

---

**a**

adafruit\_mcp9808, 11



---

## Index

---

### A

`adafruit_mcp9808` (module), [11](#)

### M

`MCP9808` (class in `adafruit_mcp9808`), [12](#)

### T

`temperature` (`adafruit_mcp9808.MCP9808` attribute), [12](#)