

---

# **AdafruitBMP3XX Library Documentation**

***Release 1.0***

**Carter Nelson**

**Jul 09, 2020**



---

## Contents

---

<b>1 Dependencies</b>	<b>3</b>
1.1 Installing from PyPI . . . . .	3
<b>2 Usage Example</b>	<b>5</b>
<b>3 Contributing</b>	<b>7</b>
<b>4 Documentation</b>	<b>9</b>
<b>5 Table of Contents</b>	<b>11</b>
5.1 Simple test . . . . .	11
5.2 adafruit_bmp3xx . . . . .	12
5.2.1 Implementation Notes . . . . .	12
<b>6 Indices and tables</b>	<b>13</b>
<b>Python Module Index</b>	<b>15</b>
<b>Index</b>	<b>17</b>



CircuitPython driver from BMP3XX Temperature and Barometric Pressure sensor.



# CHAPTER 1

---

## Dependencies

---

This driver depends on:

- Adafruit CircuitPython
- Bus Device

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the Adafruit library and driver bundle.

### 1.1 Installing from PyPI

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-bmp3xx
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-bmp3xx
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name
python3 -m venv .env
source .env/bin/activate
pip3 install adafruit-circuitpython-bmp3xx
```



# CHAPTER 2

---

## Usage Example

---

See usage examples in the examples folder.



# CHAPTER 3

---

## Contributing

---

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.



# CHAPTER 4

---

## Documentation

---

For information on building library documentation, please check out [this guide](#).



# CHAPTER 5

---

## Table of Contents

---

### 5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/bmp3xx\_simpletest.py

```
1 import time
2 import board
3 import busio
4 import adafruit_bmp3xx
5
6 # I2C setup
7 i2c = busio.I2C(board.SCL, board.SDA)
8 bmp = adafruit_bmp3xx.BMP3XX_I2C(i2c)
9
10 # SPI setup
11 # from digitalio import DigitalInOut, Direction
12 # spi = busio.SPI(board.SCK, board.MOSI, board.MISO)
13 # cs = DigitalInOut(board.D5)
14 # bmp = adafruit_bmp3xx.BMP3XX_SPI(spi, cs)
15
16 bmp.pressure_oversampling = 8
17 bmp.temperature_oversampling = 2
18
19 while True:
20     print(
21         "Pressure: {:.1f} Temperature: {:.2f}" .format(bmp.pressure, bmp.
22             temperature)
23     )
24     time.sleep(1)
```

## 5.2 adafruit\_bmp3xx

CircuitPython driver from BMP3XX Temperature and Barometric Pressure sensor.

- Author(s): Carter Nelson

### 5.2.1 Implementation Notes

#### Hardware:

- Adafruit BMP388

#### Software and Dependencies:

- Adafruit CircuitPython firmware for the supported boards: <https://github.com/adafruit/circuitpython/releases>

```
# * Adafruit's Bus Device library: https://github.com/adafruit/Adafruit\_CircuitPython\_BusDevice
```

```
class adafruit_bmp3xx.BMP3XX
```

Base class for BMP3XX sensor.

```
altitude
```

The altitude in meters based on the currently set sea level pressure.

```
filter_coefficient
```

The IIR filter coefficient.

```
pressure
```

The pressure in hPa.

```
pressure_oversampling
```

The pressure oversampling setting.

```
reset()
```

Perform a power on reset. All user configuration settings are overwritten with their default state.

```
sea_level_pressure = None
```

Sea level pressure in hPa.

```
temperature
```

The temperature in deg C.

```
temperature_oversampling
```

The temperature oversampling setting.

```
class adafruit_bmp3xx.BMP3XX_I2C(i2c, address=119)
```

Driver for I2C connected BMP3XX. Default address is 0x77 but another address can be passed in as an argument

```
class adafruit_bmp3xx.BMP3XX_SPI(spi, cs)
```

Driver for SPI connected BMP3XX.

# CHAPTER 6

---

## Indices and tables

---

- genindex
- modindex
- search



---

## Python Module Index

---

### a

`adafruit_bmp3xx`, 11



### A

`adafruit_bmp3xx (module)`, 11  
`altitude (adafruit_bmp3xx.BMP3XX attribute)`, 12

### B

`BMP3XX (class in adafruit_bmp3xx)`, 12  
`BMP3XX_I2C (class in adafruit_bmp3xx)`, 12  
`BMP3XX_SPI (class in adafruit_bmp3xx)`, 12

### F

`filter_coefficient (adafruit_bmp3xx.BMP3XX attribute)`, 12

### P

`pressure (adafruit_bmp3xx.BMP3XX attribute)`, 12  
`pressure_oversampling (adafruit_bmp3xx.BMP3XX attribute)`, 12

### R

`reset () (adafruit_bmp3xx.BMP3XX method)`, 12

### S

`sea_level_pressure (adafruit_bmp3xx.BMP3XX attribute)`, 12

### T

`temperature (adafruit_bmp3xx.BMP3XX attribute)`, 12  
`temperature_oversampling (adafruit_bmp3xx.BMP3XX attribute)`, 12