
Adafruit HID Library Documentation

Release 1.0

Scott Shawcroft

Aug 09, 2018

Contents

1	Dependencies	3
2	Usage Example	5
3	Contributing	9
4	Building locally	11
4.1	Sphinx documentation	11
5	Table of Contents	13
5.1	Simple test	13
5.2	adafruit_hid.keyboard.Keyboard	14
5.3	adafruit_hid.keycode.Keycode	15
5.4	adafruit_hid.keyboard_layout_us.KeyboardLayoutUS	21
5.5	adafruit_hid.mouse.Mouse	22
5.6	adafruit_hid.consumer_control.ConsumerControl	23
5.7	adafruit_hid.consumer_control_code.ConsumerControlCode	24
5.8	adafruit_hid.gamepad.Gamepad	24
6	Indices and tables	27
	Python Module Index	29

This driver simulates USB HID devices. Currently keyboard and mouse are implemented.

CHAPTER 1

Dependencies

This driver depends on:

- [Adafruit CircuitPython](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

CHAPTER 2

Usage Example

The Keyboard class sends keypress reports for a USB keyboard device to the host.

The Keycode class defines USB HID keycodes to send using Keyboard.

```
from adafruit_hid.keyboard import Keyboard
from adafruit_hid.keycode import Keycode

# Set up a keyboard device.
kbd = Keyboard()

# Type lowercase 'a'. Presses the 'a' key and releases it.
kbd.send(Keycode.A)

# Type capital 'A'.
kbd.send(Keycode.SHIFT, Keycode.A)

# Type control-x.
kbd.send(Keycode.CONTROL, Keycode.X)

# You can also control press and release actions separately.
kbd.press(Keycode.CONTROL, Keycode.X)
kbd.release_all()

# Press and hold the shifted '1' key to get '!' (exclamation mark).
kbd.press(Keycode.SHIFT, Keycode.ONE)
# Release the ONE key and send another report.
kbd.release(Keycode.ONE)
# Press shifted '2' to get '@'.
kbd.press(Keycode.TWO)
# Release all keys.
kbd.release_all()
```

The KeyboardLayoutUS sends ASCII characters using keypresses. It assumes the host is set to accept keypresses from a US keyboard.

If the host is expecting a non-US keyboard, the character to key mapping provided by KeyboardLayoutUS will

not always be correct. Different keypresses will be needed in some cases. For instance, to type an 'A' on a French keyboard (AZERTY instead of QWERTY), `Keycode.Q` should be pressed.

Currently this package provides only `KeyboardLayoutUS`. More `KeyboardLayout` classes could be added to handle non-US keyboards and the different input methods provided by various operating systems.

```
from adafruit_hid.keyboard import Keyboard
from adafruit_hid.keyboard_layout_us import KeyboardLayoutUS

kbd = Keyboard()
layout = KeyboardLayoutUS(kbd)

# Type 'abc' followed by Enter (a newline).
layout.write('abc\n')

# Get the keycodes needed to type a '$'.
# The method will return (Keycode.SHIFT, Keycode.FOUR).
keycodes = layout.keycodes('$')
```

The `Mouse` class simulates a three-button mouse with a scroll wheel.

```
from adafruit_hid.mouse import Mouse

m = Mouse()

# Click the left mouse button.
m.click(Mouse.LEFT_BUTTON)

# Move the mouse diagonally to the upper left.
m.move(-100, -100, 0)

# Roll the mouse wheel away from the user one unit.
# Amount scrolled depends on the host.
m.move(0, 0, -1)

# Keyword arguments may also be used. Omitted arguments default to 0.
m.move(x=-100, y=-100)
m.move(wheel=-1)

# Move the mouse while holding down the left button. (click-drag).
m.press(Mouse.LEFT_BUTTON)
m.move(x=50, y=20)
m.release_all()          # or m.release(Mouse.LEFT_BUTTON)
```

The `ConsumerControl` class emulates consumer control devices such as remote controls, or the multimedia keys on certain keyboards.

New in CircuitPython 3.0.

```
from adafruit_hid.consumer_control import ConsumerControl
from adafruit_hid.consumer_control_code import ConsumerControlCode

cc = ConsumerControl()

# Raise volume.
cc.send(ConsumerControlCode.VOLUME_INCREMENT)

# Pause or resume playback.
cc.send(ConsumerControlCode.PLAY_PAUSE)
```

The Gamepad class emulates a two-joystick gamepad with 16 buttons.

New in CircuitPython 3.0.

```
from adafruit_hid.gamepad import Gamepad

gp = Gamepad()

# Click gamepad buttons.
gp.click_buttons(1, 7)

# Move joysticks.
gp.move_joysticks(x=2, y=0, z=-20)
```


CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Building locally

To build this library locally you'll need to install the `circuitpython-build-tools` package.

```
python3 -m venv .env
source .env/bin/activate
pip install circuitpython-build-tools
```

Once installed, make sure you are in the virtual environment:

```
source .env/bin/activate
```

Then run the build:

```
circuitpython-build-bundles --filename_prefix adafruit-circuitpython-hid --library_
↳ location .
```

4.1 Sphinx documentation

Sphinx is used to build the documentation based on rST files and comments in the code. First, install dependencies (feel free to reuse the virtual environment from above):

```
python3 -m venv .env
source .env/bin/activate
pip install Sphinx sphinx-rtd-theme
```

Now, once you have the virtual environment activated:

```
cd docs
sphinx-build -E -W -b html . _build/html
```

This will output the documentation to `docs/_build/html`. Open the `index.html` in your browser to view them. It will also (due to `-W`) error out on any warning like Travis will. This is a good way to locally verify it will pass.

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/keyboard_shortcuts.py

```
1 import time
2 import board
3 import digitalio
4 from adafruit_hid.keyboard import Keyboard
5 from adafruit_hid.keycode import Keycode
6
7 kbd = Keyboard()
8
9 # define buttons. these can be any physical switches/buttons, but the values
10 # here work out-of-the-box with a CircuitPlayground Express' A and B buttons.
11 swap = digitalio.DigitalInOut(board.D4)
12 swap.direction = digitalio.Direction.INPUT
13 swap.pull = digitalio.Pull.DOWN
14
15 search = digitalio.DigitalInOut(board.D5)
16 search.direction = digitalio.Direction.INPUT
17 search.pull = digitalio.Pull.DOWN
18
19 while True:
20     # press ALT+TAB to swap windows
21     if swap.value:
22         kbd.send(Keycode.ALT, Keycode.TAB)
23
24     # press CTRL+K, which in a web browser will open the search dialog
25     elif search.value:
26         kbd.send(Keycode.CONTROL, Keycode.K)
27
```

(continues on next page)

(continued from previous page)

```
28 time.sleep(0.1)
```

Listing 2: examples/scroll.py

```

1 import time
2 import board
3 import digitalio
4 from adafruit_hid.mouse import Mouse
5
6 mouse = Mouse()
7
8 # define buttons. these can be any physical switches/buttons, but the values
9 # here work out-of-the-box with a CircuitPlayground Express' A and B buttons.
10 up = digitalio.DigitalInOut(board.D4)
11 up.direction = digitalio.Direction.INPUT
12 up.pull = digitalio.Pull.DOWN
13
14 down = digitalio.DigitalInOut(board.D5)
15 down.direction = digitalio.Direction.INPUT
16 down.pull = digitalio.Pull.DOWN
17
18 while True:
19     # scroll up one unit (varies with host/OS)
20     if up.value:
21         mouse.move(wheel=1)
22
23     # scroll down one unit (varies with host/OS)
24     elif down.value:
25         mouse.move(wheel=-1)
26
27     time.sleep(0.1)
```

5.2 adafruit_hid.keyboard.Keyboard

- Author(s): Scott Shawcroft, Dan Halbert

class adafruit_hid.keyboard.Keyboard

Send HID keyboard reports.

press (*keycodes)

Send a report indicating that the given keys have been pressed.

Parameters **keycodes** – Press these keycodes all at once.

Raises **ValueError** – if more than six regular keys are pressed.

Keycodes may be modifiers or regular keys. No more than six regular keys may be pressed simultaneously.

Examples:

```

from adafruit_hid.keycode import Keycode

# Press ctrl-x.
kbd.press(Keycode.LEFT_CONTROL, Keycode.X)

# Or, more conveniently, use the CONTROL alias for LEFT_CONTROL:
```

(continues on next page)

(continued from previous page)

```
kbd.press(Keycode.CONTROL, Keycode.X)

# Press a, b, c keys all at once.
kbd.press(Keycode.A, Keycode.B, Keycode.C)
```

release (*keycodes)

Send a USB HID report indicating that the given keys have been released.

Parameters **keycodes** – Release these keycodes all at once.

If a keycode to be released was not pressed, it is ignored.

Example:

```
# release SHIFT key
kbd.release(Keycode.SHIFT)
```

release_all()

Release all pressed keys.

send (*keycodes)

Press the given keycodes and then release all pressed keys.

Parameters **keycodes** – keycodes to send together

5.3 adafruit_hid.keycode.Keycode

- Author(s): Scott Shawcroft, Dan Halbert

class adafruit_hid.keycode.Keycode

USB HID Keycode constants.

This list is modeled after the names for USB keycodes defined in http://www.usb.org/developers/hidpage/Hut1_12v2.pdf#page=58. This list does not include every single code, but does include all the keys on a regular PC or Mac keyboard.

Remember that keycodes are the names for key *positions* on a US keyboard, and may not correspond to the character that you mean to send if you want to emulate non-US keyboard. For instance, on a French keyboard (AZERTY instead of QWERTY), the keycode for 'q' is used to indicate an 'a'. Likewise, 'y' represents 'z' on a German keyboard. This is historical: the idea was that the keycaps could be changed without changing the keycodes sent, so that different firmware was not needed for different variations of a keyboard.

A = 4

a and A

ALT = 226

Alias for LEFT_ALT; Alt is also known as Option (Mac)

APPLICATION = 101

Application: also known as the Menu key (Windows)

B = 5

b and B

BACKSLASH = 49

\ and |

BACKSPACE = 42

Delete backward (Backspace)

C = 6
c and C

CAPS_LOCK = 57
Caps Lock

COMMA = 54
, and <

CONTROL = 224
Alias for LEFT_CONTROL

D = 7
d and D

DELETE = 76
Delete forward

DOWN_ARROW = 81
Move the cursor down

E = 8
e and E

EIGHT = 37
8 and *

END = 77
End (often moves to end of line)

ENTER = 40
Enter (Return)

EQUALS = 46
= and ` +

ESCAPE = 41
Escape

F = 9
f and F

F1 = 58
Function key F1

F10 = 67
Function key F10

F11 = 68
Function key F11

F12 = 69
Function key F12

F13 = 104
Function key F13 (Mac)

F14 = 105
Function key F14 (Mac)

F15 = 106
Function key F15 (Mac)

F16 = 107
Function key F16 (Mac)

F17 = 108
Function key F17 (Mac)

F18 = 109
Function key F18 (Mac)

F19 = 110
Function key F19 (Mac)

F2 = 59
Function key F2

F3 = 60
Function key F3

F4 = 61
Function key F4

F5 = 62
Function key F5

F6 = 63
Function key F6

F7 = 64
Function key F7

F8 = 65
Function key F8

F9 = 66
Function key F9

FIVE = 34
5 and %

FORWARD_SLASH = 56
/ and ?

FOUR = 33
4 and \$

G = 10
g and G

GRAVE_ACCENT = 53
` and ~

GUI = 227
Alias for LEFT_GUI; GUI is also known as the Windows key, Command (Mac), or Meta

H = 11
h and H

HOME = 74
Home (often moves to beginning of line)

I = 12
i and I

INSERT = 73
Insert

J = 13
j and J

K = 14
k and K

KEYPAD_ASTERISK = 85
Keypad *

KEYPAD_BACKSLASH = 100
Keypad \ and | (Non-US)

KEYPAD_EIGHT = 96
Keypad 8 and Up Arrow

KEYPAD_ENTER = 88
Keypad Enter

KEYPAD_EQUALS = 103
Keypad = (Mac)

KEYPAD_FIVE = 93
Keypad 5

KEYPAD_FORWARD_SLASH = 84
Keypad /

KEYPAD_FOUR = 92
Keypad 4 and Left Arrow

KEYPAD_MINUS = 86
Keypad -

KEYPAD_NINE = 97
Keypad 9 and PgUp

KEYPAD_NUMLOCK = 83
Num Lock (Clear on Mac)

KEYPAD_ONE = 89
Keypad 1 and End

KEYPAD_PERIOD = 99
Keypad . and Del

KEYPAD_PLUS = 87
Keypad +

KEYPAD_SEVEN = 95
Keypad 7 and Home

KEYPAD_SIX = 94
Keypad 6 and Right Arrow

KEYPAD_THREE = 91
Keypad 3 and PgDn

KEYPAD_TWO = 90
Keypad 2 and Down Arrow

KEYPAD_ZERO = 98
Keypad 0 and Ins

L = 15
l and L

LEFT_ALT = 226
Alt modifier left of the spacebar

LEFT_ARROW = 80
Move the cursor left

LEFT_BRACKET = 47
[and {

LEFT_CONTROL = 224
Control modifier left of the spacebar

LEFT_GUI = 227
GUI modifier left of the spacebar

LEFT_SHIFT = 225
Shift modifier left of the spacebar

M = 16
m and M

MINUS = 45
-` and ``_

N = 17
n and N

NINE = 38
9 and (

O = 18
o and O

ONE = 30
1 and !

P = 19
p and P

PAGE_DOWN = 78
Go forward one page

PAGE_UP = 75
Go back one page

PAUSE = 72
Pause (Break)

PERIOD = 55
. and >

POUND = 50
and ~ (Non-US keyboard)

POWER = 102
Power (Mac)

PRINT_SCREEN = 70
Print Screen (SysRq)

Q = 20
q and Q

QUOTE = 52
' and "

R = 21
r and R

RETURN = 40
Alias for ENTER

RIGHT_ALT = 230
Alt modifier right of the spacebar

RIGHT_ARROW = 79
Move the cursor right

RIGHT_BRACKET = 48
] and }

RIGHT_CONTROL = 228
Control modifier right of the spacebar

RIGHT_GUI = 231
GUI modifier right of the spacebar

RIGHT_SHIFT = 229
Shift modifier right of the spacebar

S = 22
s and S

SCROLL_LOCK = 71
Scroll Lock

SEMICOLON = 51
; and :

SEVEN = 36
7 and &

SHIFT = 225
Alias for LEFT_SHIFT

SIX = 35
6 and ^

SPACE = 44
Alias for SPACEBAR

SPACEBAR = 44
Spacebar

T = 23
t and T

TAB = 43
Tab and Backtab

THREE = 32

3 and #

TWO = 31

2 and @

U = 24

u and U

UP_ARROW = 82

Move the cursor up

V = 25

v and V

W = 26

w and W

X = 27

x and X

Y = 28

y and Y

Z = 29

z and Z

ZERO = 39

0 and)

classmethod modifier_bit (*keycode*)

Return the modifier bit to be set in an HID keycode report if this is a modifier key; otherwise return 0.

5.4 adafruit_hid.keyboard_layout_us.KeyboardLayoutUS

- Author(s): Dan Halbert

class `adafruit_hid.keyboard_layout_us.KeyboardLayoutUS` (*keyboard*)

Map ASCII characters to appropriate keypresses on a standard US PC keyboard.

Non-ASCII characters and most control characters will raise an exception.

keycodes (*char*)

Return a tuple of keycodes needed to type the given character.

Parameters **char** (*str of length one.*) – A single ASCII character in a string.

Returns tuple of Keycode keycodes.

Raises **ValueError** – if **char** is not ASCII or there is no keycode for it.

Examples:

```
# Returns (Keycode.TAB,)
keycodes(' ')
# Returns (Keycode.A,)
keycode('a')
# Returns (Keycode.SHIFT, Keycode.A)
keycode('A')
# Raises ValueError because it's a accented e and is not ASCII
keycode('é')
```

write (*string*)

Type the string by pressing and releasing keys on my keyboard.

Parameters **string** – A string of ASCII characters.

Raises **ValueError** – if any of the characters are not ASCII or have no keycode (such as some control characters).

Example:

```
# Write abc followed by Enter to the keyboard
layout.write('abc\n')
```

5.5 adafruit_hid.mouse.Mouse

- Author(s): Dan Halbert

class adafruit_hid.mouse.**Mouse**

Send USB HID mouse reports.

LEFT_BUTTON = 1

Left mouse button.

MIDDLE_BUTTON = 4

Middle mouse button.

RIGHT_BUTTON = 2

Right mouse button.

click (*buttons*)

Press and release the given mouse buttons.

Parameters **buttons** – a bitwise-or'd combination of **LEFT_BUTTON**, **MIDDLE_BUTTON**, and **RIGHT_BUTTON**.

Examples:

```
# Click the left button.
m.click(Mouse.LEFT_BUTTON)

# Double-click the left button.
m.click(Mouse.LEFT_BUTTON)
m.click(Mouse.LEFT_BUTTON)
```

move (*x=0, y=0, wheel=0*)

Move the mouse and turn the wheel as directed.

Parameters

- **x** – Move the mouse along the x axis. Negative is to the left, positive is to the right.
- **y** – Move the mouse along the y axis. Negative is upwards on the display, positive is downwards.
- **wheel** – Rotate the wheel this amount. Negative is toward the user, positive is away from the user. The scrolling effect depends on the host.

Examples:

```
# Move 100 to the left. Do not move up and down. Do not roll the scroll wheel.
m.move(-100, 0, 0)
# Same, with keyword arguments.
m.move(x=-100)

# Move diagonally to the upper right.
m.move(50, 20)
# Same.
m.move(x=50, y=20)

# Roll the mouse wheel away from the user.
m.move(wheel=1)
```

press (buttons)

Press the given mouse buttons.

Parameters buttons – a bitwise-or'd combination of LEFT_BUTTON, MIDDLE_BUTTON, and RIGHT_BUTTON.

Examples:

```
# Press the left button.
m.press(Mouse.LEFT_BUTTON)

# Press the left and right buttons simultaneously.
m.press(Mouse.LEFT_BUTTON | Mouse.RIGHT_BUTTON)
```

release (buttons)

Release the given mouse buttons.

Parameters buttons – a bitwise-or'd combination of LEFT_BUTTON, MIDDLE_BUTTON, and RIGHT_BUTTON.

release_all ()

Release all the mouse buttons.

5.6 adafruit_hid.consumer_control.ConsumerControl

- Author(s): Dan Halbert

class adafruit_hid.consumer_control.ConsumerControl

Send ConsumerControl code reports, used by multimedia keyboards, remote controls, etc.

New in CircuitPython 3.0.

send (consumer_code)

Send a report to do the specified consumer control action, and then stop the action (so it will not repeat).

Parameters consumer_code – a 16-bit consumer control code.

Examples:

```
from adafruit_hid.consumer_control_code import ConsumerControlCode

# Raise volume.
consumer_control.send(ConsumerControlCode.VOLUME_INCREMENT)
```

(continues on next page)

(continued from previous page)

```
# Advance to next track (song).
consumer_control.send(ConsumerControlCode.SCAN_NEXT_TRACK)
```

5.7 `adafruit_hid.consumer_control_code.ConsumerControlCode`

- Author(s): Dan Halbert

class `adafruit_hid.consumer_control_code.ConsumerControlCode`

USB HID Consumer Control Device constants.

This list includes a few common consumer control codes from http://www.usb.org/developers/hidpage/Hut1_12v2.pdf#page=75.

New in CircuitPython 3.0.

EJECT = 184

Eject

FAST_FORWARD = 179

Fast Forward

PLAY_PAUSE = 205

Play/Pause toggle

RECORD = 178

Record

REWIND = 180

Rewind

SCAN_NEXT_TRACK = 181

Skip to next track

SCAN_PREVIOUS_TRACK = 182

Go back to previous track

STOP = 183

Stop

VOLUME_DECREMENT = 234

Decrease volume

VOLUME_INCREMENT = 233

Increase volume

5.8 `adafruit_hid.gamepad.Gamepad`

- Author(s): Dan Halbert

class `adafruit_hid.gamepad.Gamepad`

Emulate a generic gamepad controller with 16 buttons, numbered 1-16, and two joysticks, one controlling `x` and `y` values, and the other controlling `z` and `r_z` (z rotation or Rz) values.

The joystick values could be interpreted differently by the receiving program: those are just the names used here. The joystick values are in the range -127 to 127.

click_buttons (*buttons)

Press and release the given buttons.

move_joysticks (x=None, y=None, z=None, r_z=None)

Set and send the given joystick values. The joysticks will remain set with the given values until changed

One joystick provides x and y values, and the other provides z and r_z (z rotation). Any values left as None will not be changed.

All values must be in the range -127 to 127 inclusive.

Examples:

```
# Change x and y values only.
gp.move_joysticks(x=100, y=-50)

# Reset all joystick values to center position.
gp.move_joysticks(0, 0, 0, 0)
```

press_buttons (*buttons)

Press and hold the given buttons.

release_all_buttons ()

Release all the buttons.

release_buttons (*buttons)

Release the given buttons.

reset_all ()

Release all buttons and set joysticks to zero.

CHAPTER 6

Indices and tables

- `genindex`
- `modindex`
- `search`

a

`adafruit_hid.consumer_control`, [23](#)
`adafruit_hid.consumer_control_code`, [24](#)
`adafruit_hid.gamepad`, [24](#)
`adafruit_hid.keyboard`, [14](#)
`adafruit_hid.keyboard_layout_us`, [21](#)
`adafruit_hid.keycode`, [15](#)
`adafruit_hid.mouse`, [22](#)

A

A (adafruit_hid.keycode.Keycode attribute), 15
adafruit_hid.consumer_control (module), 23
adafruit_hid.consumer_control_code (module), 24
adafruit_hid.gamepad (module), 24
adafruit_hid.keyboard (module), 14
adafruit_hid.keyboard_layout_us (module), 21
adafruit_hid.keycode (module), 15
adafruit_hid.mouse (module), 22
ALT (adafruit_hid.keycode.Keycode attribute), 15
APPLICATION (adafruit_hid.keycode.Keycode attribute), 15

B

B (adafruit_hid.keycode.Keycode attribute), 15
BACKSLASH (adafruit_hid.keycode.Keycode attribute), 15
BACKSPACE (adafruit_hid.keycode.Keycode attribute), 15

C

C (adafruit_hid.keycode.Keycode attribute), 16
CAPS_LOCK (adafruit_hid.keycode.Keycode attribute), 16
click() (adafruit_hid.mouse.Mouse method), 22
click_buttons() (adafruit_hid.gamepad.Gamepad method), 24
COMMA (adafruit_hid.keycode.Keycode attribute), 16
ConsumerControl (class in adafruit_hid.consumer_control), 23
ConsumerControlCode (class in adafruit_hid.consumer_control_code), 24
CONTROL (adafruit_hid.keycode.Keycode attribute), 16

D

D (adafruit_hid.keycode.Keycode attribute), 16
DELETE (adafruit_hid.keycode.Keycode attribute), 16
DOWN_ARROW (adafruit_hid.keycode.Keycode attribute), 16

E

E (adafruit_hid.keycode.Keycode attribute), 16
EIGHT (adafruit_hid.keycode.Keycode attribute), 16
EJECT (adafruit_hid.consumer_control_code.ConsumerControlCode attribute), 24
END (adafruit_hid.keycode.Keycode attribute), 16
ENTER (adafruit_hid.keycode.Keycode attribute), 16
EQUALS (adafruit_hid.keycode.Keycode attribute), 16
ESCAPE (adafruit_hid.keycode.Keycode attribute), 16

F

F (adafruit_hid.keycode.Keycode attribute), 16
F1 (adafruit_hid.keycode.Keycode attribute), 16
F10 (adafruit_hid.keycode.Keycode attribute), 16
F11 (adafruit_hid.keycode.Keycode attribute), 16
F12 (adafruit_hid.keycode.Keycode attribute), 16
F13 (adafruit_hid.keycode.Keycode attribute), 16
F14 (adafruit_hid.keycode.Keycode attribute), 16
F15 (adafruit_hid.keycode.Keycode attribute), 16
F16 (adafruit_hid.keycode.Keycode attribute), 16
F17 (adafruit_hid.keycode.Keycode attribute), 17
F18 (adafruit_hid.keycode.Keycode attribute), 17
F19 (adafruit_hid.keycode.Keycode attribute), 17
F2 (adafruit_hid.keycode.Keycode attribute), 17
F3 (adafruit_hid.keycode.Keycode attribute), 17
F4 (adafruit_hid.keycode.Keycode attribute), 17
F5 (adafruit_hid.keycode.Keycode attribute), 17
F6 (adafruit_hid.keycode.Keycode attribute), 17
F7 (adafruit_hid.keycode.Keycode attribute), 17
F8 (adafruit_hid.keycode.Keycode attribute), 17
F9 (adafruit_hid.keycode.Keycode attribute), 17
FAST_FORWARD (adafruit_hid.consumer_control_code.ConsumerControlCode attribute), 24
FIVE (adafruit_hid.keycode.Keycode attribute), 17
FORWARD_SLASH (adafruit_hid.keycode.Keycode attribute), 17
FOUR (adafruit_hid.keycode.Keycode attribute), 17

G

G (adafruit_hid.keycode.Keycode attribute), [17](#)
 Gamepad (class in adafruit_hid.gamepad), [24](#)
 GRAVE_ACCENT (adafruit_hid.keycode.Keycode attribute), [17](#)
 GUI (adafruit_hid.keycode.Keycode attribute), [17](#)

H

H (adafruit_hid.keycode.Keycode attribute), [17](#)
 HOME (adafruit_hid.keycode.Keycode attribute), [17](#)

I

I (adafruit_hid.keycode.Keycode attribute), [17](#)
 INSERT (adafruit_hid.keycode.Keycode attribute), [17](#)

J

J (adafruit_hid.keycode.Keycode attribute), [18](#)

K

K (adafruit_hid.keycode.Keycode attribute), [18](#)
 Keyboard (class in adafruit_hid.keyboard), [14](#)
 KeyboardLayoutUS (class in adafruit_hid.keyboard_layout_us), [21](#)
 Keycode (class in adafruit_hid.keycode), [15](#)
 keycodes() (adafruit_hid.keyboard_layout_us.KeyboardLayoutUS method), [21](#)
 KEYPAD_ASTERISK (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_BACKSLASH (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_EIGHT (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_ENTER (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_EQUALS (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_FIVE (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_FORWARD_SLASH (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_FOUR (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_MINUS (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_NINE (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_NUMLOCK (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_ONE (adafruit_hid.keycode.Keycode attribute), [18](#)

KEYPAD_PERIOD (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_PLUS (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_SEVEN (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_SIX (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_THREE (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_TWO (adafruit_hid.keycode.Keycode attribute), [18](#)
 KEYPAD_ZERO (adafruit_hid.keycode.Keycode attribute), [18](#)

L

L (adafruit_hid.keycode.Keycode attribute), [19](#)
 LEFT_ALT (adafruit_hid.keycode.Keycode attribute), [19](#)
 LEFT_ARROW (adafruit_hid.keycode.Keycode attribute), [19](#)
 LEFT_BRACKET (adafruit_hid.keycode.Keycode attribute), [19](#)
 LEFT_BUTTON (adafruit_hid.mouse.Mouse attribute), [22](#)
 LEFT_CONTROL (adafruit_hid.keycode.Keycode attribute), [19](#)
 LEFT_GUI (adafruit_hid.keycode.Keycode attribute), [19](#)
 LEFT_SHIFT (adafruit_hid.keycode.Keycode attribute), [19](#)

M

M (adafruit_hid.keycode.Keycode attribute), [19](#)
 MIDDLE_BUTTON (adafruit_hid.mouse.Mouse attribute), [22](#)
 MINUS (adafruit_hid.keycode.Keycode attribute), [19](#)
 modifier_bit() (adafruit_hid.keycode.Keycode class method), [21](#)
 Mouse (class in adafruit_hid.mouse), [22](#)
 move() (adafruit_hid.mouse.Mouse method), [22](#)
 move_joysticks() (adafruit_hid.gamepad.Gamepad method), [25](#)

N

N (adafruit_hid.keycode.Keycode attribute), [19](#)
 NINE (adafruit_hid.keycode.Keycode attribute), [19](#)

O

O (adafruit_hid.keycode.Keycode attribute), [19](#)
 ONE (adafruit_hid.keycode.Keycode attribute), [19](#)

P

P (adafruit_hid.keycode.Keycode attribute), [19](#)
 PAGE_DOWN (adafruit_hid.keycode.Keycode attribute), [19](#)

- PAGE_UP (adafruit_hid.keycode.Keycode attribute), 19
- PAUSE (adafruit_hid.keycode.Keycode attribute), 19
- PERIOD (adafruit_hid.keycode.Keycode attribute), 19
- PLAY_PAUSE (adafruit_hid.consumer_control_code.ConsumerControlCode attribute), 24
- POUND (adafruit_hid.keycode.Keycode attribute), 19
- POWER (adafruit_hid.keycode.Keycode attribute), 19
- press() (adafruit_hid.keyboard.Keyboard method), 14
- press() (adafruit_hid.mouse.Mouse method), 23
- press_buttons() (adafruit_hid.gamepad.Gamepad method), 25
- PRINT_SCREEN (adafruit_hid.keycode.Keycode attribute), 19
- ## Q
- Q (adafruit_hid.keycode.Keycode attribute), 20
- QUOTE (adafruit_hid.keycode.Keycode attribute), 20
- ## R
- R (adafruit_hid.keycode.Keycode attribute), 20
- RECORD (adafruit_hid.consumer_control_code.ConsumerControlCode attribute), 24
- release() (adafruit_hid.keyboard.Keyboard method), 15
- release() (adafruit_hid.mouse.Mouse method), 23
- release_all() (adafruit_hid.keyboard.Keyboard method), 15
- release_all() (adafruit_hid.mouse.Mouse method), 23
- release_all_buttons() (adafruit_hid.gamepad.Gamepad method), 25
- release_buttons() (adafruit_hid.gamepad.Gamepad method), 25
- reset_all() (adafruit_hid.gamepad.Gamepad method), 25
- RETURN (adafruit_hid.keycode.Keycode attribute), 20
- REWIND (adafruit_hid.consumer_control_code.ConsumerControlCode attribute), 24
- RIGHT_ALT (adafruit_hid.keycode.Keycode attribute), 20
- RIGHT_ARROW (adafruit_hid.keycode.Keycode attribute), 20
- RIGHT_BRACKET (adafruit_hid.keycode.Keycode attribute), 20
- RIGHT_BUTTON (adafruit_hid.mouse.Mouse attribute), 22
- RIGHT_CONTROL (adafruit_hid.keycode.Keycode attribute), 20
- RIGHT_GUI (adafruit_hid.keycode.Keycode attribute), 20
- RIGHT_SHIFT (adafruit_hid.keycode.Keycode attribute), 20
- ## S
- S (adafruit_hid.keycode.Keycode attribute), 20
- SCAN_NEXT_TRACK (adafruit_hid.consumer_control_code.ConsumerControlCode attribute), 24
- SCAN_PREVIOUS_TRACK (adafruit_hid.consumer_control_code.ConsumerControlCode attribute), 24
- SCROLL_LOCK (adafruit_hid.keycode.Keycode attribute), 20
- SEMICOLON (adafruit_hid.keycode.Keycode attribute), 20
- send() (adafruit_hid.consumer_control.ConsumerControl method), 23
- send() (adafruit_hid.keyboard.Keyboard method), 15
- SEVEN (adafruit_hid.keycode.Keycode attribute), 20
- SHIFT (adafruit_hid.keycode.Keycode attribute), 20
- SIX (adafruit_hid.keycode.Keycode attribute), 20
- SPACE (adafruit_hid.keycode.Keycode attribute), 20
- SPACEBAR (adafruit_hid.keycode.Keycode attribute), 20
- STOP (adafruit_hid.consumer_control_code.ConsumerControlCode attribute), 24
- ## T
- T (adafruit_hid.keycode.Keycode attribute), 20
- TAB (adafruit_hid.keycode.Keycode attribute), 20
- THREE (adafruit_hid.keycode.Keycode attribute), 20
- TWO (adafruit_hid.keycode.Keycode attribute), 21
- ## U
- U (adafruit_hid.keycode.Keycode attribute), 21
- UP_ARROW (adafruit_hid.keycode.Keycode attribute), 21
- ## V
- V (adafruit_hid.keycode.Keycode attribute), 21
- VOLUME_DECREMENT (adafruit_hid.consumer_control_code.ConsumerControlCode attribute), 24
- VOLUME_INCREMENT (adafruit_hid.consumer_control_code.ConsumerControlCode attribute), 24
- ## W
- W (adafruit_hid.keycode.Keycode attribute), 21
- write() (adafruit_hid.keyboard_layout_us.KeyboardLayoutUS method), 21
- ## X
- X (adafruit_hid.keycode.Keycode attribute), 21
- ## Y
- Y (adafruit_hid.keycode.Keycode attribute), 21
- ## Z
- Z (adafruit_hid.keycode.Keycode attribute), 21
- ZERO (adafruit_hid.keycode.Keycode attribute), 21