
Adafruit MAX31855 Library Documentation

Release 1.0

Radomir Dopieralski

Jul 01, 2020

Contents

1	Dependencies	3
2	Installing from PyPI	5
3	Usage Example	7
4	Contributing	9
5	Documentation	11
6	Table of Contents	13
6.1	Simple test	13
6.2	adafruit_max31855	13
6.2.1	Implementation Notes	14
7	Indices and tables	15
	Python Module Index	17
	Index	19

CircuitPython driver for the [MAX31855 Thermocouple Amplifier Breakout](#)

CHAPTER 1

Dependencies

This driver depends on:

- [Adafruit CircuitPython](#)
- [Bus Device](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).

CHAPTER 2

Installing from PyPI

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-max31855
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-max31855
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name
python3 -m venv .env
source .env/bin/activate
pip3 install adafruit-circuitpython-max31855
```


CHAPTER 3

Usage Example

Of course, you must import the library to use it:

```
import adafruit_max31855
```

You also need to create an SPI interface object, and a pin object for the chip select pin. You can use any pin for the CS, but we use D5 here:

```
from busio import SPI
from digitalio import DigitalInOut
import board

spi = SPI(clock=board.SCK, MISO=board.MISO, MOSI=board.MOSI)
cs = DigitalInOut(board.D5)
```

Next, just create the sensor object:

```
sensor = adafruit_max31855.MAX31855(spi, cs)
```

And you can start making measurements:

```
print(sensor.temperature)
```

The temperature is read in degrees Celsius (°C). You have to convert it to other units yourself, if you need it.

CHAPTER 4

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 5

Documentation

For information on building library documentation, please check out [this guide](#).

6.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/max31855_simpletest.py

```
1 import time
2 import board
3 import busio
4 import digitalio
5 import adafruit_max31855
6
7 spi = busio.SPI(board.SCK, MOSI=board.MOSI, MISO=board.MISO)
8 cs = digitalio.DigitalInOut(board.D5)
9
10 max31855 = adafruit_max31855.MAX31855(spi, cs)
11 while True:
12     tempC = max31855.temperature
13     tempF = tempC * 9 / 5 + 32
14     print("Temperature: {} C {} F ".format(tempC, tempF))
15     time.sleep(2.0)
```

6.2 adafruit_max31855

This is a CircuitPython driver for the Maxim Integrated MAX31855 thermocouple amplifier module.

- Author(s): Radomir Dopieralski

6.2.1 Implementation Notes

Hardware:

- Adafruit [MAX31855 Thermocouple Amplifier Breakout](#) (Product ID: 269)

Software and Dependencies:

- Adafruit CircuitPython firmware for the ESP8622 and M0-based boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: https://github.com/adafruit/Adafruit_CircuitPython_BusDevice

class `adafruit_max31855.MAX31855` (*spi, cs*)
Driver for the MAX31855 thermocouple amplifier.

reference_temperature
Internal reference temperature in degrees Celsius.

temperature
Thermocouple temperature in degrees Celsius.

temperature_NIST
Thermocouple temperature in degrees Celsius, computed using raw voltages and NIST approximation for Type K, see: https://srdata.nist.gov/its90/download/type_k.tab

CHAPTER 7

Indices and tables

- `genindex`
- `modindex`
- `search`

a

adafruit_max31855, [13](#)

A

`adafruit_max31855` (*module*), [13](#)

M

`MAX31855` (*class in adafruit_max31855*), [14](#)

R

`reference_temperature`
(*adafruit_max31855.MAX31855 attribute*),
[14](#)

T

`temperature` (*adafruit_max31855.MAX31855 attribute*), [14](#)

`temperature_NIST` (*adafruit_max31855.MAX31855 attribute*), [14](#)