

---

# AdafruitMPRLS Library Documentation

*Release 1.0*

**ladyada**

**Mar 02, 2021**



---

## Contents

---

<b>1</b>	<b>Dependencies</b>	<b>3</b>
<b>2</b>	<b>Installing from PyPI</b>	<b>5</b>
<b>3</b>	<b>Usage Example</b>	<b>7</b>
<b>4</b>	<b>Contributing</b>	<b>9</b>
<b>5</b>	<b>Documentation</b>	<b>11</b>
<b>6</b>	<b>Table of Contents</b>	<b>13</b>
6.1	Simple test . . . . .	13
6.2	adafruit_mprls . . . . .	14
6.2.1	Implementation Notes . . . . .	14
<b>7</b>	<b>Indices and tables</b>	<b>15</b>
	<b>Python Module Index</b>	<b>17</b>
	<b>Index</b>	<b>19</b>



CircuitPython library to support Honeywell MPRLS digital pressure sensors.



# CHAPTER 1

---

## Dependencies

---

This driver depends on:

- [Adafruit CircuitPython](#)
- [Bus Device](#)

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the [Adafruit library and driver bundle](#).





## CHAPTER 2

---

### Installing from PyPI

---

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-mprls
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-mprls
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name
python3 -m venv .env
source .env/bin/activate
pip3 install adafruit-circuitpython-mprls
```



## CHAPTER 3

---

### Usage Example

---

```
import time
import board
import busio
import adafruit_mprls

i2c = busio.I2C(board.SCL, board.SDA)

# Simplest use, connect to default over I2C
mpr = adafruit_mprls.MPRLS(i2c, psi_min=0, psi_max=25)

while True:
    print((mpr.pressure,))
    time.sleep(1)
```



## CHAPTER 4

---

### Contributing

---

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.



## CHAPTER 5

---

### Documentation

---

For information on building library documentation, please check out [this guide](#).





## 6.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/mprls\_simpletest.py

```
1  # SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
2  # SPDX-License-Identifier: MIT
3
4  import time
5  import board
6  import busio
7  import adafruit_mprls
8
9  i2c = busio.I2C(board.SCL, board.SDA)
10
11 # Simplest use, connect to default over I2C
12 mpr = adafruit_mprls.MPRLS(i2c, psi_min=0, psi_max=25)
13
14 # You can also specify both reset and eoc pins
15 """
16 import digitalio
17 reset = digitalio.DigitalInOut(board.D5)
18 eoc = digitalio.DigitalInOut(board.D6)
19 mpr = adafruit_mprls.MPRLS(i2c, eoc_pin=eoc, reset_pin=reset,
20                            psi_min=0, psi_max=25)
21 """
22
23 while True:
24     print((mpr.pressure,))
25     time.sleep(1)
```

## 6.2 adafruit\_mprls

CircuitPython library to support Honeywell MPRLS digital pressure sensors

- Author(s): ladyada

### 6.2.1 Implementation Notes

**Hardware:**

**Software and Dependencies:**

- Adafruit CircuitPython firmware for the supported boards: <https://github.com/adafruit/circuitpython/releases>
- Adafruit's Bus Device library: [https://github.com/adafruit/Adafruit\\_CircuitPython\\_BusDevice](https://github.com/adafruit/Adafruit_CircuitPython_BusDevice)

**class** `adafruit_mprls.MPRLS` (*i2c\_bus*, \*, *addr*=24, *reset\_pin*=None, *eoc\_pin*=None, *psi\_min*=0, *psi\_max*=25)

Driver base for the MPRLS pressure sensor :param *i2c\_bus*: The `busio.I2C` object to use. This is the only required parameter. :param *int addr*: The optional I2C address, defaults to 0x18 :param *microcontroller.Pin reset\_pin*: Optional digitalio pin for hardware resetting :param *microcontroller.Pin eoc\_pin*: Optional digitalio pin for getting End Of Conversion signal :param *float psi\_min*: The minimum pressure in PSI, defaults to 0 :param *float psi\_max*: The maximum pressure in PSI, defaults to 25

**pressure**

The measured pressure, in hPa

## CHAPTER 7

---

### Indices and tables

---

- `genindex`
- `modindex`
- `search`



### **a**

`adafruit_mprls`, [13](#)



## A

`adafruit_mprls` (*module*), [13](#)

## M

`MPRLS` (*class in `adafruit_mprls`*), [14](#)

## P

`pressure` (*`adafruit_mprls.MPRLS` attribute*), [14](#)