
AdafruitTFmini Library Documentation

Release 1.0

ladyada

Jan 20, 2021

Contents

1 Dependencies	3
1.1 Installing from PyPI	3
2 Usage Example	5
3 Contributing	7
4 Documentation	9
5 Table of Contents	11
5.1 Simple test	11
5.2 adafruit_tfmini	12
5.2.1 Implementation Notes	12
6 Indices and tables	13
Python Module Index	15
Index	17

A CircuitPython/Python library for Benewake's TF mini distance sensor

CHAPTER 1

Dependencies

This driver depends on:

- Adafruit CircuitPython

Please ensure all dependencies are available on the CircuitPython filesystem. This is easily achieved by downloading the Adafruit library and driver bundle.

1.1 Installing from PyPI

On supported GNU/Linux systems like the Raspberry Pi, you can install the driver locally [from PyPI](#). To install for current user:

```
pip3 install adafruit-circuitpython-tfmini
```

To install system-wide (this may be required in some cases):

```
sudo pip3 install adafruit-circuitpython-tfmini
```

To install in a virtual environment in your current project:

```
mkdir project-name && cd project-name
python3 -m venv .env
source .env/bin/activate
pip3 install adafruit-circuitpython-tfmini
```


CHAPTER 2

Usage Example

```
import time
import board # comment this out if using pyserial
import busio # comment this out if using pyserial
import adafruit_tfmini

# Use hardware uart
uart = busio.UART(board.TX, board.RX)

# Or, you can use pyserial on any computer
#import serial
#uart = serial.Serial("/dev/ttyS2", timeout=1)

# Simplest use, connect with the uart bus object
tfmini = adafruit_tfmini.TFmini(uart)

# You can put in 'short' or 'long' distance mode
tfmini.mode = adafruit_tfmini.MODE_SHORT
print("Now in mode", tfmini.mode)

while True:
    print("Distance: %d cm (strength %d, mode %x)" %
          (tfmini.distance, tfmini.strength, tfmini.mode))
    time.sleep(0.1)
```


CHAPTER 3

Contributing

Contributions are welcome! Please read our [Code of Conduct](#) before contributing to help this project stay welcoming.

CHAPTER 4

Documentation

For information on building library documentation, please check out [this guide](#).

CHAPTER 5

Table of Contents

5.1 Simple test

Ensure your device works with this simple test.

Listing 1: examples/tfmini_simpletest.py

```
1 # SPDX-FileCopyrightText: 2021 ladyada for Adafruit Industries
2 # SPDX-License-Identifier: MIT
3
4 import time
5 import board # comment this out if using pyserial
6 import busio # comment this out if using pyserial
7 import adafruit_tfmini
8
9 # Use hardware uart
10 uart = busio.UART(board.TX, board.RX)
11
12 # Or, you can use pyserial on any computer
13 # import serial
14 # uart = serial.Serial("/dev/ttyS2", timeout=1)
15
16 # Simplest use, connect with the uart bus object
17 tfmini = adafruit_tfmini.TFmini(uart)
18
19 # You can put in 'short' or 'long' distance mode
20 tfmini.mode = adafruit_tfmini.MODE_SHORT
21 print("Now in mode", tfmini.mode)
22
23 while True:
24     print(
25         "Distance: %d cm (strength %d, mode %x)"
26         % (tfmini.distance, tfmini.strength, tfmini.mode)
27     )
```

(continues on next page)

(continued from previous page)

28 `time.sleep(0.1)`

5.2 adafruit_tfmini

A CircuitPython/Python library for Benewake's TF mini distance sensor

- Author(s): ladyada

5.2.1 Implementation Notes

Hardware:

Software and Dependencies:

- Adafruit CircuitPython firmware for the supported boards: <https://github.com/adafruit/circuitpython/releases>

class adafruit_tfmini.TFmini(uart, *, timeout=1)

TF mini communication module, use with just RX or TX+RX for advanced command & control. :param uart: the pyserial or busio.uart compatible uart device :param timeout: how long we'll wait for valid data or response, in seconds. Default is 1

distance

The most recent distance measurement in centimeters

mode

The measurement mode can be MODE_SHORT (2) or MODE_LONG (7)

strength

The signal validity, higher value means better measurement

CHAPTER 6

Indices and tables

- genindex
- modindex
- search

Python Module Index

a

adafruit_tfmini, 12

Index

A

`adafruit_tfmini` (*module*), 12

D

`distance` (*adafruit_tfmini.TFmini* attribute), 12

M

`mode` (*adafruit_tfmini.TFmini* attribute), 12

S

`strength` (*adafruit_tfmini.TFmini* attribute), 12

T

`TFmini` (*class in adafruit_tfmini*), 12